BLASTMAX 300 PUMP

ADVANCED PRESSURE SYSTEMS

OPERATION AND MAINTENANCE MANUAL

32-520-505 - REV. 0 - APRIL 2023



NOTICE

This document contains subject matter in which Advanced Pressure Systems has proprietary rights. Recipients of this document shall not duplicate, use, or disclose information contained herein, in whole or in part, for other than the purpose for which this manual was provided.

Advanced Pressure Systems believes the information described in this manual to be accurate and reliable. Much care has been taken in its preparation; however, the Company cannot accept any responsibility, financial or otherwise, for any consequences arising out of the use of this material. The information contained herein is subject to change, and revisions may be issued advising of such changes and/or additions.

ADVANCED PRESSURE SYSTEMS 2023



ADVANCED PRESSURE SYSTEMS

701 S. PERSIMMON ST. TOMBALL, TEXAS 77375

PHONE: 281-290-9950 TOLL FREE: 887-290-4277 SALES-TEAM@ADVANCEDPRESSURESYSTEMS.COM WWW.ADVANCEDPRESSURESYSTEMS.COM

co	N٦	FN	JT	S
			• •	0

About This Content	5
Overview	5
Safety	6
Safety Precautions	б
Safety Messages	9
Personal Protective Equipment (PPE)	10
Emergency Medical Information	11
Lockout/Tagout	12
Operation	. 13
Overview	13
Transporting	13
Before Starting the System	13
Startup	14
Proper Operation	15
Decommissioning	16
System Storage	16
Operation Safety Guidelines	. 18
Overview	18
General Safety Guidelines	18
Pressure Relief Devices	19
High Pressure Hose and Lance Assemblies	20
Control Gun and Control Device Safety	21
Rigid Tube Cleaning Lance Safety	22
Flexible Tube Cleaning Lance Safety	22
Nozzles	23
Personal Protective Equipment	24
Maintenance	. 26
Overview	26
Maintenance Precautions	26
Torque Specification	27
Daily Inspection	28
Monthly Maintenance	28
High Pressure Fittings and Connections	29
Filters and Strainers	29

Nozzles, Holders and Lance Connections	
Trigger and Valve Controls	
High Pressure Hoses	
Hydrostatic Testing	
Proper Hose Storage	
Replacing Maintenance Items	
Replace the Inlet Water Filters	
Replace the Hydraulic Oil Filters	
Power End Assembly	
Overview	
Power End Disassembly	
Intermediate Rod and Oil Wiper Seal Removal	
Crankshaft Removal	
Connecting Rod Removal	
Power End Installation	
Main Roller Bearing Replacement	
Connecting Rod & Crosshead Assembly Installation	
Crankshaft Installation	
Crankshaft Journal Bearing Replacement	
Crankshaft Wiper Seal Replacement	
Power End Lubrication	
Types of Lubrication	
Oil Replacement	
LP Fluid End Assembly	
Maintenance Overview	
Torque Specification	
Valve Assemblies	
Packing Assemblies	
Low Pressure Seal Assemblies	
Barrel Assemblies	
HP Fluid End Assembly	
Maintenance Overview	
Torque Specification	
Valve Assemblies	
Packing Assemblies	
Low Pressure Seal Assemblies	

Barrel Assemblies	
UHP Fluid End Assembly	
Maintenance Overview	
Torque Specification	
Valve Assemblies	
Packing Assemblies	
Low Pressure Seal Assemblies	
Barrel Assemblies	
Motor Starters	
Across-the-Line	
Variable Frequency Drive (VFD)	
Soft Start	
Troubleshooting	
Overview	
Troubleshooting Guide	
Diesel Engine	
Specifications	
General	
Standard Operating Parameters	
High Pressure Pump	
Diesel Engine	
Electric Motor	
Lubrication Specification	
Service Connections	
Installation Dimensions	
Inlet Water	
Carbide Nozzle Size Selector Chart	
References	
Engineering Drawings	
Spare Parts	
Appendix	

About This Content

Disclaimer

Due to continuing product improvement, the information contained in this document is subject to change without notice. Advanced Pressure Systems shall not be held liable for technical or editorial omissions made herein, nor for any incidental or consequential damage resulting from the use of this material.

Copyright

This content contains information protected by copyright. No part of this document shall be reproduced in any manner without prior written consent from Advanced Pressure Systems.

©2020 Advanced Pressure Systems. All rights reserved. ORIGINAL INSTRUCTIONS.

Overview

The APS Series 300 is a powerful positive displacement, triplex plunger pump system. These pumps are designed and manufactured to operate in continuous service at a designed flow and pressure. With pressures ranging from 5,000 psi to 40,000 psi (345 bar to 2,758 bar), the Series 300 is an extremely versatile pump. The Series 300 is designed for full-scale industrial use including but not limited to industrial cleaning, surface preparation and hydrostatic testing applications.

Features include:

- A triplex, belt-drive, high-pressure pump with easy access to seals and check valves.
- Multiple diesel engine options:
 - o 302 hp Caterpillar Model C-7.1 Tier 4 diesel engine.
 - o 275 hp Caterpillar Model C-7.1 Tier 3 diesel engine. (export only)
 - o 335 hp Caterpillar Model C-9.3 Tier 3 diesel engine. (export only)
- Multiple electric options ranging from 150 hp to 300 hp.
- A closed-loop oil lubrication system
- An inlet water booster pump with water filtration to 10 microns absolute.
- Over-pressure protection discs, as equipped.

Adhering to the recommended procedures for operation and maintenance outlined in this manual will ensure optimum benefit is obtained from the high-quality components used in the design and construction of the Series 300 pump system.

Safety

Advanced Pressure Systems designed your high-pressure waterjet cutting system and related equipment with safety in mind. Although the waterjet can appear harmless, it is a high-energy cutting tool capable of cutting many materials such as composites, metals, plastics, and wood products. Misuse of this equipment or carelessness in its application is extremely hazardous to personnel. Always treat the waterjet system with respect.



READ CAREFULLY BEFORE USE. KEEP FOR FUTURE REFERENCE!

Safety Precautions

Follow all safety precautions to ensure safe operation of the equipment.

- Only trained, qualified personnel shall service and maintain the equipment.
- Safety glasses and ear protection shall be worn when operating or working near the pump.
- Do not allow the waterjet stream to touch any part of your body—it will cause serious injury.
- Never point a waterjet cutting or cleaning tool at yourself or any person. Do not aim any waterjet tool at anything you do not want to cut.
- During equipment maintenance, take the system out of service. Lock and mark the controls with a warning sign. See Lockout/Tagout for details.
- All personnel required to do any system operation or service function must pay particular attention to all warning signs and notices posted in the plant and on the equipment.
- All protective guards, shields, and covers must be in place on the equipment at all times.
- First aid facilities shall be provided in convenient locations throughout the plant. All personnel must know the locations of the first aid facilities.
- Always keep the work area around the equipment clean and free of debris. Fluid spillage results in slippery floors. Clean up spills immediately.
- Any unfavorable conditions that can result in injuries must be reported to the plant supervisor immediately.
- Do not wear loose clothing or jewelry while working around equipment with moving parts.
- Pressurized air can drive particles into the eyes and skin if handled incorrectly. Use appropriate personal protective equipment and exercise caution.
- Only use water-based solvents for cleaning parts.

Diesel engines

- Do not allow the engine to exhaust into a closed work area. Provide either adequate ventilation or vent the exhaust outdoors.
- Do not overfill the fuel tank.
- Do not operate the engine in an explosive or flammable environment.
- Do not allow flammable liquids to touch the engine while it is hot.
- Do not operate the engine without its protective covers in place.
- Do not attempt to service the engine while it is in operation.
- Do not allow moving parts to contact either your clothing or body.
- Do not allow fuel to contact exposed portions of your body.

Electrical

- Only a certified electrician shall do electrical and/or electronic troubleshooting and servicing of electrical devices.
- Always assume that power is ON in all electrical systems. Always examine and lockout the main power switches before servicing the equipment. Post a sign, "Maintenance in Progress—Do Not Energize."
- Be aware that live electrical circuits are present in the control console whenever the master disconnect switch is in the ON position, regardless of whether the E-Stop is engaged.
- Turn off the circuit breakers located inside the electrical enclosure before servicing the electrical system. If this is not possible, have someone stand by to prevent someone from powering up the system.
- Take extra precautions when servicing the power system in a damp environment.
- Never alter or bypass protective interlocks or devices.
- Never use jumper wires across fuses, fuse holders, or breakers.
- Never use metal rulers, flashlights, pencils, or tools that have exposed conductive material when working near electrical/electronic components.
- Ensure all tools are correctly insulated for the job. Use only correct test apparatus; regularly examine to ensure they are working correctly. Use caution when connecting a test probe to test points.
- When connecting a voltmeter to terminals for measurement, use a range higher than the expected voltage.
- All replacement wires shall conform to the manufacturer's specifications, including colorcoding, wire numbers, and size.
- Close and latch the control panel doors or junction box covers after servicing.
- Maintain all electrical components, protective guards, and shutdown devices according to approved practices.

High-Pressure Cleaning Tools

- Turn off equipment and relieve water pressure before replacing nozzles, tips, or bits.
- Hang a warning sign on the control panel that states that the equipment is being serviced and is not available for use until servicing is complete.
- Install all protective covers and shielding on equipment before starting the pump.
- Examine for leakage after nozzle or tip replacement and correct the leak immediately.
- Use only Flow manufactured or approved waterjet nozzles, cleaning tips, and drilling or cutting bits.

Mechanical

- Do not start the system unless you know how to stop it.
- Never maintain, service, or clean around the equipment while it is operating.
- Do not use incorrect tools—they can cause injury or costly damage to equipment.
- Use only approved test equipment. Examine the equipment regularly for correct operation and calibration.
- Never climb on or around the equipment on makeshift devices. Use only approved catwalks, ladders, or platforms.
- Do not exceed specified pressure setting limits for pneumatic or hydraulic components. Exceeding these limits may result in serious injury to personnel or damage to the equipment.
- Shield and bundle equipment hoses and cables so they do not obstruct the operator's freedom of movement.
- Always be alert when working around the equipment.
- Remove all tools, parts, and rags from moving parts after servicing the equipment.

Safety Messages

Safety messages are highlighted with the safety alert symbol and a signal word or a signal word panel. Pay particular attention to these safety messages and all safety precautions posted on the equipment.

Safety Alert Symbol



This is the safety alert symbol. The safety alert symbol informs you of potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

Signal Words

WARNING!	WARNING indicates a hazardous situation, which if not avoided, can result in death or serious injury.
CAUTION!	CAUTION indicates a hazardous situation, which if not avoided, can result in minor or moderate injury.

Signal Panel Words

A DANGER	DANGER indicates a hazardous situation, which if not avoided, will result in death or serious injury.
A CAUTION	CAUTION emphasize operating or service procedures, or conditions that can result in equipment damage or impairment of system operation.
NOTICE	NOTICE indicates a non-hazardous situation, which if not avoided, can result in property damage.

Personal Protective Equipment (PPE)

Personal protective equipment (PPE) is equipment worn to minimize exposure to serious workplace injuries and illnesses.



Helmets must be worn at all times by all personnel within the work area. Helmet material must withstand a mechanical shock to 10 G in 8 ms without fracturing.





Operators must wear safety glasses with side shields and a visor, or goggles and a visor, to guard against spray and flying debris.



Operators and other personnel must wear safety footwear with steel toecaps a minimum of 5 mm (0.02-in.) thick. The toecap must cover at least 30% of the footwear length. Footwear must have metatarsal guards to provide instep protection.



The operators and other personnel exposed to noise levels of more than 90 dBa for more than 1 hour must wear suitable ear protection. Earplugs and muffs are usually adequate.



The operators must wear gloves at all times; leather gloves are preferred.



Waterproof garments only protect the operator from spray and flying debris. They do NOT deflect direct jet impact.

Emergency Medical Information



WARNING! Obtain medical treatment immediately for ANY high-pressure waterjet injuries.

It is vital that medical personnel have information about this type of injury. We recommend that all personnel working with waterjet equipment carry a medical alert card or tag that describes their work and the nature of injuries inherent in using waterjets.



Lockout/Tagout

You can lock out the water supply and electrical systems separately. Under most circumstances, you should lock out both systems.

This lockout/tagout procedure is designed to protect all employees from injuries caused by the unexpected energizing or startup of the machine, or the release of stored energy during service and maintenance.

This is accomplished with energy isolating devices that prevent the transmission or release of energy. An energy source is any source of electrical, mechanical, hydraulic, pneumatic, chemical, thermal, or other energy source that could cause injury to personnel.

A lockout device utilizes a lock and key to hold an energy isolating device in the safe position and prevents the machine from being energized. A tagout device is a prominent warning device that can be securely attached to the machine warning personnel not to operate the energy isolating device. This procedure requires the combination of a lockout device and a tagout device.

Water Supply

- 1. Shut down the pump.
- 2. Look at the gauges on the display to ensure that the UHP pressure is bled down.
- 3. Turn off the water supply to the boost pump.
- 4. Close the inlet water valve, and then install a lockout/tagout device.
- 5. Open the top and bottom petcocks on the water filter canister to drain the filter canister. If the draining water appears to be under pressure, ensure that the inlet water valve is closed.
- 6. If equipped, ensure isolation of the inlet water by looking at the Pre-Filter and After-Filter pressure on the Pump Data screen. Both readings should be at zero.

Electrical

- 1. Shut down the system.
- 2. Remove the battery box cover.
- 3. Use a 9/16-in. wrench to remove the negative (black) lead from the battery. This cable connects from the battery to the battery disconnect.
- 4. Install a lockout/tagout device over the negative battery cable.
- 5. Use a 9/16-in. wrench to remove the positive (red) lead from the positive battery post. This wire connects from the battery to the engine starter motor.
- 6. Install a lockout/tagout device over the positive battery cable.

Operation

Overview

Commissioning requirements and procedures are detailed in this section. These procedures require a thorough understanding of the individual components, safety issues, and the overall operation of the system.

All personnel involved in the operation and/or service of the system must carefully review this manual prior to commissioning and operating the machine.

The Technical Service Department at Advanced Pressure Systems is available to assist in the commissioning and operation process. Service and repair training for maintenance personnel is also available.

Transporting

The weight of the machine is not evenly distributed from one end to the other, particularly on the larger horsepower models. Do not attempt to lift the machine from either end. Note the warnings stamped on the unit. The center of gravity is located at approximately the location of the lifting eye if so equipped. The forklift should be positioned accordingly.

When the machine has been removed from the crate, note the position of the fork pockets on the bottom of the machine if so equipped. The pockets are positioned in relationship to the center of gravity to balance the weight on the forklift.

Trailer units should be transported based on the type of hitch provided and the weight rating of the unit. The unit should only be transported with the water and fuel tanks empty.

Before Starting the System

Prior to starting the system review the manufacturer's manuals included in the appendix covering the operation of the engine and drive train.

- 1. Set unit on a level surface to ensure that oil in the power end reaches the crankshaft main bearings.
- 2. Check oil and coolant levels in the pump and engine. Refer to Section 8, Specifications for information regarding power end lubrication. Refer to the engine manual in the appendix for system component lubrication.
- 3. If the pump has an oil level shutdown switch, set the shutdown trips 1/2 inch above and 1 inch below the dipstick Hi-Lo level marks.

- 4. Inspect battery cables and hoses to ensure they are tight and secure.
- 5. Check fuel tank levels on engine powered units.
- 6. Check engine power take off and drive train for tension and lubrication, see the manufacturer's manual in the appendix.
- 7. Check charge pump drives, if applicable.
- 8. Ensure the plunger and intermediate rod connections are tight.
- 9. Verify all bolts are torqued to the specified level.
- 10. Verify connections on the suction and discharge manifolds are tight and do not leak.

CAUTION Do not tighten high pressure connections when the system is pressurized. Remove all pressure from the system before tightening connections.

- 11. Ensure the supply water and the filters and strainers are clean.
- 12. Verify the pressure rating stamped on the application tag for the pump matches the pump speed, plunger size, engine horsepower and the accessories to be used with the unit.
- 13. If supplied, verify the pressure relief valve is set 10 to 15 percent above the specified maximum working pressure.
- 14. Ensure the supply water line to the pump is airtight. Air entering the suction side, supply line will cause severe knocking and cavitation of the pump.
- 15. Attach a pressurized supply water line to the pump system inlet connector, 30 psi (1.4 bar) minimum or 80 psi (5.5 bar) minimum for 40,000 psi (2,758 bar) applications. The inlet supply line must be sized to flow at least double the GPM to be pumped from the system.

NOTICE

DO NOT gravity feed the pump. Fluid supplied to the suction side must be pressurized to help protect against cavitation damage.

16. Check to ensure supply water is flowing to the system.

Startup

- 1. Disengage the clutch on diesel or gasoline engine units or open the bypass flow regulating valve on electric powered units. Open the regulator valve for the charge pump, if applicable.
- 2. Remove the nozzles or disconnect the pump for the work to allow maximum flow to be pumped without pressure for one minute.
- 3. Turn on the pressurized supply line water.
- 4. Start the engine or the electric motor.
- 5. Engage the engine clutch and/or close the bypass flow regulating valve.



Ensure that you have charge pump water pressure and oil pressure if power end is forced lubricated before engaging the PTO.

6. With the nozzles removed, pump fluid through the system for at least one minute.

- 7. Stop the engine or motor and replace the nozzles.
- 8. Start the engine or motor and gradually increase flow through the system to the maximum allowable pressure. Observe the pump pressure gauge to ensure the reading does not rise above the specified allowable working pressure. If applicable, verify the charge pump pressure is at least 30 psi (1.4 bar), or 80 psi (5.5 bar) for 40,000 psi (2,758 bar) applications.
- 9. Set the manual and automatic throttle speed controls on the engine or adjust the by-pass flow regulating valve on electric motor driven systems to obtain the specified allowable working pressure.
- 10. With the pump operating at its rated full speed the maximum working pressure should be reached easily. If the maximum working pressure cannot be reached at full speed, check the nozzle size or the system plumbing for leakage. Refer to Section 7, Troubleshooting, if the issue is not resolved.
- 11. Ensure the suction and discharge valves remain fully open during operation.

ACAUTION Never close the suction or discharge valves while the pump is running.

12. Check the plunger packing for leakage.

Proper Operation

In most jetting operations is it common practice to employ a minimum of two persons as a team. The nozzle operator holds a gun, lance or delivery hose and controls the motion and direction of the jet(s). The pump operator monitors and controls the pressurizing pump during jetting operation

- 1. The nozzle and pump operators should be aware of the working pressure for the job and pump and nozzle orifice sizes should be selected to match these conditions.
- 2. The pump operator should not start the unit until told to do so by the nozzle operator. Before the bringing the system up to pressure, the pump operator should ensure the jetting nozzle is either directed at the work piece; that the nozzle operator has a secure stance and control of the nozzle; and each team member is in the proper position to perform their task.
- 3. The pump operator should slowly raise the pressure of the system to allow the nozzle operator to adjust to the changing reaction force from the nozzle. Once the operating pressure has been reached, the pressure should not be further adjusted without the operator's awareness. When the pressure is reduced at shutdown, the pressure should also be lowered slowly to prevent the sudden lack of force from causing the operator to lose their balance.



The reaction force experienced by the nozzle operator can suddenly change when the trigger on a gun activates a dry shutoff or dump valve.



The operator should be familiar with the change in thrust at various **A CAUTION** pressures, including the working pressure for the job. The operator's stance should allow them to withstand these changes.

4. Both before and after bringing the system up to pressure the pump operator should visually examine the hose and connections to the jetting gun or nozzle for leaks.

Decommissioning

All local regulations must be adhered to for recycling and decontamination before the pump is decommissioned and taken out of service for any reason.

- 1. Shutdown the pump according to the 'Standard System Shutdown' procedure above.
- 2. Remove all of the following fluids: engine oil, hydraulic oil from the hydraulic circuit, diesel fuel and coolant from the radiator and cooling circuit.
- 3. Remove oil filters from the hydraulic circuit, oil and fuel filters from the engine, batteries and control box and electronics.
- 4. Dispose of (or recycle) the oil, fuel, coolant, filters, batteries, and electronics in accordance with local regulations.

System Storage

If the system will be idled for an extended period, it must be prepared for storage as detailed below.

1. Drain and clean the power end. Leave the drain open to permit air circulation and prevent condensation buildup.

NOTICE Fluids can be evacuated from the pump by blowing compressed air through the suction manifold.

- 2. Coat all bearings and machined surfaces inside the crankshaft with a rust inhibiting oil.
- 3. Rotate the crankshaft each month.
- 4. Read the engine maintenance manual for instructions regarding storage.



If a pump is to be stored for extended periods it is recommended by Caterpillar that the engine is turned on and allowed to warm up every 2 weeks. This is to prevent crystallization of the def components used to meet Tier 4 emissions standards. Failure to do so increases risk of def related engine codes causing the engine not to run.

Cold Weather Storage

The following additional steps should be taken when the system is taken out of service in temperatures below freezing.

- 1. If compressed air is available, connect an appropriately secured compressed air line to the inlet connection on the suction manifold and evacuate fluids from the pump and associated plumbing.
- 2. If compressed air is not available, introduce anti-freeze into the suction line and rotate the pump to mix any fluid remaining in the system with anti-freeze.
- 3. Read the engine maintenance manual for instructions regarding cold weather storage.

Startup After Storage

A system that is removed from storage must be thoroughly inspected for damage before it is returned to service. Verify that all component parts are in working order.

A CAUTION Failure to observe the following instructions can result in equipment damage.

- 1. Open the covers on the power end, engine, and drive train.
- 2. Verify the bearings are clean and in good condition.
- 3. Verify the plungers, valves and packing are properly installed and in good condition.
- 4. Verify proper tightness of bolts, nuts, studs, and fluid connections.
- 5. Fill the power end to the proper level with clean oil of the proper viscosity.
- 6. Pour oil into the crosshead reservoir and work into all the bearings.
- 7. If applicable, fill the engine with oil as recommended in the engine manual shipped with the pump.
- 8. Grease the power take off or u-joints.
- 9. Follow the startup and operations instructions in this section.

Operation Safety Guidelines

Overview

Advanced Pressure Systems products are sold with the understanding that the purchaser agrees to thoroughly train all operating and maintenance personnel in the correct and safe installation, operation and maintenance of waterblast equipment and to provide adequate supervision of personnel at all times.

Waterblast operators must be made aware that the cleaning nozzle's discharge jet can inflict serious bodily injury.

Additional safety information and updates may be obtained from the Waterjet Technology Association website at www.wjta.org.

General Safety Guidelines

Advanced Pressure Systems high pressure pump systems are designed to produce specifically related flows and pressures. Use caution when selecting nozzles and adjusting pressures to match the flow and working pressure of the specific pump model.

A CAUTION Never over-pressurize the system.

- 1. Use only products intended for high pressure water blasting. No product should be altered without the written consent of the manufacturer.
- 2. Read and follow all manufacturers' instructions prior to using any waterblast product. Contact the manufacturer should questions remain.
- 3. Inspect the condition of all components prior to use. Do not use an item in questionable condition.
- 4. Place barricades with warning signs or barricade tape around the work area.

Operational Safety



Never direct high-pressure fluid jets toward anyone or to any part of your body. High pressure water will penetrate all parts of the human body. The liquid stream and the material ejected by the extreme pressure can result in severe injury.

1. The operator handling the cleaning device and nozzle **must always** have control of the water pressure.

A surface cleaner operator should operate a trigger style, control gun capable of instantaneously stopping pressure to the nozzle.

A tube cleaning lance operator should operate a foot gun capable of instantaneously stopping pressure to the lance.

2. Before attaching a nozzle to the control gun or tube cleaning lance operate the pump at low speed to purge dirt and debris from the system.

A CAUTION Dirt and debris can clog the nozzle orifice(s) and cause excessive system pressures that could lead to a lance failure.

- 3. With the nozzle installed, operate the pump at a low pressure to test the system. If system repairs or adjustments are necessary, stop the pump and relieve all pressure before making required repairs or adjustments.
- 4. With the system operating properly, increase pump pressure slowly until the operating pressure is reached and adjusted. Pressure adjustments should always be made slowly.
- 5. Use the minimum pressure required for cleaning. Do not exceed the operating pressure of the system's lowest pressure rated component. All equipment pressure rating markers and warning tags should be left intact.
- 6. If equipment or system malfunction is suspected, immediately stop cleaning activities and relieve the pressure in the system before attempting any repairs. Always follow the manufacturer's repair instructions.
- 7. Following any repairs, operate the pump at a low pressure to test the system. Bring the system up to the operating pressure slowly.
- 8. If the system is shutdown, even for brief periods, in freezing conditions, drain the water from all components. Prior to startup in freezing conditions, the operation of all components must be carefully checked to ensure they are not frozen and will operate properly.

Pressure Relief Devices

A waterblast system should include both primary and secondary pressure relief protection.



Properly adjusted and maintained pressure relief devices are imperative for the protection of both the operator and the equipment against dangerous over pressurization.

- For primary protection a spring load relief valve is set at 1.25 times the maximum operation pressure. A relief valve is set at 12,500 psi (862 bar) if the maximum operating pressure is 10,000 psi (689 bar).
- For secondary protection a rupture disc assembly containing a manufacturer's approved disc with a burst rating of 1.5 times the maximum operating pressure is recommended.

If a rupture disc assembly is used for primary pressure relief protection, it should contain a manufacturer's approved disc with a burst rating of 1.25 times the maximum operating pressure.



Only use a rupture disc holder that will not permit the use of coins or other objects in place of discs.



Never adjust relief valves to open at more than 15 percent above the maximum working pressure of the pump.

N Never adjust relief valves while the pump is operating under pressure.

- 1. Relief devices should **never** be mounted so the discharge could strike personnel.
- 2. Never install a shut-off valve between the pump and the relief device.
- 3. Set pressure must be prominently displayed on all relief devices. Never install a relief device unless its set pressure is known.
- 4. The operation of relief valves and the accuracy of the set pressure should be field checked in accordance with manufacturer's instructions at regular intervals, **at least every 40 operating hours.**
- 5. Do not attempt to correct a leaking relief valve by increasing spring tension. This will increase the set pressure.
- 6. Do not use a pressure relief valve as a combination relief and throttling device.
- 7. Keep relief valves dry during freezing conditions.

High Pressure Hose and Lance Assemblies

The minimum burst rating for high pressure hoses must be a minimum of 2.5 times the operating pressure. For example, when operating at 10,000 psi (689 bar), the hose must have a minimum burst rating of 25,000 psi (1,724 bar). **Do not** use a high-pressure hose with an unknown burst rating or manufacturer's operating pressure rating.

- Use of a safety shroud where the hose connects to the control gun is strongly recommended.
- Position the wrench on the wrench flats when making threaded connections. **Do not** position wrench on the fitting ferrule (collar).
- Protect the hose from contact with sharp objects, abrasive surfaces and foot or wheel traffic.
- Support hoses, pipes and fittings to prevent excessive sway and/or wear created by vibration or stress on the end connections.
- Inspect hoses for damage, wear or imperfections prior to and periodically during operation.
- Disconnect, drain, coil and store hoses properly after use.



Never attempt to repair or re-couple hoses in the field. High pressure hose fittings are permanently crimped and can only be properly installed with hydraulic crimping equipment.

Hoses must be removed from service if the:

• cover is damaged and reinforcing wires are exposed to rust and corrosion.

- cover is loose, has blisters or bulges. •
- hose has been crushed or kinked.
- end fittings show evidence of damage, slippage, or leakage.
- hose has been exposed to pressures greater than 50% of burst rating.
- hose is three or more years old, regardless of condition.

Control Gun and Control Device Safety

- 1. Prior to use, thoroughly inspect the control gun or device for smooth and proper operation. Control guns and devices should also be inspected for proper operation before each operating shift. Do not use any device that has not been inspected before your operating shift.
- 2. A control gun operator using a hand-held gun should position and brace their body for the gun's rearward reaction force before depressing the gun trigger. The rearward reaction force is high and is usually 40 to 50 pounds of force. The operator should maintain firm, solid footing to counter the rearward reaction.



Do not use a hand-held control gun if the nozzle discharge can accidently strike the operator's body. A 48-inch long discharge barrel **DANGER** must be used on hand-held control guns to prevent nozzle discharge from accidently striking the operator's feet, legs or body.

- 3. The use of a safety shroud and a safety whip hose is strongly recommended for operator protection against a possible burst in the high-pressure hose connected to the gun. Use of a hand grip and a shoulder stock with hand-held guns will provide greater comfort and thus increase cleaning production.
- 4. Fall protection should be provided when blasting on scaffolding or sloping surfaces. Do not operate a hand-held control gun while standing on slippery surfaces.
- 5. The control gun operator should always start blasting with a **low system pressure** and **slowly** increase blasting pressure. When operating pressure is reached depress and release the control gun trigger/pedal several times to check the gun's operation before starting cleaning operation.
- 6. A dump-type control gun should **always** open fully and reduce the system pressure to near zero *immediately* when the trigger/pedal is released. If the gun does relieve system pressure immediately or pressure does not fall below to 200 psi (14 bar) when the trigger/pedal is released, do not use the control gun.
- 7. The operator should **never** pass a control gun to another operator without first stopping the pump and water flow to the gun. Failure to do so is dangerous because of possible accidental trigger actuation.
- 8. Do not use a control gun or control device that has malfunctioned, or you suspect malfunctioned without having it repaired and/or thoroughly checked for proper operation by a gualified high-pressure maintenance mechanic or your supervisor.
- 9. Do not use a control gun that does not have a trigger guard.

- 10. Never tie, wedge, or clamp a control gun's trigger in the blast position.
- 11. Hand-operated control guns **should never** be used as foot-operated devices.
- 12. Any hose used for transporting dump water back to the pump should have a large enough diameter and short enough length to keep potentially dangerous back pressure low. Protect the hose from traffic.
- 13. All electric throttle control cords should be rated for wet conditions. All cord connectors and switches should be kept out of water.

Rigid Tube Cleaning Lance Safety

Do not use a rigid lance with a burst rating less than 3.0 times the operating pressure. A rigid lance operating at 10,000 psi (689 bar) must have a minimum burst rating of 30,000 psi (2,068 bar). Do not use a rigid lance with an unknown burst or manufacturers' operating pressure rating.

- 1. Clearance between the lance and tube **must be enough** to permit the unrestricted backflow of water and debris. With tubes containing hard deposits, this clearance should be a **minimum** of 1/8 inch on the diameter, or 1/16 inch per side, of the lance. With tubes containing soft, pliable deposits, this clearance should be greater. Insufficient side clearance may cause lance to blow back toward the operator.
- 2. Where practicable, a safety shield should be installed around the lance to prevent a lance nozzle from inadvertently being withdrawn and possibly causing injury.
- 3. **Ensure the nozzle, lance and adapter thread sizes are compatible** before installing the nozzle and adapter on the lance. Do not use a rigid lance that has damaged or missing threads.
- 4. When a pipe wrench is used to connect the lance, **avoid deep wrench marks** that may weaken the lance or lance connectors.
- 5. A rigid lance over 4 feet long requires two operators for support and safe operation. The **operator at the tube entrance should use a foot control gun** so they can instantly relieve system pressure in case of emergency.
- 6. When using and moving the lance support it in a manner to avoid stress and possible breakage at the inlet end connection.
- 7. Never 'ramrod' the lance into tube blockage.
- 8. Transport and store lances in tubes or racks to avoid bending, corrosion or other damage. Damaged lances (bends, marks, etc.) should be removed from service.

Flexible Tube Cleaning Lance Safety

The following lance accessories are strongly recommended for safer lance operation:

• A lance flex guard helps prevent fitting failure on the inlet end of the lance.

- A lance stinger provides greater control of the nozzle, establishes a safety zone so the operator knows when the nozzle is about to exit the tube and eliminates the possibility of nozzle and lance 'double back' toward the operator in large diameter pipe.
- A safety grip prevents the lance from exiting the tube unexpectedly.

A DANGER Serious injury may occur if a lance with a live nozzle exits the tube.

Do not use a flex lance with a burst rating less than 2.5 times the operating pressure. A rigid lance operating at 10,000 psi (689 bar) must have a minimum burst rating of 25,000 psi (1,724 bar). **Do not** use a flex lance with an unknown burst or manufacturers' operating pressure rating.

- 1. **Do not use a flex lance that is kinked, worn, frayed** or when its ability to hold pressure is questionable.
- 2. **Do not** use a flex lance with damaged or missing threads.
- 3. Clearance between the lance and tube **must be enough** to permit the unrestricted backflow of water and debris. With tubes containing hard deposits this clearance should be a **minimum** of 1/8 inch on the diameter, or 1/16 inch per side, of the lance. With tubes containing soft, pliable deposits this clearance should be greater. **Insufficient side clearance may cause lance to blow** back toward the operator.
- 4. Use only nozzles designed for use with flex lances. For example, a nozzle drilled with enough rearward orifices, so nozzle pulls the lance through the tube.
- 5. Where the length of the nozzle and rigid coupling is less than the inside diameter of the pipe, a length of rigid pipe, not less than the diameter of the pipe being cleaned, should be fitted directly behind the nozzle, or a suitable safety shield should be provided to protect the operator.
- 6. If end fittings do not have wrench flats, use properly adjusted pipe wrenches to connect the nozzle onto the lance and to connect the lance to a pressure source. When installing the nozzle on the lance apply the wrench on the end fitting directly behind the end fitting thread, **not on the fitting ferrule or collar.** Do not clamp the lance hose in a vice when installing the nozzle.
- 7. Avoid rough handling, stretching or straining of the lance.
- 8. Never attempt to 'ramrod' the lance into tube blockage or to repair or re-couple lances.
- 9. After use, drain, coil and restore the lance properly. Ensure safety tags remain intact.

Nozzles

Do not use a nozzle with a burst rating of less than 3.0 times, or a manufacturers' pressure rating of a least, the nozzle's operating pressure.

1. Prior to installation make sure the nozzle has no clogged orifices. Blocked orifices can cause excessive system pressure and failure. If an orifice appears clogged or partially blocked with dirt or debris, immediately remove the nozzle from the control gun or lance and clean.

2. Use Teflon tape when connecting nozzles with male pipe (NPT) threads. Do not let the tape overlap the thread end, tape fragments may enter the water stream and clog the orifices in the nozzle.

Pipe thread connections should be hand-tight plus two (2) full wrench turns. Do not tighten past two (2) turns. All pipe thread connections must have a minimum engagement of four (4) threads.



Use wrench flats when available or a properly adjusted pipe wrench for tightening nozzle. Avoid deep wrench marks that may weaken the nozzle.

- 3. Special nozzles requiring a thread locking pin **must** have the pin installed prior to use or the nozzle may unscrew from the lance while in service, causing the lance to blow back toward the operator.
- 4. With nozzles requiring adjustment, always read applicable instructions.

Personal Protective Equipment

Proper safety apparel should be provided to all operators. It is strongly recommended that instructions be given regarding when and how specific clothing and other types of protective devices shall be worn.



Protective equipment may not prevent injuries to operators and other workers caused by the direct impact of high-pressure waterjets or from debris that may be thrown out by the impact of the jet.

Head Protection

All operators shall be issued suitable head protection which shall be worn at all times while at the worksite. Where possible, head protection should include a full-face shield.

Eye Protection

Eye protection shall be provided to, and worn by, all high-pressure waterjet equipment operators and all visitors to waterjet operations while they are in the working area. Eye protection must provide the protection needed and must fit properly. Eye protection shall meet appropriate ANSI requirements for that type of eye protection. Side shields to glasses and goggles should prevent liquids from getting through.

🛕 DANGER

In some cases, liquids may be in use that can cause eye damage. In those cases, a combination visor and goggles or a full hood with shield should be used.

• Hearing Protection

Waterjets generate considerable noise; both in the air and under water. All operators and all visitors shall be issued and shall wear hearing protection while in the working area. Hearing protectors should be regularly inspected and properly maintained and should comply with federal and/or state OSHA standards.

All personnel, operators and others in the vicinity of waterjet equipment should be taught how to fit and properly use ear protection so that their exposure to noise does not exceed OSHA or other regulatory limits.

Body Protection

Protective clothing should be waterproof and have an outer layer that repels casual rebounding water. Protective clothing should also provide some protection from the impact of rebounding debris from the jet impact point where this may be a hazard to the operator.



Waterjets can penetrate clothing, most protective suits, skin, and cause serious injury.

• Everyone working around a waterjet operation should be provided with, and should wear, sufficient waterproof clothing to provide protection from the type of exposure to water and debris that the work might create. Garments should completely cover the operator, including their arms.

Liquid or chemical resistant suits shall be worn when there is a reasonable chance such equipment can prevent an injury.

• Hand Protection

All operators should be provided with adequate means to protect their arms and hands. This protective equipment shall be worn when there is a reasonable chance it can prevent an injury.

• Foot Protection

All operators and workers in the vicinity of a jetting operation should be supplied with, and shall wear, waterproof boots that have been fitted with steel toe caps. A metatarsal guard should also be worn by jetting gun operators.

Respiratory Protection

A respiratory program shall be implemented where there is a reasonable chance it can prevent an injury.

Maintenance

Overview

In order to keep the equipment in optimum operating condition, routine and preventive maintenance is essential.

Only trained personnel should be authorized to perform maintenance or repairs to the equipment. All manufacturers' repair instructions, including tool, torque, clearance and lubrication recommendations should be followed. **Do not attempt to install or use a part whose dimensions, clearances, function or use are suspect.**

Repaired equipment must be thoroughly and carefully tested before it is returned to service. Do not put any piece of repaired equipment in service if its performance is questionable.



For diesel units: if a pump is to be stored for extended periods it is recommended by Caterpillar that the engine is turned on and allowed to warm up every 2 weeks. This is to prevent crystallization of the def components used to meet Tier 4 emissions standards. Failure to do so increases risk of def related engine codes causing the engine not to run.

Maintenance Precautions

Observe these precautions whenever you maintain the equipment.

- Protect all machined and lapped mating surfaces against nicks, scratches, and burrs.
- Carefully clean and blow out all parts to be reassembled. Do not use paper towels. Do not create airborne dust.
- Do not use any substitutes for the fluids, sealants, and lubricants recommended by Advanced Pressure Systems.
- Lubricate threads for all high-pressure connections with blue lubricant before assembly.
- Lubricate new bearings before installation.

General Precautions

Observe the following general precautions at all times.

Mechanical

- Do not make any unauthorized alterations to the equipment or components.
- Use only high-pressure fittings, hoses, valves, and tubing with a minimum burst rating of 2.5 times the system operating pressure when making alterations or additions to the high-pressure water system.

- Repair any leaks in fittings or connections immediately. Do not over-torque fittings to stop leakage. Refer to the Torque specifications table below.
- Torque all fittings to the manufacturer's specifications.
- Follow the tubing manufacturer's recommendations for high-pressure tubing bending radii.
- When pressurizing any new, rebuilt, or serviced high pressure components, remove all personnel from the immediate area until the system pressure has been applied for three minutes and has been cycled on and off at least three times. Gradually increase pressure [maximum of 1380 bar (20,000 psi) per minute].
- High-pressure water may remain in the system for a prolonged period after closing the highpressure water source. Bleed the system pressure off before servicing any part of the pump.
- Follow the manufacturer's recommendations for servicing the pump and use only original manufacturer replacement parts.
- Visually examine the entire system before placing it in operation. If you detect any fault or malfunction, correct it.

Tools

- Use only approved test equipment. Examine the equipment regularly for correct operation and calibration.
- Use the correct tools for the job. Use of incorrect tools can result in injury to personnel or costly damage to the equipment.
- Remove all tools and rags from around the machine after you service and before you start the pump.
- Use only approved work platforms. Never climb on or around the equipment on makeshift devices.

Protective Clothing

• See Personal Protective Equipment (PPE) for more information.

Torque Specification

If a torque value for a gland nut is not specified, reference this table to determine torque value. Always leave 3–4 threads showing between the end of the high-pressure tubing and gland nut collar.

TUBING O.D.	TORQUE [FT. LB. (Nm)]
1/4"	15 - 25 (20 - 34)
3/8"	47 - 60 (35 - 45)
9/16"	60 - 70 (80 - 100)

Daily Inspection

The following inspection procedures should be performed each day. If problems are detected, they should be remedied before placing the equipment in service.

- Prior to startup, check power end and engine oil levels and inspect oils for dirt or contamination.
 DANGER Do not check the oil while the pump is running.
- Check all system connections to ensure they are tight and leak proof.
- Check suction and discharge supply line valves to ensure they are fully open.
- Review relevant sections of engine and drive train manuals.
- As the machine is started and water pressure increases, listen for unusual sounds.
- Check for plunger packing leakage.
- Check for leakage between the barrels and suction manifold.
- Check the intermediate rod and main bearing oil seals for leakage.
- Review relevant sections of engine and drive train manuals.

Monthly Maintenance

A number of factors can contribute to component failure: poor water quality, operating conditions, or improper maintenance procedures. Maintaining a service log can be a useful method of tracking component life and maintenance trends. Analyzing service intervals will assist in preparing a preventive maintenance schedule tailored to your specific requirements. Periodic maintenance, at regularly scheduled intervals, will minimize unscheduled downtime and premature component failure.

Improper assembly can lead to the premature failure of components. Maintenance procedures must be followed carefully; components must be properly cleaned prior to assembly and tightened to the correct torque specifications.

- Degrease, wash, and clean the system monthly.
- Drain and refill the power end every 500 hours or as often as required to maintain clean, sludge free oil of the proper viscosity.
- Clean the pump and engine air breathers with a non-explosive solvent.
- Check studs, nuts and bolts for tightness and tighten as required.
- Check gaskets for leaks and replace as required.

To avoid unsafe conditions and the risk of equipment damage, operating personnel and service technicians must carefully read and follow the procedures in this manual.

High Pressure Fittings and Connections

The minimum burst rating for high pressure fittings must be a minimum of 2.5 times the system operating pressure.

- All fittings shall be cleaned before installing in the system.
- Never use a damaged or corroded fitting, or one with damaged or missing threads.
- Check the condition of thread connections prior to the makeup of any high-pressure connection. **Do not** use a component with missing or damaged threads on high pressure connections.
- Use Teflon tape on male pipe threads (NPT) for sealing purposes. Do not let the tape overlap the pipe thread end. Tape fragments may enter the system water stream and clog nozzle orifices.
- Properly tighten all high-pressure connections. All pipe connections **must have a minimum engagement of four (4) threads**. Pipe connections should be hand-tight plus two (2) full wrenched turns. **Do not** tighten pipe threads past two wrenched turns.
- Position the wrench on the wrench flat when making threaded connections. Do not position the wrench on the fitting ferrule. If wrench flats are not available, use a properly adjusted pipe wrench to tighten fittings. Deep wrench flats weaken fittings.

Filters and Strainers

Regular checks should be made of all fluid filters to ensure they are not blocked or damaged. Care should be taken when examining, changing, or cleaning filters to ensure that no solid particles escape into the supply lines to the pump and nozzle. Solid particles can damage valves and nozzles and make the pump run poorly. All fluid filters should be checked at regular intervals, especially when the supply water is of a poor quality.

Nozzles, Holders and Lance Connections

The system should be flushed with water before installing the nozzle. Nozzles should be checked to ensure they are not blocked or damaged and that they seat properly in the holder or manifold. The condition of the threads holding the nozzle in place should be checked to ensure they are in good condition and not worn. All damage shall be repaired, or the parts replaced, before jetting begins.

Trigger and Valve Controls

Each hand-operated and foot-operated valve shall be manually checked before a unit is placed in operation to ensure it is clean and properly functioning. Valves should be periodically disassembled to examine the condition of the internal components and to replace worn parts. Valve guards should also be inspected and any defects that might interfere with the proper operation of the unit shall be corrected.

High Pressure Hoses

Hose assemblies must be visually inspected prior to each use and thoroughly tested every six (6) months or sooner, regardless of whether they were in use or not.

A visual inspection should be made at periodic intervals to determine if a hose assembly is suitable for continued service.

The visual inspection must include checking for loose covers, kinks, bulges or soft spots that might indicate broken or displaced reinforcement. Couplings or fittings must be closely examined and, if there is an indication of displacement of the hose from the couplings, the hose must be removed from service.

Hydrostatic Testing

A hydrostatic test should be performed at periodic intervals to determine if a hose assembly is suitable for continued service. Hose assemblies must be hydrostatically tested for one minute for 1.5 times of the recommended working pressure every six (6) months.

Water is the usual test medium. During the hydrostatic test, the hose should be straight, not coiled or in a kinked position. A regular schedule for testing hose assemblies must be established and verified with formal Inspection Records maintained in a permanent and accessible file.

Prior to hydrostatic testing the hose assembly must be depressurized and laid out straight for visual inspection.

- 1. Look for cuts, gouges or worn spots in the hose cover that expose the wire reinforcement. Remove hose with exposed reinforcement from service.
- 2. Look for bulges in the hose cover, or for sections with mashed flats or kinks. Remove hose showing any of these faults from service.
- 3. Inspect for hose cover blisters or loose outer cover. Remove hose showing either of these faults from service.
- 4. Examine the 18-inch length of hose adjacent to the coupling carefully for damage, such as kinks, soft spots, cover cracks or permanent deformation. Remove hose showing any of these faults from service.
- 5. If possible, inspect the inside of the hose assembly for blisters and soft or gummy spots. Remove hose showing any of these internal faults from service.
- 6. Check couplings for damage. Replace all damaged couplings and hydrostatically test the hose assembly before returning it to service.
- 7. Check couplings for worn threads. Replace all damaged couplings and hydrostatically test the hose assembly before returning it to service.
- 8. Inspect couplings for excessive corrosion or rust. Replace all rusted couplings and hydrostatically test the hose assembly before returning it to service.



Only trained personnel, using proper tools and procedures, should conduct the hose assembly pressure tests.



Before conducting pressure tests on hose assemblies, provisions must be made to ensure the safety of personnel performing the tests and to prevent possible damage to property.

- 9. Use only clean water with a maximum temperature of 80° F (27 ° C). Air or other compressible gas must not be used as the test medium.
- 10. Prior to building up water pressure entrapped air should be bled through an outlet valve while the hose is being filled.
- 11. The hose being pressure tested must be restrained by placing it in a series of anchored steel straps close to each end and at approximately 10-foot (3 m) intervals along the length. If failure occurs during the test the anchored straps should not destroy the hose but can prevent a whipping action from causing other damage or injury.
- 12. The outlet end of the hose should be bulwarked so that a blown-out fitting cannot escape.
- 13. Sheet metal or a heavy matting shroud must be placed over the hose end to protect testing personnel from flying objects should a hose and bulwark failure occur during testing.
- 14. Test personnel must never stand in front of or to the rear of the hose ends during testing.

Proper Hose Storage

Hose assemblies in storage can be affected adversely by temperature, humidity, ozone, sunlight, oils, solvents, corrosive liquids and fumes, insects, rodents, and radioactive materials.

The appropriate method for storing hose depends largely on the diameter and length, the quantity to be stored and the way it is packaged. Hose should not be piled or stacked to the extent that the weight of the stack creates distortions on the lengths at the bottom. Hoses with a very thin wall will not support as much load as hoses with a heavier wall or wire reinforcement. Hose shipped in coils or bales should be stored so the coils lie flat on a horizontal plane.

Hose assemblies should be stored in a container. Containers can provide protection against the deteriorating effects of oils, solvents, and corrosive liquids. Containers also give some protection against ozone and sunlight.

Rodents and insects can damage rubber hose products. Protection from them must be considered.

The ideal temperature for storing hose assemblies ranges from 35° to 80° F (2° to 27° C) with a maximum limit of 100° F (38° C). If stored below 32° F (0° C) some hose will become stiff and will required warming before being placed in service. Hose assemblies should not be stored near sources of heat, such as radiators or space heaters.

Replacing Maintenance Items

Replace the Inlet Water Filters

Dirty or incorrect filters can shorten pump life.

<u>TASK</u>

1. Do the Lockout/Tagout procedure.



WARNING! Failure to do the lockout/tagout procedure can result in equipment damage or injury to personnel.

- 2. Remove the inlet line to the high-pressure manifold and then drain the filter canister.
- 3. Open the air bleed valve located on the filter canister lid.
- 4. Open the drain valve located at the bottom of the filter body to drain the filter canister.
- 5. To remove the filter canister lid, unscrew the canister lid clamp T-bolt.
- 6. If the clamp does not disengage from the filter assembly, gently strike the clamp with a mallet to disengage it.
- 7. Remove the filter lid.
- 8. Remove the filters from the canister. Examine them for unusual contamination and then discard them.
- 9. Examine the contents of the canister.

These inspections can provide early warning of a change in inlet water quality. The quality of the inlet water directly affects the life of the filter.

- 10. Flush the canister with fresh water or use a wet-dry vacuum to clean debris from the bottom of the canister.
- 11. Install new filter cartridges.
- 12. Align the filter canister lid to the filter body.
- 13. Apply a thin layer of blue lubricant to the threads and face of the clamp T-bolt, and then tighten the clamp.

You may need to strike the clamp gently with a mallet to seat correctly on the flanges.

- 14. Flush the inlet line to the high-pressure manifold with fresh water to remove any contaminants that may have bypassed the filter housing.
- 15. Connect the inlet line to the high-pressure manifold.
- 16. Gradually open the inlet water valve and carefully examine the manifold and filters for leaks.
- 17. Use the bleeder valve on top of the filter housing to remove air from the system.
- 18. Do a final inspection to remove tools, parts, and rags from the equipment before startup.

Replace the Hydraulic Oil Filters

TOOLS

• 36-mm socket and appropriate ratchet or equivalent wrench

PARTS

- Particulate filter
- Shell Morlina S3 BA 100 oil, adequate amount to fill the pump hydraulic oil reservoir

SUPPLIES

• Silver anti-seize

<u>TASK</u>

1. Do the <u>Lockout/Tagout</u> procedure.



WARNING! Failure to do the lockout/tagout procedure can result in equipment damage or injury to personnel.

- 2. Remove the filter housing by turning the 36 mm nut located at the bottom of the housing.
- 3. Remove the filter.
- 4. Clean the housing.
- 5. Install a new filter.
- 6. Apply silver anti-seize to the housing threads.
- 7. Reinstall the filter housing.
- 8. Run the pump. While the pump is running, monitor the level of oil in the pump hydraulic oil reservoir. Add oil to the reservoir until the oil level is between the low and high marks of the site gauge.

Power End Assembly

Overview

This section describes the instructions for repairing the Series 300 power frame. It must be read carefully and understood before performing any repair operations on the power frame. Proper use and adequate maintenance are fundamental for the power frame's functionality and longevity. Advanced Pressure Systems declines any responsibility for damage caused by the misuse, or the disregard of the instructions described in this section.

Improper assembly can lead to the premature failure of components. Maintenance procedures must be followed carefully; components must be properly cleaned prior to assembly and tightened to the correct torque specifications.

Power End Disassembly

A DANGER

Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance.

\Lambda DANGER

Ensure all pressure is relieved or blocked from the hydraulic and high-pressure circuits before performing maintenance.

Intermediate Rod and Oil Wiper Seal Removal

1. Use the packing nut wrench to loosen the plunger collet nut from the intermediate rod. Use a punch or screwdriver to remove the plunger collet. Insert the punch or screwdriver through the access hole in the rod and pry against the collet. If necessary, turn the pump crankshaft by hand to retract the rod and remove the collet and the collet nut.



Figure 1: Intermediate Rod Removal

2. Remove the cap screws attaching the wiper seal holder to the power frame. Leave the holder, gasket, and seals as an assembly with the intermediate rod.



Figure 2: Wiper Seal Removal

- 3. Push the plunger forward into the packing retainer.
- 4. Insert a rod into one of the holes in the end of the intermediate rod and strike with a hammer to loosen. Unscrew the rod from the crosshead and remove the wiper seal holder and the rod as an assembly.
- 5. Repeat this procedure for the remaining two intermediate rods.

A CAUTION Take care not to score the area where the oil wiper seal rides.

Crankshaft Removal

- 1. Drain the oil following the procedure, Power End Lubrication, and remove the rear inspection cover.
- 2. Cut the safety wires on the connecting rod bolts.
- 3. Guide tubes are used around the connecting rod bolts to align the connecting rod caps with the connecting rods. To remove the rod caps, loosen the rod bolts approximately 3/4-inch from the caps. Alternately, tap the upper and lower bolts until the guide tubes break free from the rods. Note the position of each of the metal stamped rod caps and remove the caps.
- 4. Push the three connecting rod assemblies fully forward, away from the crankshaft.

A CAUTION Ensure the oil seal is protected during removal.


Figure 3: Connecting Rod Cap Removal

- 5. Remove the cap screws from the bearing retainers on both ends of the crankshaft. Pry the retainers loose with the o-ring, oil seal and shims intact. Do not remove the main roller bearings from the crankshaft. Tie the shims to their respective retainers and mark for reassembly in the original location.
- 6. Support the crankshaft during removal by placing a piece of wood inside the power frame under the crankshaft. Pull the crankshaft out of the power frame while supporting the outer race on the bearings as they are removed with the crankshaft.



Figure 4: Crankshaft Removal

7. Inspect the tapered roller bearings while on the crankshaft. The bearings should not be removed unless worn or damaged.

Connecting Rod Removal

- 1. Remove the connecting rod/crosshead assembly from the power end.
- 2. Lightly heat the setscrews in the wrist pins to soften the Loctite and remove the screws.
- 3. Use a hydraulic press or a brass rod and hammer to press the wrist pins out of the crossheads.
- 4. Slide the connecting rod assemblies out of the crossheads.



Figure 4: Crankshaft Removal

Power End Installation

In addition to component installation, the following procedures include instructions for replacing wear components.

Main Roller Bearing Replacement

If replacement is required, remove the main roller bearings from the crankshaft and proceed with Step 1 below.

- 1. Thoroughly clean and remove all burrs from the ID of the new roller bearing assemblies and from the bearing surfaces on the crankshaft.
- 2. Heat the new bearing assemblies in a controlled temperature oil bath to 280° F (138 °C)



Avoid overheating the bearing assemblies. Do not use a torch to heat the bearings.

3. When the bearings have reached the specified temperature, firmly support the crankshaft and install the bearing assemblies on the crankshaft. Press fit the bearing assemblies firmly against the shoulders on the crankshaft with the high side of the tapered roller toward the crankshaft journal.





Connecting Rod & Crosshead Assembly Installation

- 1. Remove all burrs and nicks from the connecting rod, crosshead and wrist pin bearing assembly.
- 2. Remove all burrs and nicks from the connecting rod, crosshead and wrist pin bearing assembly. After installation, test the fit with a wrist pin. There should be no binding. Allowable clearance between the pin and the bearing is 0.001-0.007" (0.025-0.178 mm).



Figure 6: Connecting Rod and Crosshead Assembly

3. Chill the wrist pin. Insert the connecting rod into the crosshead. Press the wrist pin into the crosshead bore, through the wrist pin bearing. Interference between the pin and the crosshead is 0.0015-0.0030" (0.038- 0.073 mm).



To ease assembly, the crosshead may be preheated in an oil bath to no more than 280° F (138 °C).

- 4. Apply a light coat of Loctite 262 to the setscrew and firmly tighten against the wrist pin.
- 5. Remove the match marked rod cap from the connecting rod and set aside.
- 6. Slide the connecting rod/crosshead assembly into the crosshead bore of the power frame. **Be** sure to install the connecting rod with the oil holes facing up. Note the position of each

connecting rod as indicated by the two-digit number stamped on the end of the rod. The crosshead is a sliding fit in the bore with an allowable clearance of 0.010-0.015" (0.254-0.384 mm).

7. Repeat this procedure for the remaining two assemblies.



The connecting rod and crosshead assemblies must be installed and pushed forward into the crosshead bores in the power frame prior to installing the crankshaft.

Crankshaft Installation

- 1. Verify the main roller bearing bores in the pump frame are clean and free from burrs.
- 2. Place a piece of wood, approximately 2 inches thick, in the bottom of the power frame to support the crankshaft during installation.



Figure 6: Crankshaft Installation

- 3. With the roller bearing assemblies in position on the crankshaft, slide the crankshaft through either of the power end bearing bores.
- 4. The bearing outer races are a slip fit in the power frame with an allowable clearance of 0.001-0.003" (0.025-0.076 mm). Use a brass hammer to tap the races into the power frame until the bearing retainer cap screws will draw them in the rest of the way.
- 5. Install the shims, o-rings and bearing retainers in their original locations.
- 6. Rotate the crankshaft occasionally to be sure it is not binding. If the crankshaft begins to lock up, add shims under one of the bearing retainers as needed.
- Adjust the roller bearings by removing shims until there is a slight drag when the crankshaft is rotated manually. Then add shims to remove the drag or preload, approximately 0.001-0.003" (0.025-0.076 mm).



Divide the total thickness of shims as equally as possible between the two bearing retainers to center the crankshaft in the power frame. 8. Torque the cap screws in the bearing retainer to 120 ft-lbs. (163 Nm) and perform the final test of the crankshaft. The bearings are correctly adjusted when there is no noticeable play on the end of the crankshaft and the crankshaft rotates freely.

A CAUTION Do not preload the main roller bearings.

9. Replace the oil seal on the drive side, bearing retainer. Cover sharp edges on the keyway in the crankshaft extension to protect the seal from damage during installation. Press the new seal into the retainer so the lip faces the bearing. The outer lip excludes dirt and moisture.

Crankshaft Journal Bearing Replacement

The two-piece journal bearings on the crankshaft are tri-metal steel shells, non-adjustable and easily replaced when worn. The bearings must be inspected periodically and replaced as required.

- 1. Thoroughly clean the crankshaft journals and the bearing surface on the connecting rod and its mating cap. Lightly oil the crankshaft journal.
- 2. Snap the half of a bearing set into the connecting rod, ensuring the tang on the end of the bearing fits into the small groove in the rod. Snap the other half of the bearing into the rod cap.



Figure 7: Crankshaft Journal Bearing Installation

- 3. Verify the oil hole in the connecting rod is facing up. Pull the connecting rod up to the crankshaft and place the rod cap in position on the crankshaft journal.
- 4. Thread the connecting rod bolts into the connecting rod and evenly torque the bolts to 120 ftlbs. (163 Nm). Do not lubricate the rod bolt threads.
- 5. Manually rotate the crankshaft once to check for binding.
- 6. Using the drilled holes in the head of the rod bolts, crosswire the two bolts to each other to prevent the bolts from loosening.
- 7. Repeat this procedure for the remaining two connecting rods.
- 8. Replace the oil in the power end following the procedure, Power End Lubrication.

Crankshaft Wiper Seal Replacement

1. Clean the groove ID of the seal holder. Install the oil seals in the holder with the u-cup seal lips facing the inside and the wiper seal facing the outside as shown below.



Figure 8: Intermediate Rod Installation

- 2. Apply an oil resistant sealant to one side of the gasket to hold it in position and install the gasket onto the power frame.
- 3. Push the seal holder onto the intermediate rod from the rear and hand-tighten the intermediate rod into the crosshead.
- 4. Tighten the intermediate rod into the crosshead by inserting a steel bar into the access holes in the intermediate rod and strike the bar with a hammer.
- 5. Push the seal holder into the power frame with the TOP marking facing up. Tighten the cap screws to secure it to the frame.
- 6. Repeat this procedure for the remaining two intermediate rods.

Power End Lubrication

The use of quality lubricating oils, combined with appropriate condensed water drain and oil filter change intervals, are critical factors in maintaining performance and durability. Change the power end oil every 500 hours or six (6) months, or as frequently as operating conditions require to maintain clean, sludge and moisture free oil or proper viscosity.

See section 'Specifications', for recommended types of power end lubricating oils.

Types of Lubrication

The power frame of the S300 utilizes two methods for lubricating the journal bearings. These include splash lubrication and force lubrication. The utilization of the force lubrication method allows for a higher load on the connecting rods, thus a higher horsepower rating.

When utilizing the splash lubrication method, the oil hole in the connecting rod cap is left open. The rotation of the crankshaft allows oil to 'splash' into this orifice and is drawn to the journal bearing via capillary action.

When utilizing the force lubrication method, the oil hole in the connecting rod cap is plugged. Oil is forced through the drilled crankshaft to lubricate the journal bearings.

Oil Replacement

- 1. Drain the oil from the power end by removing the pipe cap shown below.
- 2. Replace the oil by removing the air filter and filling the power end from this location.
- 3. Fill oil until the level reaches the center of the sight gauge.



LP Fluid End Assembly

Maintenance Overview

The following table provides a listing of low-pressure fluid end assemblies included in this portion of the manual.

LOW PRESSURE FLUID END ASSEMBLIES		
PART NO.	PLUNGER SIZE	DESIGN PRESSURE*
25-510-024	1-1/2" (1.50)	10,000 PSI (689 BAR)
25-510-026	1-5/8" (1.63)	10,000 PSI (689 BAR)
25-510-028	1-3/4" (1.75)	10,000 PSI (689 BAR)
25-510-030	1-7/8" (1.88)	10,000 PSI (689 BAR)

*Fluid end designed for stated pressure, rod load not to exceed 15,700 lbs for splash lubricated, 17,500 lbs for forced systems.

Never perform any type of maintenance on the fluid end assembly while it is pressurized. Always turn the power off and bleed the high-pressure water before servicing.

Improper assembly can lead to the premature failure of components. Maintenance procedures must be followed carefully; components must be properly cleaned prior to assembly and tightened to the correct torque specifications.



Figure 1: Fluid End Assembly

NOTICE Refer to fluid end drawing for a complete listing of replacement parts and part numbers.

Specialized Maintenance Tools

Most of the tools required to maintain and adjust the Series 300 pump can be found in an ordinary set of mechanics hand tools.

APS has designed specialized tool kits to facilitate the removal and installation of some system components. These tool kits are supplied with each pump and are in the table below.

TOOL KIT	25-500-021
PACKING NUT WRENCH	25-500-022
VALVE SEAT PULLER	61115311
PACKING CARTRIDGE REMOVAL TOOL	61121208

Torque Specification

<u>Suction Manifold:</u>



- 1. Apply silver grade anti-seize to threads and torque to 500 ft. lbs. in increments of 100 ft. lbs.
- 2. Tighten bolts in order indicated by numbers.
- Discharge Manifold:



- 1. Apply silver grade anti-seize to threads and torque to 350 ft. lbs. in increments of 100 ft. lbs.
- 2. Tighten bolts in order indicated by numbers.
- Plunger Collet Nut
 - 1. Apply silver grade anti-seize to threads and torque to 60 ft. lbs.

Valve Assemblies

The fluid end valves are spring loaded, flat disc and seat type. Both the discharge and suction valves and seat can be removed from the front of the fluid end.

Valves and seating surfaces encounter high wear during operation. Frequent inspection, maintenance and/or replacement are required to ensure proper operation. Poor suction and water quality can reduce valve life and result in rapid mechanical wear of the power end components.

- Valve springs should be replaced after 2,000 hours of operation to reduce the possibility of a fatigue break; or when the coils have flat wear spots due to rubbing during normal operation.
- The valve seat provides a seating surface for both the discharge and suction valve. Valve seat surfaces are flat and can be restored by surface grinding to a 4 to 16 RMS surface finish.
- Mating surfaces of the valve seat and the valves must be smooth and free from nicks and scratches.



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

- 1. Disconnect all piping to the discharge manifold.
- 2. Remove the cap screws and washers attaching the discharge manifold to the suction manifold. Lift and remove the discharge manifold, separating it from the discharge spacers.



Figure 2: Valve Removal

- 3. Remove the discharge valve guide, discharge valve and valve spring from the spacer.
- 4. Use the valve seat puller to remove the discharge spacer and valve seat as one piece. Inspect the o-ring and two compression seals installed on the spacer. Do not remove the components unless they are damaged and require replacement.

- 5. Remove the suction valve, valve spring and spring spacer from the barrel by pulling the components out through the bore in the suction manifold.
- 6. Assemble a new suction valve, suction valve spring and spring spacer as one assembly and install in the barrel, spacer first.
- 7. Inspect the valve seat for damage and replace or rework if necessary. Install the valve seat in the barrel ensuring the suction side is installed first. The suction side includes a center hole with several smaller holes around the flat surface of the seat.
- 8. Apply a light coat of Loctite 76764 anti-seize or equivalent to the suction manifold bore and press the discharge spacer into the manifold until it contacts the valve seat. Tap into position with a rubber mallet.
- 9. Assembly a new discharge valve guide, discharge valve spring and discharge valve as one assembly and insert in the discharge spacer, valve first.
- 10. Lift the discharge manifold into position, ensuring the shoulders on the discharge spacers slip into the counter-bores in the manifold.
- 11. Apply Loctite 76764 anti-seize or equivalent to the threads on the cap screws and install the washers and screws. Torque the screws to the specifications above, Torque Specifications.

Packing Assemblies

Depending on plunger size, high pressure units utilize either a packing cartridge or a chevron style packing. Replacement procedures differ for each style and are detailed below.

A DANGER

Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

Chevron Packing

- Use the packing nut wrench to loosen the plunger collet nut from the intermediate rod. Insert the collet removal tool through the access hole in the collet nut and pry against the collet to loosen. If necessary, turn the pump crankshaft by hand to retract the rod and remove the collet and the collet nut.
- 2. Break loose but do not unscrew the intermediate rod.
- 3. Push the plunger forward through the packing retainer.
- 4. Remove the cap screws attaching the oil wiper seal holder to the power frame. Slide the holder forward, leaving it on the intermediate rod.
- 5. Use the access holes in the intermediate rod to unscrew the rod from the crosshead and remove the rod and wiper seal holder as an assembly.



Figure 3: Packing Removal

A CAUTION Take care not to score the area where the oil wiper seal rides.

- 6. Remove the plunger from the packing retainer by pulling it straight back, into the opening in the power frame.
- 7. Use the packing nut wrench or a large pipe wrench to unscrew the packing retainer from the barrel.
- 8. Remove the packing seat and packing from the barrel.
- 9. With the plunger removed from the barrel, slide the new front and rear packing onto the plunger. Position the packing in the middle of the plunger and slide the packing seat onto the plunger behind the rear packing.
- 10. Position the plunger in the barrel and center the packing in the beveled guide at the barrel entrance.
- 11. Rotate the crankshaft until the crosshead is moved to the rear of the power frame. Screw the intermediate rod with the oil wiper seal holder into the crosshead and hand-tighten. Insert a lever into the access holes in the rod and strike the rod with a hammer to tighten. Push the oil wiper seal holder into the power frame and tighten the screws to secure it to the power frame.



- 12. Inspect the o-ring on the packing retainer and replace if necessary. Thoroughly coat the threads on the packing retainer and on the barrel with Loctite 76764 anti-seize or equivalent and position the retainer on the plunger. Use the packing nut wrench to screw the packing retainer into the barrel. Continue turning until the retainer and packing seat make metal-to-metal contact against the barrel. Maintain pressure on the packing nut wrench and strike the wrench once with a hammer to complete.
- 13. Place the collet nut and collet on the plunger. Rotate the crankshaft by hand until the intermediate rod contacts the plunger. Slide the collet and collet nut up to the rod. Tighten and torque to the specifications in the section above, Torque Specifications. If the plunger is too far forward to contact the intermediate rod, tighten the collet nut and rotate the pump by hand to withdraw the plunger. Then loosen the collet nut and advance the rod one more time before final tightening.



The intermediate rod must contact the plunger before tightening. Failure to do so can result in damage to the plunger as the pump reaches full operating pressure.

14. When all three plungers are installed, turn the crankshaft one complete revolution by hand to ensure nothing interferes with the plunger's movement.

Low Pressure Seal Assemblies



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

1. Use the packing nut wrench to loosen the plunger collet nut from the intermediate rod. Use a punch or screwdriver to remove the plunger collet. Insert the punch or screwdriver through the access hole in the rod and pry against the collet to loosen. If necessary, turn the pump crankshaft by hand to retract the rod and remove the collet and the collet nut.



- 2. Rotate the crankshaft to fully retract the intermediate rod.
- 3. Use the packing nut wrench to unscrew the packing retainer.
- 4. Remove the retaining ring and then remove the low-pressure seal holder from the packing retainer.
- 5. Remove the low-pressure seal and the o-ring from the holder.

NOTICE Some plunger sizes do not utilize an o-ring on the low-pressure seal holder.

6. Install a new low-pressure seal in the seal holder and install a new o-ring on the holder, if applicable. Ensure the correct orientation of the seal as illustrated below.



- 7. Apply a small amount of FML-2 grease to the o-ring and insert the seal holder into the packing retainer. Secure the holder in position with the retaining ring.
- 8. Apply Loctite 76764 anti-seize or equivalent to the threads on the packing retainer and install the retainer on the plunger. Use the packing nut wrench to tighten the retainer into the barrel.
- 9. Place the collet nut and collet on the plunger. Rotate the crankshaft by hand until the intermediate rod contacts the plunger. Slide the collet and collet nut up to the rod. Tighten and torque to the specifications in the above section, Torque Specifications. If the plunger is too far forward to contact the intermediate rod, tighten the collet nut, and rotate the pump by hand to withdraw the plunger. Then loosen the collet nut and advance the rod one more time before final tightening.



The intermediate rod must contact the plunger before tightening. Failure to do so can result in damage to the plunger as the pump reaches full operating pressure.

10. When all three plungers are installed, turn the crankshaft one complete revolution by hand to ensure nothing interferes with the plunger's movement.

Barrel Assemblies

Before the barrels can be removed for service, the valve and packing assemblies must be removed. Follow the procedures detailed above for removing these assemblies and then proceed with Step 1 below.



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

1. Remove the cap screws attaching the suction manifold to the power frame. Remove the suction manifold to expose the o-rings and compression seals in the barrels. Remove the o-rings and the seals.



2. Use a brass hammer to tap out the barrels. If removal by tapping is not possible, a hand operated hydraulic jack is recommended.



If using a hydraulic jack, reinforce the face of the power frame with a $6" \times 14" \times 1/2"$ steel plate.

3. Remove any nicks or burrs from all mating surfaces on the power frame and the barrels.

4. Insert the barrels into the power frame, aligning the cooling water ports as shown below. The barrel should be positioned in the power frame with the cooling water port aligned with the relief in the power frame to permit the attachment of the cooling lines.



A CAUTION Place a block of wood over the end of the barrel to prevent damage while tapping it into position.

- 5. Insert the o-ring and the compression seal into the appropriate grooves on the face of the barrel. Apply a light coat of FML-2 grease to the o-ring to hold it in position.
- 6. Install the suction manifold by carefully positioning the counter-bores on the manifold over each of the barrel pilots.
- 7. Apply Loctite 76764 anti-seize or equivalent to the threads on the cap screws and install the screws to secure the manifold to the power frame. Verify that none of the o-rings have shifted during the installation of the manifold. Cross torque the screws to the specifications in the above section, Torque Specifications.

HP Fluid End Assembly

Maintenance Overview

The following table provides a listing of low-pressure fluid end assemblies included in this portion of the manual.

HIGH PRESSURE FLUID END ASSEMBLIES			
PART NO.	PLUNGER SIZE	DESIGN PRESSURE*	
25-520-012	3/4" (0.75)	20,000 PSI (1,379 BAR)	
25-520-014	7/8" (0.88)	20,000 PSI (1,379 BAR)	
25-520-016	1" (1.00)	20,000 PSI (1,379 BAR)	
25-520-018	1-1/8″ (1.13)	20,000 PSI (1,379 BAR)	
25-520-020	1-1/4" (1.25)	20,000 PSI (1,379 BAR)	
25-520-022	1-3/8" (1.38)	20,000 PSI (1,379 BAR)	

*Fluid end designed for stated pressure, rod load not to exceed 15,700 lbs for splash lubricated, 17,500 lbs for forced systems.

Never perform any type of maintenance on the fluid end assembly while it is pressurized. Always turn the power off and bleed the high-pressure water before servicing.

Improper assembly can lead to the premature failure of components. Maintenance procedures must be followed carefully; components must be properly cleaned prior to assembly and tightened to the correct torque specifications.



Figure 1: Fluid End Assembly

NOTICE Refer to fluid end drawing for a complete listing of replacement parts and part numbers.

Specialized Maintenance Tools

Most of the tools required to maintain and adjust the Series 300 pump can be found in an ordinary set of mechanics hand tools.

APS has designed specialized tool kits to facilitate the removal and installation of some system components. These tool kits are supplied with each pump and are in the table below.

TOOL KIT	61109016
PACKING NUT WRENCH	61122702
VALVE SEAT PULLER	61115311
PACKING CARTRIDGE REMOVAL TOOL	61121208

Torque Specification

Suction Manifold:



- 3. Apply silver grade anti-seize to threads and torque to 500 ft. lbs. in increments of 100 ft. lbs.
- 4. Tighten bolts in order indicated by numbers.
- Discharge Manifold:



- 3. Apply silver grade anti-seize to threads and torque to 300 ft. lbs. in increments of 100 ft. lbs.
- 4. Tighten bolts in order indicated by numbers.
- Plunger Collet Nut
 - 2. Apply silver grade anti-seize to threads and torque to 60 ft. lbs.

Valve Assemblies

The fluid end valves are spring loaded, flat disc and seat type. Both the discharge and suction valves and seat can be removed from the front of the fluid end.

Valves and seating surfaces encounter high wear during operation. Frequent inspection, maintenance and/or replacement are required to ensure proper operation. Poor suction and water quality can reduce valve life and result in rapid mechanical wear of the power end components.

- Valve springs should be replaced after 2,000 hours of operation to reduce the possibility of a fatigue break; or when the coils have flat wear spots due to rubbing during normal operation.
- The valve seat provides a seating surface for both the discharge and suction valve. Valve seat surfaces are flat and can be restored by surface grinding to a 4 to 16 RMS surface finish.
- Mating surfaces of the valve seat and the valves must be smooth and free from nicks and scratches.



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

- 1. Disconnect all piping to the discharge manifold.
- 2. Remove the cap screws and washers attaching the discharge manifold to the suction manifold. Lift and remove the discharge manifold, separating it from the discharge spacers.



Figure 2: Valve Removal

- 3. Remove the discharge valve guide, discharge valve and valve spring from the spacer.
- 4. Use the valve seat puller to remove the discharge spacer and valve seat as one piece. Inspect the o-ring and two compression seals installed on the spacer. Do not remove the components unless they are damaged and require replacement.

- 5. Remove the suction valve, valve spring and spring spacer from the barrel by pulling the components out through the bore in the suction manifold.
- 6. Assemble a new suction valve, suction valve spring and spring spacer as one assembly and install in the barrel, spacer first.
- 7. Inspect the valve seat for damage and replace or rework if necessary. Install the valve seat in the barrel ensuring the suction side is installed first. The suction side includes a center hole with several smaller holes around the flat surface of the seat.
- 8. Apply a light coat of Loctite 76764 anti-seize or equivalent to the suction manifold bore and press the discharge spacer into the manifold until it contacts the valve seat. Tap into position with a rubber mallet.
- 9. Assembly a new discharge valve guide, discharge valve spring and discharge valve as one assembly and insert in the discharge spacer, valve first.
- 10. Lift the discharge manifold into position, ensuring the shoulders on the discharge spacers slip into the counter-bores in the manifold.
- 11. Apply Loctite 76764 anti-seize or equivalent to the threads on the cap screws and install the washers and screws. Torque the screws to the specifications above, Torque Specifications.

Packing Assemblies

Depending on plunger size, high pressure units utilize either a packing cartridge or a chevron style packing. Replacement procedures differ for each style and are detailed below.



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

Packing Cartridge

1. Use the packing nut wrench to loosen the plunger collet nut from the intermediate rod. Use a punch or screwdriver to remove the plunger collet. Insert the collet removal tool through the access hole in the rod and pry against the collet to loosen. If necessary, turn the pump crankshaft by hand to retract the rod and remove the collet and the collet nut.



- 2. Rotate the crankshaft to fully retract the intermediate rod. Use the packing nut wrench or large pipe wrench to unscrew the packing retainer from the barrel.
- 3. Thread the packing cartridge removal tool into the packing assembly cartridge until the tool bottoms out against the barrel. Continue turning the tool until the outer seals on the cartridge break free from the barrel, and the cartridge is loose.



- 4. Remove the packing removal tool and use the plunger to work the spring spacer out of the barrel. Remove the plunger, packing assembly and spacer as an assembly.
- 5. Insert the plunger through the new packing assembly from the small end of the packing cartridge. Position the packing in the middle of the plunger and install the spring spacer in front of the plunger.
- 6. Apply a light coat of Loctite 76764 anti-seize or equivalent to the outer seals on the packing cartridge
- 7. Install the plunger with the packing assembly and spring spacer into the barrel. Push the packing assembly forward until the outer seals contact the barrel.
- 8. Inspect the o-ring on the packing retainer and replace if necessary. Thoroughly coat the threads on the packing retainer and on the barrel with Loctite 76764 anti-seize or equivalent and position the retainer on the plunger. Use the packing nut wrench to screw the packing retainer into the barrel. Continue turning until the retainer and packing cartridge make metal-to-metal contact against the barrel. Maintain pressure on the packing nut wrench and strike the wrench once with a hammer to complete.
- 9. Place the collet nut and collet on the plunger. Rotate the crankshaft by hand until the intermediate rod contacts the plunger. Slide the collet and collet nut up to the rod. Tighten and torque to the specifications in the above section, Torque Specifications. If the plunger is too far forward to contact the intermediate rod, tighten the collet nut, and rotate the pump by hand to withdraw the plunger. Then loosen the collet nut and advance the rod one more time before final tightening.
- 10. When all three plungers are installed, turn the crankshaft one complete revolution by hand to ensure nothing interferes with the plunger's movement.



The intermediate rod must contact the plunger before tightening. **A CAUTION** Failure to do so can result in damage to the plunger as the pump reaches full operating pressure.

Low Pressure Seal Assemblies



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

1. Use the packing nut wrench to loosen the plunger collet nut from the intermediate rod. Use a punch or screwdriver to remove the plunger collet. Insert the punch or screwdriver through the access hole in the rod and pry against the collet to loosen. If necessary, turn the pump crankshaft by hand to retract the rod and remove the collet and the collet nut.



- Rotate the crankshaft to fully retract the intermediate rod.
- 3. Use the packing nut wrench to unscrew the packing retainer.
- 4. Remove the retaining ring and then remove the low-pressure seal holder from the packing retainer.
- 5. Remove the low-pressure seal and the o-ring from the holder.

NOTICE Some plunger sizes do not utilize an o-ring on the low-pressure seal holder.

6. Install a new low-pressure seal in the seal holder and install a new o-ring on the holder, if applicable. Ensure the correct orientation of the seal as illustrated below.



- 7. Apply a small amount of FML-2 grease to the o-ring and insert the seal holder into the packing retainer. Secure the holder in position with the retaining ring.
- 8. Apply Loctite 76764 anti-seize or equivalent to the threads on the packing retainer and install the retainer on the plunger. Use the packing nut wrench to tighten the retainer into the barrel.
- 9. Place the collet nut and collet on the plunger. Rotate the crankshaft by hand until the intermediate rod contacts the plunger. Slide the collet and collet nut up to the rod. Tighten and torque to the specifications in the above section, Torque Specifications. If the plunger is too far forward to contact the intermediate rod, tighten the collet nut, and rotate the pump by hand to withdraw the plunger. Then loosen the collet nut and advance the rod one more time before final tightening.



The intermediate rod must contact the plunger before tightening. Failure to do so can result in damage to the plunger as the pump reaches full operating pressure.

10. When all three plungers are installed, turn the crankshaft one complete revolution by hand to ensure nothing interferes with the plunger's movement.

Barrel Assemblies

Before the barrels can be removed for service, the valve and packing assemblies must be removed. Follow the procedures detailed above for removing these assemblies and then proceed with Step 1 below.



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

1. Remove the cap screws attaching the suction manifold to the power frame. Remove the suction manifold to expose the o-rings and compression seals in the barrels. Remove the o-rings and the seals.



2. Use a brass hammer to tap out the barrels. If removal by tapping is not possible, a hand operated hydraulic jack is recommended.

DTICE If using a hydraulic jack, reinforce the face of the power frame with a $6" \times 14" \times 1/2"$ steel plate.

- 3. Remove any nicks or burrs from all mating surfaces on the power frame and the barrels.
- 4. Insert the barrels into the power frame, aligning the cooling water ports as shown below. The barrel should be positioned in the power frame with the cooling water port aligned with the relief in the power frame to permit the attachment of the cooling lines.



- 5. Insert the o-ring and the compression seal into the appropriate grooves on the face of the barrel. Apply a light coat of FML-2 grease to the o-ring to hold it in position.
- 6. Install the suction manifold by carefully positioning the counter-bores on the manifold over each of the barrel pilots.
- 7. Apply Loctite 76764 anti-seize or equivalent to the threads on the cap screws and install the screws to secure the manifold to the power frame. Verify that none of the o-rings have shifted during the installation of the manifold. Cross torque the screws to the specifications in the above section, Torque Specifications.

UHP Fluid End Assembly

Maintenance Overview

The following table provides a listing of low-pressure fluid end assemblies included in this portion of the manual.

ULTRA-HIGH PRESSURE FLUID END ASSEMBLIES			
PART NO.	PLUNGER SIZE	DESIGN PRESSURE*	
25-540-008	1/2" (0.50)	40,000 PSI (2,758 BAR)	
25-540-010	5/8" (0.63)	40,000 PSI (2,758 BAR)	
25-540-011	11/16" (0.69)	40,000 PSI (2,758 BAR)	

*Fluid end designed for stated pressure, rod load not to exceed 15,700 lbs for splash lubricated, 17,500 lbs for forced systems.

Never perform any type of maintenance on the fluid end assembly while it is pressurized. Always turn the power off and bleed the high-pressure water before servicing.

Improper assembly can lead to the premature failure of components. Maintenance procedures must be followed carefully; components must be properly cleaned prior to assembly and tightened to the correct torque specifications.



Figure 1: Fluid End Assembly

NOTICE Refer to fluid end drawing for a complete listing of replacement parts and part numbers.

Specialized Maintenance Tools

Most of the tools required to maintain and adjust the Series 300 pump can be found in an ordinary set of mechanics hand tools.

APS has designed specialized tool kits to facilitate the removal and installation of some system components. These tool kits are supplied with each pump and are in the table below.

TOOL KIT	61109042
PACKING NUT WRENCH	61122702
PACKING CARTRIDGE REMOVAL TOOL	61121240

Torque Specification

Suction Manifold:



- 1. Apply silver grade anti-seize to threads and torque to 300 ft. lbs. in increments of 100 ft. lbs.
- 2. Tighten bolts in order indicated by numbers.
- Discharge Manifold:



- 1. Apply silver grade anti-seize to threads and torque to 300 ft. lbs. in increments of 100 ft. lbs.
- 2. Tighten bolts in order indicated by numbers.
- Plunger Collet Nut
 - 1. Apply silver grade anti-seize to threads and torque to 60 ft. lbs.

Valve Assemblies

The fluid end valves are spring loaded, flat disc and seat type. Both the discharge and suction valves and seat can be removed from the front of the fluid end.

Valves and seating surfaces encounter high wear during operation. Frequent inspection, maintenance and/or replacement are required to ensure proper operation. Poor suction and water quality can reduce valve life and result in rapid mechanical wear of the power end components.

- Valve springs should be replaced after 2,000 hours of operation to reduce the possibility of a fatigue break; or when the coils have flat wear spots due to rubbing during normal operation.
- The valve seat provides a seating surface for both the discharge and suction valve. Valve seat surfaces are flat and can be restored by surface grinding to a 4 to 16 RMS surface finish.
- Mating surfaces of the valve seat and the valves must be smooth and free from nicks and scratches.



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance.



Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

- 1. Disconnect all piping to the discharge manifold.
- 2. Remove the cap screws and washers attaching the discharge manifold to the suction manifold. Lift and remove the discharge manifold, separating it from the discharge spacers.



Figure 2: Valve Removal

- 3. Remove the discharge valve guide, discharge valve and valve spring from the spacer.
- 4. Remove the discharge spacer by prying on the outside groove on the spacer. Inspect the o-ring and two compression seals installed on the spacer. Do not remove the components unless they are damaged and require replacement.

- 5. Remove the valve seat by inserting a small rod into the center bore and gently prying side to side.
- 6. Remove the suction valve, valve spring and spring spacer from the barrel by pulling the components out through the bore in the suction manifold.
- 7. Assemble a new suction valve, suction valve spring and spring spacer as one assembly and install in the barrel, spacer first.
- 8. Inspect the valve seat for damage and replace or rework if necessary. Install the valve seat in the barrel ensuring the suction side is installed first. The suction side includes a center hole with several smaller holes around the flat surface of the seat.
- 9. Apply a light coat of Loctite 76764 anti-seize or equivalent to the suction manifold bore and press the discharge spacer into the manifold until it contacts the valve seat. Tap into position with a rubber mallet.
- 10. Assembly a new discharge valve guide, discharge valve spring and discharge valve as one assembly and insert in the discharge spacer, valve first.
- 11. Lift the discharge manifold into position, ensuring the shoulders on the discharge spacers slip into the counter-bores in the manifold.
- 12. Apply Loctite 76764 anti-seize or equivalent to the threads on the cap screws and install the washers and screws. Torque the screws to the specifications above, Torque Specifications.

Packing Assemblies

\Lambda DANGER

Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.

🛕 DANGER

Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

Packing Cartridge

- 1. Use the packing nut wrench to loosen the plunger collet nut from the intermediate rod. Use a punch or screwdriver to remove the plunger collet. Insert the collet removal tool through the access hole in the rod and pry against the collet to loosen. If necessary, turn the pump crankshaft by hand to retract the rod and remove the collet and the collet nut.
- 2. Rotate the crankshaft to fully retract the intermediate rod. Use the packing nut wrench or large pipe wrench to unscrew the packing retainer from the barrel.
- 3. Place the collet nut and collet on the plunger. Rotate the crankshaft by hand until the intermediate rod contacts the plunger. Slide the collet and collet nut up to the rod. Tighten and torque to the specifications in the above section, Torque Specifications.



4. Start the engine and let it idle. Using the power take-off (PTO) lever, slip the clutch very slightly and rotate the pump slowly several revolutions. Do not engage the PTO.

After several revolutions the pressure inside the barrel should be sufficient to blow the packing out of the barrel.

- 5. Remove the collet nut, collet, plunger, and old packing assembly.
- 6. Install the new o-ring on the packing. Apply a light coat of FML-2 grease to the o-ring and press the new packing into the barrel, grooved end first.
- 7. Insert the plunger into the packing and slide the packing seat onto the plunger.
- 8. Inspect the o-ring on the packing retainer and replace if necessary. Thoroughly coat the threads on the packing retainer and on the barrel with Loctite 76764 anti-seize or equivalent and position the retainer on the plunger. Use the packing nut wrench to screw the packing retainer into the barrel



Continue turning until the retainer and packing seat make metal-to-metal contact against the barrel. Maintain pressure on the packing nut wrench and strike the wrench once with a hammer to complete.

9. Place the collet nut and collet on the plunger. Rotate the crankshaft by hand until the intermediate rod contacts the plunger. Slide the collet and collet nut up to the rod. Tighten and torque to the specifications in the above section, Torque Specifications.



The intermediate rod must contact the plunger before tightening. **ACAUTION** Failure to do so can result in damage to the plunger as the pump reaches full operating pressure.

10. When all three plungers are installed, turn the crankshaft one complete revolution by hand to ensure nothing interferes with the plunger's movement.

Low Pressure Seal Assemblies

A DANGER



Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.

Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

- 1. Use the packing nut wrench to loosen the plunger collet nut from the intermediate rod. Use a punch or screwdriver to remove the plunger collet. Insert the punch or screwdriver through the access hole in the rod and pry against the collet to loosen. If necessary, turn the pump crankshaft by hand to retract the rod and remove the collet and the collet nut.
- 2. Rotate the crankshaft to fully retract the intermediate rod.
- 3. Use the packing nut wrench to unscrew the packing retainer.
- 4. Remove the retaining ring and then remove the low-pressure seal holder from the packing retainer.



5. Remove the low-pressure seal and the o-ring from the holder.

NOTICE Some plunger sizes do not utilize an o-ring on the low-pressure seal holder.

6. Install a new low-pressure seal in the seal holder and install a new o-ring on the holder, if applicable. Ensure the correct orientation of the seal as illustrated below.



- 7. Apply a small amount of FML-2 grease to the o-ring and insert the seal holder into the packing retainer. Secure the holder in position with the retaining ring.
- 8. Apply Loctite 76764 anti-seize or equivalent to the threads on the packing retainer and install the retainer on the plunger. Use the packing nut wrench to tighten the retainer into the barrel.
- 9. Place the collet nut and collet on the plunger. Rotate the crankshaft by hand until the intermediate rod contacts the plunger. Slide the collet and collet nut up to the rod. Tighten and torque to the specifications in the above section, Torque Specifications.

If the plunger is too far forward to contact the intermediate rod, tighten the collet nut, and rotate the pump by hand to withdraw the plunger. Then loosen the collet nut and advance the rod one more time before final tightening.



The intermediate rod must contact the plunger before tightening. Failure **A CAUTION** to do so can result in damage to the plunger as the pump reaches full operating pressure.

10. When all three plungers are installed, turn the crankshaft one complete revolution by hand to ensure nothing interferes with the plunger's movement.

Barrel Assemblies

Before the barrels can be removed for service, the valve and packing assemblies must be removed. Follow the procedures detailed above for removing these assemblies and then proceed with Step 1 below.



DANGER

Severe injury can result if the machine is not properly locked out. Observe electrical Lockout/Tagout procedures before performing maintenance on the system components.

Ensure all pressure is relieved or blocked from the hydraulic and highpressure circuits before performing maintenance.

1. Remove the cap screws attaching the suction manifold to the power frame. Remove the suction manifold to expose the o-rings and compression seals in the barrels. Remove the o-rings and the seals.



2. Use a brass hammer to tap out the barrels. If removal by tapping is not possible, a hand operated hydraulic jack is recommended.

TICE If using a hydraulic jack, reinforce the face of the power frame with a $6" \times 14" \times 1/2"$ steel plate.

- 3. Remove any nicks or burrs from all mating surfaces on the power frame and the barrels.
- 4. Insert the barrels into the power frame, aligning the cooling water ports as shown below. The barrel should be positioned in the power frame with the cooling water port aligned with the relief in the power frame to permit the attachment of the cooling lines.



- 5. Insert the o-ring and the compression seal into the appropriate grooves on the face of the barrel. Apply a light coat of FML-2 grease to the o-ring to hold it in position.
- 6. Install the suction manifold by carefully positioning the counter-bores on the manifold over each of the barrel pilots.
- 7. Apply Loctite 76764 anti-seize or equivalent to the threads on the cap screws and install the screws to secure the manifold to the power frame. Verify that none of the o-rings have shifted during the installation of the manifold. Cross torque the screws to the specifications in the above section, Torque Specifications.

Motor Starters

Across-the-Line

The across-the-line starter is a common, general use motor starter. This starter connects the incoming power directly to the motor via contactor.

This starter features a thru-door disconnect to de-energize the internal components from the incoming power before opening the enclosure. A push button e-stop immediately cuts power to the motor and shuts down the pump. The start and stop push buttons are used to start and stop the pump under normal operation.

To install the starter, bring each of the three phases into the enclosure utilizing a strain relief device. Attach each phase of incoming power to the circuit breaker utilizing best practices and adhering to local codes. Be sure to check motor rotation. If the motor rotates in the wrong direction, switch two phases of incoming power.



(Image used as reference only, actual item may vary)

Variable Frequency Drive (VFD)

The VFD is a type of motor starter that can safely start and stop the electric motor as well as fully control the speed of the motor during its operation. Since the speed of the motor depends on the supply frequency, the VFD is mostly used for varying the speed of the motor during operation.

When equipped, the remote pendant features a push button e-stop that immediately cuts power to the motor and shuts down the pump. The start and stop push buttons are used to start and stop the pump under normal operation. A speed dial allows for the control of the motor speed remotely. A green light indicates that the starter is active and energized. It is not recommended to maintain a zero speed input for extended periods when the starter is energized.

To install the starter, bring each of the three phases into the enclosure utilizing a strain relief device. Attach each phase of incoming power to the VFD utilizing best practices and adhering to local codes. For wiring details, see the figure below.



(Image used as reference only, actual item may vary)

Soft Start

The soft start is a type of motor starter that reduces the starting current or the high inrush current by reducing the voltage applied to the motor. Since the soft starter only reduces the supply voltage during starting & stopping of the motor, it cannot vary the speed of the motor during normal operation. Therefore, they are used for constant speed application.

This starter features a thru-door disconnect to de-energize the internal components from the incoming power before opening the enclosure. A push button e-stop immediately cuts power to the motor and shuts down the pump. The start and stop push buttons are used to start and stop the pump under normal operation. A display on the front of the enclosure allows for soft start parameters to be modified.

To install the starter, bring each of the three phases into the enclosure utilizing a strain relief device. Attach each phase of incoming power to the circuit breaker utilizing best practices and adhering to local codes. Be sure to check motor rotation. If the motor rotates in the wrong direction, switch two phases of incoming power.



(Image used as reference only, actual item may vary)

Troubleshooting

Overview

The troubleshooting guide will help identify the probable cause of a system malfunction and assist in providing corrective action. In addition to this manual, you may also need the manufacturer's manuals provided with your pump. The following symptoms are discussed in this section:

- High pressure line pulsation
- Knock in power end
- Water hammer
- Valve wear
- Packing failure

Before doing any procedure:

- Look for obvious problems.
- Read and understand each procedure.
- Make sure that you have the appropriate tools available.
- Make sure that you have the appropriate parts available.

Troubleshooting Guide

Listen to the machine and observe it in operation. Learn to recognize the normal sounds and operating conditions of the system. Carefully define the symptom of the problem. Locate the symptom on the troubleshooting guide that most closely corresponds to the problem.

If the symptoms in the guide do not correspond to the malfunction, or if the problem is not resolved by the recommended corrective action, contact the APS Customer Service Department for assistance.

	Malfunction	Indication	Check
1.	High pressure line pulsation	Suction supply line has been affected	Debris or scale back
			Partially closed valve in suction line
			Air entering the suction supply line through a loose connection or a ruptures pipe
			Low supply line water pressure
		High pressure fluid loss	Worn or broken suction or discharge valves
			Loose packing retainer nut
			Damaged or broken plunger
			Damaged suction or discharge valve spring
			Damaged discharge valve guide
			Worn packing assembly and/or packing seat

- Plunger failure
- Oil wiper seal leakage
- Packing seal leakage
- Crankshaft oil seal leak
| | Malfunction | Indication | Check |
|----|------------------------|-----------------------------------------|-----------------------------------------------------------------------------|
| 2. | Knock in power end | Loosely connected components | Tightness of intermediate rod in crosshead |
| | | | Plunger collet is fully compressed |
| | | | Connecting rod wrist pin bearings |
| | | | Crankshaft journal bearing wear |
| | | | Crankshaft main roller bearings and shims |
| | | Fluid end effects | Cavitation in fluid end |
| | | | Damaged suction or discharge valve or seats |
| | | | Damaged suction or discharge valve springs |
| | | | Damaged plunger |
| | | | Worn packing |
| З. | Water hammer/wheezing | Cavitation effects | Low supply line water pressure |
| | | | Stuck suction valve |
| | | Plumbing design defects | Flow separation at elbows and fittings |
| | | | Variable fluid acceleration in the suction supply plumbing |
| 4. | Valve wear | Contaminated supply water | Supply water quality or chemistry |
| | | | Filters are not correctly rated |
| | | Cavitation effects | Worn valve guides |
| | | | Damaged valve springs |
| 5. | Packing failure | Contaminated supply water | Supply water quality or chemistry |
| | | | Filters are not correctly rated |
| | | Cavitation effects | Cavitation due to insufficient or low supply water pressure |
| | | Installation damage | Packing installation |
| | | Lack of cooling | Packing lubrication holes in barrel blocked |
| 6. | Plunger failure | Cavitation effects | Low supply line water pressure |
| | | | Air entering supply water line |
| | | | Air entering the barrel through worn packing |
| | | Mechanical damage | Chipping from physical impact of foreign
material entering the pump well |
| | | Contaminated supply water | Supply water quality or chemistry |
| | | | Filters are not correctly rated |
| | | Contact with the packing seat | Deformation and wear of packing seat |
| 7. | Oil wiper seal leakage | Foreign material entering the pump well | Pump well cover is kept closed |
| | | | Dirt does not settle on the intermediate rod |
| | | Running the pump without oil | Oil level is correctly set |
| | | | Oil quality is correct |
| | | Scored intermediate rod | Oil wiper seal is contacting a smooth surface |
| | | | Oil wiper seal is not nicked from intermediate rod damage |
| 8. | Packing seal leakage | Pump run without water | Supply water pressure |
| | | | Plunger coolant holes in barrels are not blocked |

		Dirt accumulation	Packing damaged from dirt entering the pump well		
		Installation	Packing installed backward		
9.	Crankshaft oil seal leak	Dirt accumulation	Seal surface is clean		
			Crankshaft contact point for seal lip wear into the shaft		
		High oil level in the power end	Oil level is not over the high mark		
			Water or condensation has overfilled the power end		

Diesel Engine

Refer to the Caterpillar manual for engine issues.

The display shows codes generated by the Caterpillar Engine Control Module. Refer to the Engine Diagnostics section of your Caterpillar manual for detailed information.

If the engine starts and then immediately shuts down, the cause can be difficult to diagnose correctly. One cause can be low starting battery voltage. Make sure that the starting battery is at 12.6 V and that the battery terminals are clean. Refer to the Caterpillar manual for further instructions on diagnosing engine starting, batteries, and charging system issues.



For diesel units: if a pump is to be stored for extended periods it is recommended by Caterpillar that the engine is turned on and allowed to warm up every 2 weeks. This is to prevent crystallization of the def components used to meet Tier 4 emissions standards. Failure to do so increases risk of def related engine codes causing the engine not to run.

Specifications

General

	BASE UNIT 79" H x 132.5" W x 67.5" D			
DIMENSIONS	FORK POCKETS + 4" H			
	TRAILER + 26" H			
DRY WEIGHT	8,000 LBS. (MAY VARY DEPENDING ON OPTIONS)			
REQUIRED CLEARANCE	3 FT. ON ALL SIDES			
SITE GRADE	LEVEL; SLOPE LESS THAN 8° FROM HORIZONTAL			
MOUNTING TYPE	SKID FRAME			
OIL CAPACITY	40 GALLONS			
FUEL CAPACITY	225 GALLONS			
DEF CAPACITY	8.5 GALLONS			
NOISE EMMISSION	105 dBA @ 3 ft. @ 2100 ENGINE RPM			

Standard Operating Parameters

OUTPUT PRESSURE	3,000 PSI TO 40,000 PSI
OUTPUT FLOW RATE (60HZ)	7.8 GPM TO 85 GPM

High Pressure Pump

TYPE	POSITIVE DISPLACEMENT TRIPLEX, BELT DRIVEN
HYDRAULIC LUBRICATION	SPLASH LUBRICATION / FORCE LUBRICATION
STROKE	3.5 IN.
PLUNGER DIAMETER	SEE 'LP, HP, UHP FLUID END ASSEMBLY' SECTION
OIL	SEE 'POWER END ASSEMBLY' SECTION
LUBRICANT CAPACITY	2.5 GALLON (9.5 LITERS)
RECOMMENDED OIL	SHELL MORLINA SD 100 OR EQUIVALENT SAE 30 NON-DETERGENT OIL

Diesel Engine

TYPE	Tier 3 CAT C7.1	Tier 4 CAT C7.1	Tier 3 CAT C9.3
BHP RATING	275	302	335
FUEL CONSUMPTION (EST.)	13 GAL/HR	13 GAL/HR	15 GAL/HR
ENGINE OIL	10w30	10w30	10w30
EMMISIONS	EXPORT ONLY	TIER 4 FINAL	EXPORT ONLY

Electric Motor

		WEG – W22 NEMA premium efficiency, 3PH									
HORSEPOWER (HP)	HORSEPOWER (HP) 125 150 200 200		00	200	250	250	250	300			
VOLTAGE (VAC)	380	230	460	380	230	460	380	230	460	380	460
FRQUENCY (Hz)	FRQUENCY (Hz) 50 60 50 60		50	60		50	60				
SPEED (RPM)	1480	17	1780 1475 1785		85	1490	1785		1480	1780	
RATED CURRENT (A)	170	340	170	279	460	230	270	554	277	337	330
LOCKED ROTOR CURRENT (A)	1190	2244	1122	1423	3128	1564	1593	3601	1801	2056	2145
FRAME SIZE	FRAME SIZE 444/5T 445/7T			504/5T		447	'/9T				
SAFETY FACTOR	1	1.	15	1	1 1.15		1.15	1.15		1	1.15

Lubrication Specification

Series 250 pumps are splash lubricated by circulating oil or other specified lubricants in the power end. To ensure proper power end lubrication, the oil must pour freely at lowest ambient operating temperatures.

The recommended power end lubricant is Shell Morlina SD 100 or equivalent SAE 30 non- detergent oil. The pump oil capacity for Series 250 pumps is 2.5 gallons (9.5 liters). For system component lubrication refer to the engine, clutch and drive train manuals in the appendix.

The use of quality lubricating oils combined with appropriate condensed water drain and oil filter change intervals are critical factors in maintaining performance and durability. Change the power end oil every 500 hours or six (6) months, or as frequently as operating conditions require to maintain clean, sludge and moisture free oil or proper viscosity.

Service Connections

		LOW PR (10,00	ESSURE 10 PSI)		HIGH PRESSURE (20,000 PSI)						ULTRA-HIGH PRESSURE (40,000 PSI)		
PART NO.	25-510-024 25-510-026 25-510-028 25-510-030		25-520-012 25-520-014 25-520-016 25-520-018 25-520-020 25-		25-520-022	25-540-008	25-540-010	25-540-011					
PLUNGER SIZE	1-1/2"	1-5/8"	1-3/4"	1-7/8"	3/4"	7/8"	1"	1-1/8"	1-1/4"	1-3/8"	1/2"	5/8"	11/16"
INLET	2" NPT				2" NPT						1" NPT		
OUTLET	(4X) SERIES 50			(6X) SERIES 50					(4X) SERIES 50				
OUTLET	(2X) SERIES 100				N/A					(2X) MULTI-CONNECTOR			

		CONNECTION TYPE								
SERIES 50	BLANK (61105026)	1/2" NPT (61105240)	3/4" NPT (61176229)	3/8" HP (61125727)	9/16" MP (61105248)					
SERIES 75	BLANK (61105281)	3/8" HP (61105256)	9/16" HP (61105273)							
SERIES 100	BLANK (61125230)	1/2" NPT (B1104312)	3/4" NPT (61105050)	1" NPT (61150772)	9/16" MP (61152484)	1" MP (61150616)				

Installation Dimensions







	А	В	С	D	E*	F	G	Н	J
10K	16.5	38	.75	52.88	34	31.5	7.63	23.5	30.25
20K	16.5	38	.75	53	34	31.5	7.63	23.5	30.25
40K	16.5	38	.75	51.63	34	31.5	7.63	23.5	30.25

* FOR FORCE LUBRICATED APPLICATIONS ONLY

Inlet Water

The quality of the inlet water supply is one of the most important factors affecting component life and performance. Water treatment requirements can be determined by a water analysis.

The cutting water supply must meet the following standards. A high concentration of dissolved solids, especially calcium, silica and chlorides will affect high pressure component life.

Water Condition

The inlet water source must meet the minimum required levels for the following parameters.

GENERAL PROPERTIES							
CLARITY	-	CLEAR					
COLOR	-	COLORLESS					
ODOR	-	NONE PRESENT					
ELECTRICAL CONDUCTIVITY	-	100-400 µS/cm					
рН	-	6-8.5					

	WATER QUALITY GUIDELINES							
TDS	LOW TDS (<100 PPM)	GOOD QUALITY WATER (MAY USE SOFTENING)						
TDS	MODERATE TDS (100-200 PPM)	CAN BE TREATED BY SOFTENING OR TDS REDUCTION (REVERSE OSMOSIS OR DEIONIZATION)						
TDS	HIGH TDS (>200 PPM)	POOR QUALITY WATER, SHOULD BE TREATED WITH REVERSE OSMOSIS OR DEIONIZATION						
SILICA	HIGH CONTENT (>15 PPM)	TREAT WITH DUAL STRING BASE DEIONIZATION						

Inlet Water Temperature

Higher than specified water temperature causes more wear of internal seals and components.

Ideal inlet water temperature should not exceed 77°F (25°C).

If the temperature of the inlet water to the pump is not within the parameters as specified in this manual, a chiller may be required to achieve the expected pump maintenance cycles. Horsepower, application, and site-specific conditions determine the capacity of a chiller. Contact APS Technical Service for more information.

Inlet Water Pressure

WATER SUPPLY PRESSURE	100 PSI. MAX.
WATER SUPPLY FLOW RATE	10 GPM (HP & UHP FLUID ENDS) 25 GPM (LP FLUID ENDS)

Inlet Water Filtration

10 micron absolute

Carbide Nozzle Size Selector Chart

					N	IOZZLE I	FLOW R	ATING IN	I GPM						
						,	ACTUAL	NOZZLE P	RESSURE	[KSI (BAR))]				
NOZZLE #	ORIFICE IN (MM)	4 (276)	5 (345)	6 (414)	7 (483)	8 (552)	9 (621)	10 (689)	12 (827)	15 (1034)	20 (1379)	25 (1724)	30 (2068)	35 (2413)	40 (2758)
0.1	.008 (.207)	0.12	0.13	0.14	0.15	0.17	0.18	0.19	0.20	0.23	0.26	0.29	0.32	0.35	0.37
0.2	.012 (.293)	0.26	0.29	0.32	0.35	0.37	0.40	0.42	0.46	0.51	0.59	0.66	0.72	0.78	0.83
0.3	.014 (.358)	0.36	0.40	0.44	0.47	0.51	0.54	0.57	0.62	0.69	0.80	0.90	0.98	1.06	1.13
0.4	.016 (.414)	0.47	0.52	0.57	0.62	0.66	0.70	0.74	0.81	0.91	1.05	1.17	1.28	1.39	1.48
0.5	.018 (.463)	0.59	0.66	0.73	0.78	0.84	0.89	0.94	1.03	1.15	1.33	1.48	1.62	1.75	1.87
0.6	.020 (.507)	0.73	0.82	0.90	0.97	1.03	1.10	1.16	1.27	1.42	1.64	1.83	2.00	2.16	2.31
0.7	.022 (.547)	0.89	0.99	1.08	1.17	1.25	1.33	1.40	1.53	1.71	1.98	2.21	2.42	2.62	2.80
0.8	.023 (.585)	0.97	1.08	1.19	1.28	1.37	1.45	1.53	1.68	1.87	2.16	2.42	2.65	2.86	3.06
0.9	.024 (.621)	1.05	1.18	1.29	1.39	1.49	1.58	1.67	1.83	2.04	2.36	2.63	2.89	3.12	3.33
1.0	.026 (.654)	1.24	1.38	1.51	1.64	1.75	1.86	1.96	2.14	2.39	2.77	3.09	3.39	3.66	3.91
1.1	.027 (.686)	1.33	1.49	1.63	1.76	1.89	2.00	2.11	2.31	2.58	2.98	3.33	3.65	3.95	4.22
1.2	.028 (.717)	1.43	1.60	1.76	1.90	2.03	2.15	2.27	2.48	2.78	3.21	3.59	3.93	4.24	4.54
1.3	.029 (.746)	1.54	1.72	1.88	2.04	2.18	2.31	2.43	2.66	2.98	3.44	3.85	4.21	4.55	4.87
1.4	.030 (.774)	1.65	1.84	2.02	2.18	2.33	2.47	2.60	2.85	3.19	3.68	4.12	4.51	4.87	5.21
1.5	.032 (.801)	1.87	2.09	2.29	2.48	2.65	2.81	2.96	3.24	3.63	4.19	4.68	5.13	5.54	5.92
1.6	.033 (.827)	1.99	2.23	2.44	2.64	2.82	2.99	3.15	3.45	3.86	4.45	4.98	5.46	5.89	6.30
1.7	.034 (.853)	2.11	2.36	2.59	2.80	2.99	3.17	3.34	3.66	4.10	4.73	5.29	5.79	6.26	6.69
1.8	.035 (.878)	2.24	2.51	2.74	2.96	3.17	3.36	3.54	3.88	4.34	5.01	5.60	6.14	6.63	7.09
1.9	.035 (.902)	2.24	2.51	2.74	2.96	3.17	3.36	3.54	3.88	4.34	5.01	5.60	6.14	6.63	7.09
2.0	.036 (.925)	2.37	2.65	2.90	3.14	3.35	3.56	3.75	4.11	4.59	5.30	5.93	6.49	7.01	7.50
2.5	.041 (1.034)	3.08	3.44	3.77	4.07	4.35	4.61	4.86	5.33	5.96	6.88	7.69	8.42	9.10	9.73
3.0	.045 (1.133)	3.70	4.14	4.54	4.90	5.24	5.56	5.86	6.42	7.17	8.28	9.26	10.15	10.96	11.72
3.5	.048 (1.224)	4.22	4.71	5.16	5.58	5.96	6.32	6.66	7.30	8.16	9.43	10.54	11.54	12.47	13.33
4.0	.052 (1.308)	4.95	5.53	6.06	6.54	7.00	7.42	7.82	8.57	9.58	11.06	12.37	13.55	14.63	15.64
4.5	.055 (1.388)	5.53	6.19	6.78	7.32	7.83	8.30	8.75	9.59	10.72	12.37	13.84	15.16	16.37	17.50
5.0	.058(1.463)	6.15	6.88	7.54	8.14	8.70	9.23	9.73	10.66	11.92	13.76	15.39	16.85	18.21	19.46
5.5	.060 (1.534)	6.59	7.36	8.07	8.71	9.31	9.88	10.41	11.41	12.75	14.73	16.47	18.04	19.48	20.83
6.0	.063 (1.602)	7.26	8.12	8.89	9.61	10.27	10.89	11.48	12.58	14.06	16.24	18.15	19.89	21.48	22.96
6.5	.066 (1.668)	7.97	8.91	9.76	10.54	11.27	11.95	12.60	13.80	15.43	17.82	19.92	21.82	23.57	25.20
7.0	.068 (1.731)	8.46	9.46	10.36	11.19	11.96	12.69	13.38	14.65	16.38	18.92	21.15	23.17	25.02	26.75
7.5	.071 (1.791)	9.22	10.31	11.30	12.20	13.04	13.83	14.58	15.97	17.86	20.62	23.06	25.26	27.28	29.16
8.0	.073 (1.850)	9.75	10.90	11.94	12.90	13.79	14.62	15.42	16.89	18.88	21.80	24.37	26.70	28.84	30.83
8.5	.075 (1.907)	10.29	11.51	12.60	13.61	14.55	15.44	16.27	17.82	19.93	23.01	25.73	28.18	30.44	32.54
9.0	.077 (1.962)	10.85	12.13	13.28	14.35	15.34	16.27	17.15	18.79	21.01	24.25	27.12	29.71	32.09	34.30
9.5	.079 (2.016)	11.42	12.77	13.98	15.10	16.15	17.13	18.05	19.78	22.11	25.53	28.54	31.27	33.77	36.11
10.0	.081 (2.069)	12.00	13.42	14.70	15.88	16.98	18.01	18.98	20.79	23.24	26.84	30.01	32.87	35.51	37.96
11.0	.085 (2.170)	13.22	14.78	16.19	17.49	18.69	19.83	20.90	22.89	25.60	29.56	33.05	36.20	39.10	41.80
12.0	.089 (2.266)	14.49	16.20	17.75	19.17	20.49	21.74	22.91	25.10	28.06	32.40	36.23	39.69	42.87	45.83
12.5	.091 (2.313)	15.15	16.94	18.56	20.04	21.43	22.73	23.95	26.24	29.34	33.88	37.88	41.49	44.81	47.91
13.0	.093 (2.359)	15.82	17.69	19.38	20.93	22.38	23.74	25.02	27.41	30.64	35.38	39.56	43.33	46.81	50.04
14.0	.096 (2.448)	16.86	18.85	20.65	22.30	23.84	25.29	26.66	29.20	32.65	37.70	42.15	46.17	49.87	53.32
15.0	.100 (2.533)	18.30	20.45	22.41	24.20	25.87	27.44	28.93	31.69	35.43	40.91	45.74	50.10	54.12	57.85

References

Engineering Drawings

Engineering drawings are supplied with your pump in the appendix of this manual.

Spare Parts

Fluid End Parts

	L	OW PRESSU	RE (10,000 PS	SI)		Н	IGH PRESSU	RE (20,000 P	SI)		ULTRA-HIGI	H PRESSURE	(40,000 PSI)		
PART NO.	25-510-024	25-510-026	25-510-028	25-510-030	25-520-012	25-520-014	25-520-016	25-520-018	25-520-020	25-520-022	25-540-008	25-540-010	25-540-011		
PLUNGER SIZE	1-1/2"	1-5/8"	1-3/4"	1-7/8″	3/4"	7/8″	1″	1-1/8"	1-1/4"	1-3/8″	1/2″	5/8"	11/16"		
PLUNGER	61115080	61115129	61115147	61115163	61115072	61114858	61115064	61115121	61115105	61109355	61115179	61115204	61152359	3*	
HP PACKING	25-500-224	25-500-226	25-500-228	25-500-230	25-500-212	25-500-214	25-500-216	25-500-218	25-500-220	25-500-222	25-500-208	25-500-210	25-500-211	6*	
LP PACKING	25-500-324	25-500-326	25-500-328	25-500-330	25-500-312	25-500-314	25-500-316	25-500-318	25-500-320	25-500-322	25-500-308	25-500-310	25-500-311	6*	
SPRG SPACER	61137104	61137169	61125180	61120068	61119761	61119844	61119662	61119720	61119712	61119738	61119605	61120034	61152443	3*	
SUCT MFLD		25-50	10-110				6110	2112				61102104			
DISCH MFLD		6113	7021				6110	2062				25-500-111			
BARREL		25-50	10-101				25-50	0-102				25-500-103			
VALVE SEAT		6111	9227		61119152							3*			
SPCR CMP SEAL		61117217					6111	7350				61117491		3*	
COMP SEAL					6111	7350						61117267		3*	
COMP SEAL		61118677				61117350						61117316			
DISCH VALVE		6112	1984				6112	1942				61121927		3*	
DISCH SPR		6113	7055		61120339								3*		
DISCH GDE		6110	6138				6112	2760					3*		
SUCT VALVE		6112	2348				6112	2827				61135748		3*	
SUCT SPR		6112	0521				6112	0529				61120199		3*	
RTN RNG		6111	5964				6111	5907				61115956		3*	
PKG NUT		25-50	10-104			25-50	10-106		25-50	0-105		25-500-107			
PKG NUT O-RNG							30-002-150							6*	
MFLD O-RNG		6111	8083						61117835					6*	
SUCT BOLTS	25-500-116						90-02	8-550				90-028-500			
DISCH BOLTS	;				90-02	6-500						90-022-450			
COLLET NUT	61112944				61113085										
PLGR COLLET	61103054 61103187 61103062 61103070				0 61103137 61103153 61103088 61103111 61103104 61103119					61103119	19 61103096 61103145 61152492				
PONY ROD	61128832				25-500-108				25-500-109						

* Recommended spare parts quantities

Lubricants

Silver Anti-Seize	Part # 24-002-001
Blue Lubricant	Part # 24-001-001
Loctite 242	Part # 24-001-026
LubriMatic® White Lithium Grease	Part # 24-001-016

Water Quality Test Kit

Water Test Kit Part # 007851-1



			8	7	6	5		4	3
ſ	ITEM NO.	QTY.	PART NO.	DESCRIPTION	NOTES	•			-
Ī	1	1	32-500-000	TRPLX UNIT-S300, T4C7, BASE	1. PUMP SPEED: 700 RPM @ 2100 ENGINE RPM /	MAX.			
ł	2	1	25-520-016	FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD	2. OPERATING PRESSURE: 20,000 PSI				
3	3	1	25-520-200	KIT-FL END ACCESS, \$300, P,2P,4G40,9M,240R,270R,P	3. THEORETICAL FLOW: 25 GPM @ 2100 ENGINI	ERPM			A)
ł	4	1	33-500-012	KIT-WTR TNK, S300	4. TEST FOR THR. PUMP SHOULD DEVELOP 20 K	SI USING A #11 (0.085) NOZ @ 2100 RPM			
ľ	5	1	33-500-011	KIT, LIFT BALE, S300	3. HEMINOI SHOWN				
ł	6	1	31-500-013	WEIDMENT BASKET CRASHGUARD S-300	-				
ł	7	1	31-500-028	WEIDMENT FORK POCKETS S-300	-				
	, 8	1	11-001-039	PENDANI E-STOP 50 FI					
- F F E E E E E E E E E E E E E E E E E									
							AP		WISE SPECIFIED:
									IHIRD ANC

									VUNAL BAIER ABBURG	DIMS IN MM ARE	. FOR REFERENCE ONLY	
A								SHAPE IEC	HNOLOGIES GROUP	BREAK SHARP EL	GES AND DEBURR .015	DWG BY
				REVISIONS						TOLERANCES	(EXCEPT AS NOTED)	
	ZONE	REV.		DESCRIPTION		DATE	APPROVED	APS AND THE APS LOGO AP			DIM TOLERANCES: (in) .X = ± .063	APRVD BY
		1		INITIAL RELEASE		4/5/2023	K. SMITH	INC. IN THE UNITED STATES AND	D/OR OTHER COUNTRIES	ANGLE ±1°	XX = ± .015 .XXX = ± .005 .XXXX = ± .0005	MATERIAL
			8	7	6			5		4	:	3



	8	7	6	5	4	3
F			FUEL COOLER		HYD. MOTOR SET WATER PRESSURE 140 PSI @ 2100 RPM	
				PARTICLE		WATER TO O
			DIESEL	FILTER		HEAT EXCHANG
		' 	FUEL ETURN			
			DIESEL			WATER CIRCU
Ξ			FUEL 302 HORSEP IN DIESEL ENG 2100 RPM	OWER GINE MAX		(SEE SHEET
				HYD. GEAR		
					WATER CHARGE PUMP (SEE SHEET 2)	
						>
			POWER END			
						HYD. RELIEF SET 80 F @ 2100 R
►		I 🗼				0 2.00
			LEVEL ROLL OVER GAUGE VENT			
			$\Box \qquad \Leftrightarrow \qquad $	· · · · · · · · · · · · · · · · · · ·		\frown
В			Y			
			DIESEL FUEL TANK 225 GAL. (850 LITER) CAP	ACITY	HYDRAULIC O 40 GAL. (170 L	IL RESERVOIR ITER) CAPACITY
				APS AND THE APS LOGO ARE EITHER	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES	TITLE:
A				OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES	INTERPRET PER ANSI 114.5-2009 DIM'S IN [mm] ARE REFERENCE ONLY BREAK SHARP EDGES & DEBURR .015	
-		REVISIONS		THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATION WHICH MAY BE CONTROLLED AND IS NOT TO RE	SURFACE 63/ DIM TOLERANC	THIRD ANG CES: (in) 063 DWG BY
ZOI	NE REV.	DESCRIPTION	DATE APPROVED	DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM ADVANCED PRESSURE SYSTEMS.	$\begin{array}{c cccc} MACHINE & R.02 & \vdots & \vdots \\ \hline FILLETS & R.02 & .XX & = \pm \\ \hline ANGLE & \pm 1^{\circ} & .XXX & = \pm \\ \end{array}$.015 .005 APRVD BY
L	8	7	6	5	4	3



A I					APS AND THE APS LOG REGISTERED TRADEMARKS OF SHAPE TECHNOLOG	O ARE EITHER OR TRADEMARKS IES INC. IN THE	DI	UNLESS OTHE ALL DIMENSION INTERPRET PER M'S IN [mm] ARE EAK SHARP EDO	<u>RWISE SPECIFIED</u> IS ARE IN INCHES ANSI Y14.5-2009 E REFERENCE ONLY GES & DEBURR .015	
		REVISIONS					TOLERA SURFACE FINISH	NCES (E)	XCEPT AS NOTED) DIM TOLERANCES: (in)	THIRD AND
ZONE	REV.	DESCRIPTION	DATE	APPROVED	DISCLOSED TO OTHERS FOR ANY FOR MANUFACTURING PURPOSE	PURPOSE NOR USED S WITHOUT WRITTEN	MACHINE FILLETS	R.02	$.XX = \pm .005$ $.XX = \pm .015$	
	0	INITIAL RELEASE	11/2/20	K. SMITH	PERMISSION FROM ADVANCED	PRESSURE SYSTEMS.	ANGLE	±1°		
	8	7	6		5	Î.	4		3	

F

_

E

_

D

->

С

_

В



Int Mo. PART NO. DESCRIPTION IPM NO. PART NO. DESCRIPTION 1 1 3500006 WOLDMATL LAW, SOL MPROBALL CLIMES 51 4 9020-075 BOLL HEX, SUP 11X 2.14/2 2 1 A.7344 BREAMER, PRESSURED, 400K/R0N 52 8 9020-075 BOLL HEX, SUP 11X 2.14/2 3 1 2020810 COMPR, ACCESS, IOP HARNIT, 100K, HINFY, 100K, HINF 51 4 9022-105 BOLL HEX, 10/4 11X 1/4 5 1 2020820 BERAMER, VEIN, KON-SEASL 11/4/11X 1/4 16 9025-005 BULTION HINES, 307-18X 2/4/5 7 1 31-50002 WELDMEN, BRACET, SOD, FILEY STAND 97 4 9025-005 NULTION HINES, 307-18X 2/4/5 9 1 31-50001 WELDMEN, BRACET, SOD, FILEY STAND 97 4 9021-005 NULTION HINES, 327-18X 2/4/5 11 1 31-50001 WELDMEN, BRACET, SOD, FILEY STAND 97 6 9047-00 FILEY MARKER, 3/2/5 12 1 31-50001 WELDMEN, BRACET, SOD, FILEY STAND 97 4 9022-				8	7			6	5 5
1 3158000 WELDMENT, TANK, 5200, IPDRAULUC/DESL 51 24 90.02-175 BOLT, IEE, 567-11 X 1-3/* 2 1 202080-20 CAURE, IDDID LVIZ, ALMANUA, 5 NCH 53 4 90.02-205 BOLT, IEE, S67-11 X 1-3/* 4 1 202080-20 CAURE, IDDID LVIZ, ALMANUA, 5 NCH 53 4 90.02-205 BOLT, IEE, X, 3/* 10.0.1.3/* 4 1 202080-20 SEALINE, VINT, ION-SA ASH, VIA VIA 54 4 90.02-07.55 BUTTON HIRES, 307-16X 3/* 5 1 20080-01 SEALINE, VINT, ION-SA ASH, VIA VIA 56 4 90.02-07.55 BUTTON HIRES, 307-16X 3/* 57 8 1 31-500.00 WELDMEN, IBACKET S.200, IEE A SHOWAID 58 17 90-720.00 NUL, INV-OCK 38*-11 10 1 31-500.00 WELDMENT, IBACKET AND, S00, PR41 60 8 90.490.200 INUL INV-OCK 38*-11 11 1 31-500.01 WELDMENT, IBACKET AND, S00, PARIDAND 64 94.490.200 INUL INV-OCK 38*-100 12 1 31-500.013 WELDMENT, IPR ASTE	ITEM	NO.		PART NO.	DESCRIPTION	ITEM NO.		PART NO.	DESCRIPTION
2 1 A-rised BERLIFER (PESUBERD 40 MCRON 52 8 00:00:025 BDITL HER, SPIT 1X 3: A/r 5 1 2008000 CAUGE (UDIT VIRLA LUNEWUK, DICH) 63 4 40:00:201 BERLIFER, VEX, TA'Y 6 1 200281:01 COVER, ACCESS, TOP FROMT, TANK, HSKY, TA'S MF 6 4 40:00:201 BULT HEX, YES, X'F' 1X 3: A'' 7 1 31:500:00 WEIDMENR, BRACKET, SSO, DE FROMT, TANK, HSKY, TAY 5 4 40:00:201 BULT NER, YES, X'F' X'F'S 8 1 31:500:00 WEIDMENR, BRACKET, SSO, DER, KORT, SSO, TERS TAND 57 4 90:51:00:55 BUTTON THIERS, YES, X'F'S 9 1 31:500:00 WEIDMENR, BRACKET, SSO, DER, KARN 50 6 90:51:00:55 NUTTON THIERS, YES, X'F'S 10 1 31:500:001 WEIDMENR, BRACKET, SSO, DER, KARN 6 8 90:61:600 FLATWASHER, YE' 11 31:500:001 WEIDMENR, BRACKET, SSO, DER, STABROLANO 61 14:00010 FLATWASHER, YE' 11 31:500:001 WEIDMENR, MER ZE', HO'N, MARANA, SSO <td>1</td> <td></td> <td>1</td> <td>31-500-006</td> <td>WELDMENT, TANK, S-300, HYDRAULIC/DIESEL</td> <td>51</td> <td>24</td> <td>90-020-175</td> <td>BOLT, HEX, 5/8"-11 X 1-3/4"</td>	1		1	31-500-006	WELDMENT, TANK, S-300, HYDRAULIC/DIESEL	51	24	90-020-175	BOLT, HEX, 5/8"-11 X 1-3/4"
3 1 20068.00 CALIGE LINUE INVE. ALLWAND, SERVEL 53 4 90.00.00 BOT, LIKE, SET IX 2* 5 1 20228101 CONTR ALCESS, TOP FORT, TAKE, HEY, PER, 125 RCH, 54 4 90.00.00 BOT, HEX, X1*10, X1*24* 5 1 20228101 CONTR ALCESS, TOP FORT, TAKE, HEY, PER, 125 RCH, 54 4 90.00.00 BOT, HEX, X1*25 X 6 1 33.00.00 RELEDINE, BLACKET, S300, TILEX FLORESTAND 57 4 90.50.00.05 BUTON PHILIPS, 30*124 X1*25 X 7 1 33.00.00 WELDINE, BLACKET, S300, TILEX FLORESTAND 56 6 90.30*05 S BUTON PHILIPS, 30*124 X1*25 X 9 1 31.500.001 WELDINE, BLACKET, 500, TILEX FLORENCH 66 12 90.20.000 RAT WASHER, 177 10 1 31.500.010 WELDINE, BLACKET, MOD, S300, FORT 60 8 90.810.000 RAT WASHER, 177 11 1 31.500.016 WELDINE, INFORMON, S300, FORT 61 1 33.001.016 ASSEMUL, DETAWASHER, 176 12 1 31.500.016 WELDINE, INFORMAN	2		1	A-7564	BREATHER, PRESSURIZED, 40 MICRON	52	8	90-020-225	BOLT, HEX, 5/8"-11 X 2-1/4"
4 1 202810 COVER.ACCESI. TOP FROMT. TANK, HISKY, 1.22 BINC 54 4 90.022.175 BOIT, HEX, 34-10, X1-34- 5 1 20288-01 BRADIRE VIRT, MONS-PASUL, 11/27 NP1 56 4 90.022.175 BUIT, HEX, 147.47-47 7 1 31.500.003 GALIGE, LICUID LIVEL, DESEL, 8°1.6, 1-1/27 NP1 56 4 90.512.075.5 BUITON FIRUES, 270-14 X1-27 SS 7 1 31.500.003 WEILDMENT, BRACKET, S300. IERA & STARBOARD 57 4 90.512.005 BUITON FIRUES, 270-11 X1-X X-Y SS 9 1 31.500.003 WEILDMENT, BRACKET, S00. DERK & STARBOARD 60 90.812.000 FLAT WASHER, 287 11 1 31.500.013 WEILDMENT, BRACKET-MOD, S00.01 61 54 90.820.000 FLAT WASHER, 297 113 1 31.500.010 WEILDMENT, MERACKET-MOD, S00.01 62 4 90.820.000 FLAT WASHER, 297 114 1 31.500.014 PLAUELDMENT, MERACKET-MOD, S00.01 64 1 90.900.01 GASKER, 74.04, 24.47 11 1 3	3		1	200680-02	GAUGE, LIQUID LEVEL, ALUMINUM, 5 INCH	53	4	90-020-300	BOLT, HEX, 5/8"-11 X 3"
s 1 2020B201 BIRCHUR, VEN, NON-SPLASI, 1/Y MPT S5 4 99-028-000 BOLT LEX, 19.X X ⁺ 6 1 331-00002 WELDMENT, BRACKET S-300, TELEXSTAND 57 4 90-520-0525 BUITON PHUES, 310-2X X-2S5 8 1 31-00000 WELDMENT, BRACKET S-300, TELEX, PORT 58 12 90-22-000 NUT, MY-LOCK, 567-11 9 1 31-00000 WELDMENT, BRACKET S-300, TELEX, PORT 58 12 90-22-000 NUT, MY-LOCK, 567-11 10 1 31-00001 WELDMENT, BRACKET-MOD, S300, FORT 60 8 99-81-000 FLAT WASHER, 547 11 1 31-80010 WELDMENT, BRACKET-MOD, S300, FORT 62 4 90-822-000 FLAT WASHER, 547 13 1 31-80010 WELDMENT, BRACKET-MOD, S300, FORT 63 1 33-001-001 RAXE REV, DET MARK 14 1 31-80010 WELDMENT, MOS SHARE, S47 1 33-001-001 RAXE REV, DET MARK 1 15 1 31-80010 WELDMENT, MOS SHARE, REV MENT, S00-902-01	4		1	202281-01	COVER, ACCESS, TOP FRONT, TANK, HISKY, 1.625 INCH	54	4	90-022-175	BOLT, HEX, 3/4"-10 X 1-3/4"
6 1 33:00:05 GAUGE LOUID LEVEL DESL 0" (G. 1-1/2" MPT 56 6 90:50:07555 BUITON PHILPS, 410:4X 1/2" SS 7 1 31:500:002 WELDMENT, BRACKET, 5300, FREE STAND 57 4 90:52:07555 BUITON PHILPS, 300:16X X1/2" SS 8 1 31:500:001 WELDMENT, BRACKET, 5300, FREE STAND, DRAFT 58 12 90:52:07555 BUITON PHILPS, 300:16X X1/2" SS 10 1 31:500:001 WELDMENT, BRACKET, 5500, DRAFT, STAND, DRAFT 68 90:812:000 FR.11 WASHER, 50" 11 1 31:500:010 WELDMENT, BRACKET, MOD, SS00, STABRICARD 61 54 90:820:000 FR.11 WASHER, 50" 12 1 31:500:010 WELDMENT, BRACKET, MOD, SS00, STABRICARD 61 13:300:010 FR.11 WASHER, 50" 13 13:300:021 WELDMENT, PROVENDER TALE, FORT 66 11 33:500:010 FR.11 WASHER, 540" 14 1 31:400:010 WELDMENT, PROVENDER TALE, FORT 66 11 33:500:001 ASSEMBLY, MERCHENE, SS00, DESA 17 1 31:400:010 WELDMENT	- 5		1	202882-01	BREATHER, VENT, NON-SPLASH, 1/4" NPT	55	4	90-026-400	BOLT, HEX, 1"-8 X 4"
7 1 31:500:002 VELDMENT, BRACKET, SJOD, TER STAND 57 4 90:512:005 BUTTO, PHURES, SZE, 154:304 SZE	6		1	33-001-035	GAUGE, LIQUID LEVEL, DIESEL, 8" LG, 1-1/2" NPT	56	6	90-506-050.SS	BUTTON PHILIPS, #10-24 X 1/2" SS
8 1 31 500.003 WELDMENT, BRACETT, S200, TIER 4, PORT 58 12 9972.000 NUT, IY-UCCK, 5/// 11 9 1 31.500.004 WELDMENT, BRACETT-MOD, S200, FDR1 60 8 99812.000 FLAT WASHER, 1/2 111 1 31.500.031 WELDMENT, BRACETT-MOD, S200, S1ARBOARD 61 94 99822.000 FLAT WASHER, 5/2* 12 13 31.500.010 WELDMENT, BRACETT-MOD, S200, S1ARBOARD 62 4 99822.000 FLAT WASHER, 5/4* 13 1 31.500.010 WELDMENT, PLATE, PLOS SUPPORT TWIN, S200 63 1 33.001.011 ASSEMBLY, DET TANK ENCLOSURE, HUSKY 14 1 31.500.010 WELDMENT, PLOS SUPPORT TARLE, PORT 64 1 33.500.001 ASSEMBLY, WET GEAR, 33CC, S4A, 111 H1/62 PTCH 16 1 31.500.015 WELDMENT, PLOS SUPPORT FLATE, PORT 64 1 33.500.002 ASSEMBLY, WER RULER, S300 17 1 33.500.005 ENGINE, CAT, TS, TARLE, ASDE N, BASE 67 1 33.500.002 ASSEMBLY, WER ALL, RULE, NURA, SSDE ALL, ASDE N, BASE 71	7		1	31-500-002	WELDMENT, BRACKET, S-300, FILTER STAND	57	4	90-512-075.SS	BUTTON PHILIPS, 3/8"-16 X 3/4" SS
9 1 31:500:004 WIELDMENT, BRACKET, SOD, TIER & STAREGARD 59 6 99:81:2000 FLAT WASHER, 3/# 10 1 31:500:031 WIELDMENT, BRACKET-MOD, S300, PORT 60 8 99:81:2000 FLAT WASHER, 3/# 11 11 31:500:027 WIELDMENT, BRACKET-MOD, S300, PORT 60 8 99:82:000 FLAT WASHER, 3/# 12 11 31:500:010 WIELDMENT, BRACKET-MOD, S300, PORT 62 4 99:82:000 FLAT WASHER, 3/# 13 11 31:500:010 WIELDMENT, PLORES, STORES, S00 63 1 33:01:016 ASSEMBLY, DETANK REACIOSUBE, HUSKY 14 1 31:500:010 WIELDMENT, PLOS SUPPORT FLATE, SIAREGARD 65 1 33:500:000 ASSEMBLY, DETANK REACE PLURP, S-300 17 1 33:500:000 MIELDMENT, ERIE SVUMENT, ERIE SVEMENT, ERIE SVUMENT, ERIE SVEMENT, ERIE	8		1	31-500-003	WELDMENT, BRACKET, S-300, TIER 4, PORT	58	12	90-720-000	NUT, NY-LOCK, 5/8"-11
10 1 31-500-031 WELDMENT, BRACKET-MOD, S300, FORT 60 8 99-82-000 FLAT WASHER, 1/2" 11 1 31-500-032 WELDMENT, BRACKET-MOD, S300, STARBOARD 61 54 99-82-000 FLAT WASHER, M/F 12 1 31-500-010 WELDMENT, PLATE, BASK, BY SAND 63 1 33-001-01 ASSEMBLY, DET TANK ENCLOSURE, HUSK Y 14 1 31-500-015 WELDMENT, PLATE, STARBOARD 64 1 39-001-016 ASSEMBLY, WASHER, 1/2" 14 1 31-500-015 WELDMENT, PLO SUPPORT PLATE, STARBOARD 65 1 33-001-021 PUMP, EXT GEAR, 33-CC, SAE A, 11 TH 16/32 PICH 16 1 33-500-005 ASSEMBLY, MORALUC FUER, S-300 ASSEMBLY, MORALUC FUER, S-300 18 1 61102294 ISHIG SPI LIPR, CD, 3.75 ID, AGD S2504-60 69 1 33-500-002 ASSEMBLY, MORALUC FUER, S-300 21 1 61102294 ISHIG SPI LIPR, CD, 3.50 ID, FACD S2504-65 70 1 33-500-006 ASSEMBLY, MORALUC FUER, S-300 22 1 61102294 ISHIG SPI LIPR, CD	9		1	31-500-004	WELDMENT, BRACKET, S-300, TIER 4, STARBOARD	59	6	90-812-000	FLAT WASHER, 3/8"
11 1 31:500:02 WELDMENT, BRACKET MOD, S200, STARBOARD 61 54 90:822:000 FLAT WASHER, 5/If 12 1 31:500.010 WELDMENT, BELT GUARD, S300 62 4 90:822:000 FLAT WASHER, 5/If 14 1 31:500.010 WELDMENT, FLOR SUPPORT, TWN DISC 64 1 90:492:001 GASKET, FLAT, SAE-A 28:001. N890, 1/4/ 16 1 31:500.010 WELDMENT, PLO SUPPORT, FLATE, STARBOARD 65 1 33:001.021 PUMP, EXT GEAR, 33:CC, SAE-A, 11:11 H 16/32 FICH 16 1 33:600.05 ENGINE, CAT, C71, TIER 4, 302 HP, BASE 67 1 33:600.002 ASSEMBLY, WARER FLEE, S300 17 1 33:600.05 ENGINE, CAT, C71, TIER 4, 302 HP, BASE 67 1 33:600.002 ASSEMBLY, HORAUE FLEE, S300 18 1 6110224 BSHG SPLITR/CD, 33:0 D / ACD S2044-56 70 1 33:600.002 ASSEMBLY, HORAUE FLEW, MARLD, S30, NO ECV/PT 20 1 6110823 SPRK1-HAM MICH, 275 W, HAB EKE, MOD, 1450 73 1 33:4995.003 LABEL, PLATE, WARNER, GU, CON Y	10	5	1	31-500-031	WELDMENT, BRACKET-MOD, S300, PORT	60	8	90-816-000	FLAT WASHER, 1/2"
12 1 31-500-007 WELDMENT, PLIN PLARD, S-300 62 4 90-822-000 FLAT WASHER, 3/4" 13 1 31-500-010 WELDMENT, PLIN PLASE, 8 HGT, S-300 63 1 13-001-016 ASSEMBLY, DET TANKE NUCLOSURE, HUSKY 14 1 31-500-016 WELDMENT, PLO SUPPORT, INN DISC 64 1 99-04%-001 GASKET, ITAT, SAK-A. 24-001, TIRKY, SAK-A. 24-01, TIRK, SAK-24-001, TIRK, SAK-24-01, TIRK, TIRK, SAK-24-01, TIRK	11	1	1	31-500-032	WELDMENT, BRACKET-MOD, S300, STARBOARD	61	54	90-820-000	FLAT WASHER, 5/8"
13 1 31-500-010 WELDMENT, PUMP BASE, 8' HGT, S-300 63 1 33-301-016 ASSEMBLY, DET TANK ENCLCSURE, HUSKY 14 1 31-500-014 PLATE, FIO SUPPORT, TWIN DISC. 64 1 99-494 9001 GASET, FLAT, SAE A, 240CJ, 18099, 17.44" 15 1 31-500-016 WELDMENT, PIO SUPPORT, TWIN DISC. 64 1 33-300-001 ASSEMBLY, WATER FLEER, S-300 16 1 31-500-016 WELDMENT, PIO SUPPORT, PLATE, FORT 66 1 33-500-000 ASSEMBLY, WATER FLEER, S-300 18 1 61106294 BSHG-SPLTPR, CDL, 37-50 JAACD, S2904-60 69 1 33-500-009 ASSEMBLY, WATER FLEER, S-300 19 1 61102294 BSHG-SPLTPR, CDL, 37-50 JAACD, S2940-60 69 1 33-500-009 ASSEMBLY, WATER FLEER, VLWNELD, S-300, NCV/PT 21 1 6110623 SPRKT-HAMM PTCH, 2.75 WIA9 TEETH 77 1 33-599-001 LABEL, PATE, WARNING, COLONEY 22 1 6116823 SPRKT-HAMM PTCH, 2.75 WIA9 TEETH 77 1 33-995-001 LABEL, PATE, WARNING, COLONEY <t< td=""><td>12</td><td>2</td><td>1</td><td>31-500-007</td><td>WELDMENT, BELT GUARD, S-300</td><td>62</td><td>4</td><td>90-822-000</td><td>FLAT WASHER, 3/4"</td></t<>	12	2	1	31-500-007	WELDMENT, BELT GUARD, S-300	62	4	90-822-000	FLAT WASHER, 3/4"
14 1 31-500-014 PLATE, PIO SUPPORT, TWIN DISC 64 1 99-049-001 GASKET, FLAT, SAE A 2 BOLT, N8090, 1/64* 15 1 31-500-015 WILLDMAIN, PIO SUPPORT, FLATE, STARBOARD 65 1 33-900-01 GASKET, FLAT, SAE A 2 BOLT, N8090, 1/64* 16 1 31-500-015 WILLDMAIN, PIO SUPPORT, FLATE, STARBOARD 66 1 33-900-001 ASSEMBLY, INTER, S300 17 1 33-90-005 ENGINE, CAT, C7.1, TIER 4, 302 HP, IBASE 67 1 33-500-002 ASSEMBLY, INTER, S300 18 1 61109698 CUICH-PIO DBL P, S9311,SAE NO.3 HIGS 68 1 33-500-000 ASSEMBLY, INTER, VARIARCE PLIMP, S300 20 1 61102836 BSHG, SPLITPR, CDJ. 37.50 MLADD S25044-56 70 1 33-995-001 LABEL, PATE, WARNING, OLI ON V 22 1 61102870 KEY SIK SQL 88.51, RID AOD S2443-14 71 1 33-995-001 LABEL, PATE, WARNING, OLI ON V 23 1 61166823 SPRK1-HAM PICH, 27.59 WIDE, CINNIL 74 1 33-995-001 DECAL, WIN, WARNIN, PICH, PISH, PISH, MARNIN	13	3	1	31-500-010	WELDMENT, PUMP BASE, 8" HGT, S-300	63	1	33-001-016	ASSEMBLY, DEF TANK ENCLOSURE, HUSKY
15 1 31-500-015 WELDMENT, PTO SUPPORT PLATE, STARBOARD 65 1 33-001-021 PUMP, EXT GEAR, 33-CC, SAE, A, 11 TH 16/32 PTCH 16 1 33-500-016 WELDMENT, PTO SUPPORT PLATE, PORT 66 1 1 33-500-002 ASSEMBLY, WATER FLIER, S300 17 1 33-500-005 ENGINE, CAT. (7.1, TIE 4, 302 HP, BASE 67 1 33-500-000 ASSEMBLY, WATER FLIER, S300 18 1 61160498 CLIUTCH-PTO, DRU P, IS711,5AE NO. 3 HSG 68 1 33-500-006 ASSEMBLY, CHARGE PLMP, S-300 20 1 61102636 BSHG-SPLTIPR, OD. 370 ID, ACID S25044-56 70 1 33-500-006 ASSEMBLY, HEAF EXCHANGER, HIGH FLOW, S300 21 1 61108870 EKY STS-S, BR.ST. HAM PICH 2,75 WI 16 RETH 71 1 33-995-001 LABEL, PLATE, WARNING, OLI ONLY 22 1 61106870 SPRKT-14MM PICH 2, 75 WI 16 RETH / SERES SBHG 73 1 33-995-010 DECAL, VINY, WARTE RITER TAG 24 1 33-001-029 RELT 3124, HAM PICH 2, 75 WIDE, CNINIL 74 1 33-995-010	14	4	1	31-500-014	PLATE, PTO SUPPORT, TWIN DISC	64	1	99-049-001	GASKET, FLAT, SAE-A 2-BOLT, N8090, 1/64"
16 1 31-500-016 WELDMENT, PTO SUPPORT PLATE, PORT 66 1 33-500-001 ASSEMBLY, WATER FLITER, S-300 17 1 33-500-005 ENGINE, CAL, C.Y., TIER 4, 302 PH, PASE 67 1 1 33-500-003 ASSEMBLY, HARGE PLWP, S-300 18 1 6110-920 BSHG-SPLITPR, QD, 3.75 ID, M. AQD 52504-65 69 1 33-500-003 ASSEMBLY, CHARGE PLWP, S-300 20 1 61102294 BSHG-SPLITPR, QD, 3.75 ID, M. AQD 52504-55 70 1 33-500-009 ASSEMBLY, HAT EXCHANCE, RIGH FLOW, S300 21 1 611035228 SPRKT-14MM PTICH, 2.75 W.168 TEETH 72 1 33-995-003 LABEL, PLATE, WARNING, OU DNY 22 1 61135228 SPRKT-14MM PTICH, 2.75 W.168 TEETH 72 1 33-995-003 LABEL, PLATE, WARNING, OU DNY 24 1 33-000-029 BELT-336, JAMM PTICH, 2.75 WIDE, CNTNIL 74 1 33-995-010 DECAL, VINYL, WATER FLIER INZL 25 1 25-500-004 PWE RD ASSY "SRIE 300, APS & AQD 75 2 33-995-011 DECAL, VINYL, WATER FLIER NATI	15	5	1	31-500-015	WELDMENT, PTO SUPPORT PLATE, STARBOARD	65	1	33-001-021	PUMP, EXT GEAR, 33CC, SAE-A, 11 TH 16/32 PTCH
17 1 33.950-005 ENGINE, CAT, C.T., TIER 4, 302 HP, BASE 6.7 1 33.800-002 ASSEMBLY, HYDRAULIC FILTER, S. 300 18 1 61180/988 CLUTCH-PIC.DBL PL, SP311,SAE NO. 3 HSG 68 1 33.800-002 ASSEMBLY, RELIEF VLV MINED, S. 300 19 1 61102244 BSHG-SPLTIPR.OD. 3.75 ID.MAOD S2504-60 69 1 33.500-008 ASSEMBLY, RELIEF VLV MINED, S. 300, NO ECV/PT 20 1 61108270 KEY SIK SOL BASILPITD.AQD S2404-56 70 1 33.905-003 LABEL, PLATE, WARNING, OLI ONLY 22 1 61108270 KEY SIK SOL BASILPITD.AQD S2404-514 71 1 33.905-003 LABEL, PLATE, WARNING, OLI ONLY 23 1 61108270 KEY SIK SOL BASILF PLD AQD S2404-514 71 1 33.905-003 LABEL, PLATE, SERVICE/SUPPORT 23 1 6116823 SPRK1-14MM PTICH 2.75 WIDE, CNINIL 74 1 33.905-010 DECAL, VINY, UATER FILTER FAG 26 1 12-005-0064 PWR END ASSY. SENES 300, APS & ACDD 75 2 33.905-014 DECAL, VINY, UATER FILTER AG	16	5	1	31-500-016	WELDMENT, PTO SUPPORT PLATE, PORT	66	1	33-500-001	ASSEMBLY, WATER FILTER, S-300
18 1 61186988 CLUTCH-PIO.DBL PL, SP311.SAE NO. 3 HSG 68 1 33.800-003 ASSEMBLY, CHARGE PUMP, S-300 19 1 61102294 BSHG-SPLTJPR.OD. 3.75 ID.M. AOD S25046-60 69 1 33.800-006 ASSEMBLY, RELET VLV MARLD, S-300, ND ECV/PT 20 1 61102366 BSHG-SPLTJPR.OD. 3.50 ID, FAOD S25046-60 69 1 33.800-006 ASSEMBLY, HEAT EXCHANGER, HIGH FLOW, S300 21 1 61108270 KEY SKO.28, SLI, PLID.AOD S2484514 71 1 33.905-001 LABEL, PLATE, WARNING, OLI ONLY 22 1 61136228 SPRKT-14MM PTICH, 2.75 WJ66 TEEHT 72 1 33.905-001 LABEL, PLATE, WARNING, OLI ONLY 23 1 25.00-004 PWR END ASSY. SERIES 300, APS & AOD 75 2 33.995-011 DECAL, VINYL, WARER FILTER TAG 26 1 12-005-0608 FITTING, STRI, MNPT-MUIC, 08-08 76 1 33.995-011 DECAL, VINYL, WARER FILTER TAG 28 1 12-007-2424.8 FITTING, STRI, MNPT-MUIC, 08-08 76 1 33.995-019 LABEL, PLATE, WARENG, PRICH POINT	17	7	1	33-950-005	ENGINE, CAT, C7.1, TIER 4, 302 HP, BASE	67	1	33-500-002	ASSEMBLY, HYDRAULIC FILTER, S-300
19 1 61102344 BSHG-SPLT,PR-QD, 3.75 ID,MAQD S25046-60 69 1 33-500-006 ASSEMBLY, RELIEF VLV MNFLD, S-300, NC ECV/PI 20 1 61102366 BSHG-SPLT,PR-QD, 3.50 ID,F AOD S25044-56 70 1 33-500-006 ASSEMBLY, HEAT EXCHANCER, HIGH FLOW, S300 21 1 61108870 KEY SIK-SQ, 88 SIL,PITD AQD S24483-14 71 1 33-995-001 LABEL, PLATE, WARNING, OIL ONLY 22 1 61158278 SPRKT-14MM PTICH, 275 WJ, 56 TEETH 72 1 33-995-003 LABEL, PLATE, SERVICE/SUPPORT 23 1 61166823 SPRKT-14MM PTICH, 275 WJ, 56 TEETH, 52 RES SBHG 73 1 33-995-010 DECAL, VINVL, WATER FLITER TAG 25 1 25500-004 PWR RIND ASY-SEBERS 300, APS & AOD 75 2 33-995-014 DECAL, VINVL, WATER FLITER TAG 26 1 12005-616 FITTING, STRT, MNPT-MUIC, 06-08 76 1 33-995-011 DECAL, VINVL, WATER FLITER TAG 27 1 12-015-666 FITTING, STRT, MNPT-MUIC, 06-06 77 1 33-995-011 DECAL, VINVL, WATER FLITER TAG </td <td>18</td> <td>3</td> <td>1</td> <td>61186988</td> <td>CLUTCH-PTO, DBL PL, SP311, SAE NO. 3 HSG</td> <td>68</td> <td>1</td> <td>33-500-003</td> <td>ASSEMBLY, CHARGE PUMP, S-300</td>	18	3	1	61186988	CLUTCH-PTO, DBL PL, SP311, SAE NO. 3 HSG	68	1	33-500-003	ASSEMBLY, CHARGE PUMP, S-300
20 1 61102636 BSHG-SPLT, IPR, QD, 3:00 IDF, AQD S2404-56 70 1 33:500-009 ASSEMBLY, HEAT EXCHANGER, HIGH FLOW, S300 21 1 61108870 KEY STK-S0, 28, STL, PLTD, AQD S24453-14 71 1 33:995-003 LABEL, PLATE, WARNING, OIL ONLY 22 1 61135228 SPRK1-14MM PTICH, 2:75 WIDE, CNITNIL 72 1 33:995-003 LABEL, PLATE, SERVICE/SUPPORT 23 1 03:001-029 BELT-3136,14MM PTICH, 2:75 WIDE, CNITNIL 74 1 33:995-010 DECAL, VINVL, WATER FLITER TAG 25 1 25:500-004 PWR END ASSY. SERIES 380, APS & AOD 75 2 33:995-011 DECAL, VINVL, DEF FLUID 26 1 12:005-0808 FITTING, STR, MPI-MJIC, 08-08 76 1 33:995-011 DECAL, VINVL, PLETER, DATE DECAL, VINVL, FLETER FAIL 27 1 12:005-0808 FITTING, STRI, MPI-MJIC, 08-08 76 1 33:995-011 DECAL, VINVL, PLETER, DATE DECAL, VINVL, FLETER FAIL 28 2 12:007-0406.B FITTING, STRI, MPI-MJIC, 08-06 77 1 33:	19	,	1	61102294	BSHG-SPLT,TPR,QD, 3.75 ID,M,AQD S25046-60	69	1	33-500-006	ASSEMBLY, RELIEF VLV MNFLD, S-300, NO ECV/PT
21 1 61108870 KEY SIK-SO, 88, STL,PLTD, ACD S24453-14 71 1 33-995-001 LABEL, PLATE, VARNING, OIL ONLY 22 1 61108820 SPRKT-14MM PTICH, 2.75 W, 168 TEEHH 72 1 33-995-003 LABEL, PLATE, SERVICE/SUPPORT 23 1 61166823 SPRKT-14MM PTICH, 2.75 W, 56 TEETH, 5 SRIES BSHG 73 1 33-995-000 LABEL, STICKER, DIESEL FUEL ONLY, 2.25 GAL 24 1 33-010-029 BELF-1316,14MM PTICH, 2.75 WIDE, CNITNIL 74 1 33-995-010 DECAL, VINYL, WATER FIFTURG 25 1 25.500-004 PWR END ASSY. SERIES 300, APS & AOD 75 2 33-995-011 DECAL, VINYL, WATER FIFTURG 26 1 12.005-1616 FITTING, STRT, MNPT-MJIC, 08-08 76 1 33-995-019 LABEL, PLATE, MODEL/SERAL, APS 28 2 12.007-424.8 FITTING, STRT, FINPL-MJIC, 06-06 77 2 3 33-995-010 DECAL, VINYL, WARNING, OIL ONLY 29 1 12-010-646.8 FITTING, STRT, FINC-HOZ, 06-06 76 1 33-995-010 DECAL, VINYL, WARNING,	20	5	1	61102636	BSHG-SPLT,TPR,QD, 3.50 ID,F,AQD S25044-56	70	1	33-500-009	ASSEMBLY, HEAT EXCHANGER, HIGH FLOW, \$300
22 1 61135228 SPRK1-14MM PTCH.2.75 W, 168 TEETH 72 1 33-995-003 LABEL, PLATE, SERVICE/SUPPORI 23 1 61166823 SPRK1-14MM PTCH.2.75 W, 56 TEETH, SERIES BSHG 73 1 33-995-020 LABEL, STICKER, DIESEL FUEL ONLY, 225 GAL 24 1 33-001-029 BELT-3136,114MM PTCH.2.75 W, 168 TEETH, SERIES BSHG 73 1 33-995-020 LABEL, STICKER, DIESEL FUEL ONLY, 225 GAL 25 1 25-500-004 PWR END ASSY- SERES 300, APS & AOD 75 2 33-995-011 DECAL, VINVL, WATER FILTER TAG 26 1 12-005-6068 FITTING, STRI, MNPT-MUIC, 06-08 76 1 33-995-019 LABEL, PLATE, MODEL/SERIAL, APS 28 2 12-007-2424.8 FITTING, STRI, FINPT-MUIC, 06-06 79 2 10-950-201 HOSE CLAMP, IV, WARING, PICH POINT 29 1 12-007-2466.8 FITTING, STRI, FJIC-HOSE, 16-16.8 80 3 10-960-201 HOSE CLAMP, IV, WORN DR, 7/16 - 25/32, SI N WD 31 5 12-027-1666.8 FITTING, STRI, FJIC-HOSE, 16-16.8 81 1 9-013-020 <td< td=""><td>21</td><td>1</td><td>1</td><td>61108870</td><td>KEY STK-SQ, 88, STL, PLTD, AQD S24453-14</td><td>71</td><td>1</td><td>33-995-001</td><td>LABEL, PLATE, WARNING, OIL ONLY</td></td<>	21	1	1	61108870	KEY STK-SQ, 88, STL, PLTD, AQD S24453-14	71	1	33-995-001	LABEL, PLATE, WARNING, OIL ONLY
23 1 61166823 SPRK1-14MM PTCH, 2.75W, 56 TEETH,F SERIES BSHG 73 1 33.995-020 LABEL, STICKER, DISSEL FUEL ONLY, 225 GAL 24 1 33.001-029 BELT-3136, 14MM PTCH, 2.75 WIDE, CNTNTL 74 1 33.995-010 DECAL, VINYL, WATER FILTER TAG 25 1 25-500-004 PWR END ASSY-SERES 300, APS & AOD 75 2 33.995-011 DECAL, VINYL, PLTER, PARTICULATE REMOVAL 26 1 12-005-0608 FITTING, STRT, MNPT-MJIC, 08-08 76 1 33.995-011 DECAL, VINYL, FLTER, PARTICULATE REMOVAL 27 1 12-007-2424.B FITTING, STRT, MNPT-MJIC, 06-06 77 2 10-950-201 HOSE CLAWP, TRODEL/SERIAL, APS 28 2 12-007-2424.B FITTING, STRT, FNPT-MJIC, 06-06 79 2 10-950-201 HOSE CLAWP, TRODEL, TSTAINLESS, 2-1/8' OD 30 3 12-027-060.B FITTING, STRT, FJIC-HOSE, 16-16.B 81 1 99-013-020 ROUTING CLAWP, 1-5/16' ID, ZINC STEEL 33 1 12-033-0604 FITTING, 90, MNPT-FNPT, 24-24.B 82 1 99-013-021 ROUTIN	22	2	1	61135228	SPRKT-14MM PITCH,2.75 W,168 TEETH	72	1	33-995-003	LABEL. PLATE, SERVICE/SUPPORT
24 1 33:001-029 BELT-3136,14MM PITCH, 2.75 WIDE, CNTNTL 74 1 33:995-010 DECAL, VINYL, WATER FILTER TAG 25 1 25:500-004 PWR END ASSY-SERIES 300, APS & AQD 75 2 33:995-011 DECAL, VINYL, DEF FLUID 26 1 12:005-0808 FITTING, STRT, MMPT-MJIC, 08:08 76 1 33:995-014 DECAL, VINYL, PLTE, PARTICULATE REMOVAL 27 1 12:005-1616 FITTING, STRT, MNPT-MJIC, 06:06 77 1 33:995-019 LABEL, PLATE, MODEL/SERIAL, APS 28 2 12:007-2424.8 FITTING, STRT, FNIC-MIC, 06:06 78 3 33:995-021 DECAL, VINYL, WARNING, PINCH POINT 29 1 12:010-666 FITTING, STRT, FNIC-MIC, 06:06 79 1 0-950-201 HOSE CLAMP, TADLT, STAINLESS, 2-1/8' O D 31 5 12:027-1616.8 FITTING, STRT, FNIC-MIC, 06:06 80 3 10:960-006 HOSE CLAMP, TADLT, STAINLESS, 2-1/8' O D 33 1 12:027-1616.8 FITTING, 90, MNPT-MIC, 06:04 83 1 11:001-011 ENCLOSURE, BATTERY, 13M, (ALSO A-9407)	23	3	1	61166823	SPRKT-14MM PITCH, 2.75W, 56 TEETH, F SERIES BSHG	73	1	33-995-020	LABEL, STICKER, DIESEL FUEL ONLY, 225 GAL
25 1 25:50:004 PWR END ASSY-SERIES 300, APS & AQD 75 2 33:995-011 DECAL, VINYL, DEF FLUID 26 1 12:005-0808 FITTING, STRT, MNPT-MJIC, 08:08 76 1 33:995-014 DECAL, VINYL, FLIER, PARTICULATE REMOVAL 27 1 12:005-1616 FITTING, STRT, MNPT-MJIC, 16:16 77 1 33:995-014 DECAL, VINYL, FLIER, PARTICULATE REMOVAL 28 2 12:007-2424.8 FITTING, STRT, MNPT-MJIC, 06:06 79 2 10:950-201 HOSE CLAMP, T-BOLT, STAINLESS, 2:1/8' OD 30 3 12:027-0606.8 FITTING, STRT, FJIC-HOSE, 06:06.8 80 3 10:950-201 HOSE CLAMP, T-BOLT, STAINLESS, 2:1/8' OD 31 5 12:027-1616.8 FITTING, STRT, FJIC-HOSE, 16:16.8 81 1 99:013:021 ROUTING CLAMP, 1:5/16' ID, ZINC STEEL 32 1 12:032-2424.8 FITTING, 90, MNPT-MJIC, 08:04 83 1 11:001:011 ENCLOSURE, BATTERY, 31M, (ALSO A:9407) 34 1 12:033-804 FITTING, 90, MNPT-MJIC, 08:04 83 1 11:001:011 ENCLOSURE, BATTERY, 31M, (24	4	1	33-001-029	BELT-3136,14MM PITCH, 2.75 WIDE, CNTNTL	74	1	33-995-010	DECAL, VINYL, WATER FILTER TAG
26 1 12:005-0808 FITTING, STRT, MNPT-MJIC, 08:08 76 1 33:995-014 DECAL, VINYL, FILTER, PARTICULATE REMOVAL 27 1 12:005-1616 FITTING, STRT, MNPT-MJIC, 16:16 77 1 33:995-019 LABEL, PLATE, MODEL/SERIAL, APS 28 2 12:007-2424.B FITTING, STRT, MNPT-HOSE, 24:24.B 78 3 33:995-021 DECAL, VINYL, WARNING, PINCH POINT 29 1 12:011-0606 FITTING, STRT, FNPT-MJIC, 06:06 79 2 10:950-201 HOSE CLAMP, FBOLT, STAINLESS, 2:18' OD 30 3 12:027-0606.B FITTING, STRT, FNPT-MJIC, 06:06 80 3 10:960-006 HOSE CLAMP, WORM DR, 7/16: 25;23, S IN WD 31 5 12:027-1616.B FITTING, STRT, FJC-HOSE, 16:16.B 81 1 99:013-020 ROUTING CLAMP, 1-5/16'ID, ZINC STEEL 32 1 12:030-2424.B FITTING, 90, MNPT-MJIC, 08:04 83 1 11:001-011 ENCLOSURE, BATTERY, 31M, (ALSO A:9407) 34 1 12:033-0804 FITTING, 90, MARFI-MJIC, 16:16 84 1 11:001-011 ENCLOSURE, BATTERY, BLX,	25	5	1	25-500-004	PWR END ASSY- SERIES 300, APS & AQD	75	2	33-995-011	DECAL, VINYL, DEF FLUID
27 1 12-005-1616 FITTING, STRT, MNPT-MJIC, 16-16 77 1 33-995-019 LABEL, PLATE, MODEL/SERIAL, APS 28 2 12-007-2424.B FITTING, STRT, MNPT-MJIC, 06-06 79 2 10-950-201 HOSE CLAMP, T-BOLT, STAINLESS, 2-1/8° OD 30 3 12-027-0606.B FITTING, STRT, FNPT-MJIC, 06-06 79 2 10-950-201 HOSE CLAMP, T-BOLT, STAINLESS, 2-1/8° OD 31 5 12-027-0606.B FITTING, STRT, FJIC-HOSE, 66-06.B 80 3 10-960-006 HOSE CLAMP, WORM DR, 7/16 - 25/32, 5 IN WD 31 5 12-027-1616.B FITTING, 90, MNPT-FNPT, 24-24.B 81 1 99-013-020 ROUTING CLAMP, 11/16'ID, ZINC STEEL 33 1 12-033-0804 FITTING, 90, MNPT-MJIC, 16-16 84 1 11-001-011 ENCLOSURE, BATTERY, 31M, (ALSO A.9407) 34 1 12-033-1616 FITTING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SOZ BCKL, 2° WD, 8FT LG, NYLON 36 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 11-005-011 CABLE, BATTERY, 8L	26	5	1	12-005-0808	FITTING, STRT, MNPT-MJIC, 08-08	76	1	33-995-014	DECAL, VINYL, FILTER, PARTICULATE REMOVAL
28 2 12-007-2424.B FITTING, STRT, MNPT-HOSE, 24-24.B 78 3 33-995-021 DECAL, VINYL, WARNING, PINCH POINT 29 1 12-011-0606 FITTING, STRT, FNPT-MJIC, 06-06 79 2 10-950-201 HOSE CLAMP, T-BOLT, STAINLESS, 2-1/8' OD 30 3 12-027-0606.B FITTING, STRT, FJIC-HOSE, 06-06.B 80 3 10-960-006 HOSE CLAMP, WORM DR, 7/16 - 25/32, .5 IN WD 31 5 12-027-1616.B FITTING, STRT, FJIC-HOSE, 16-16.B 81 1 99-013-021 ROUTING CLAMP, 1-5/16' ID, ZINC STEEL 32 1 12-033-0804 FITTING, 90, MNPT-MJIC, 08-04 83 1 11-001-011 ENCLOSURE, BATTERY, 31M, (ALSO A-9407) 34 1 12-033-1616 FITTING, 90, MNPT-MJIC, 16-16 84 1 11-001-016 BATTERY, 12V, 31M, 1000 CCA (A-9338) 35 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2* WD, 8F1 LG, NYLON 36 1 12-044-1616 FITTING, 90, MSAE-MJIC, 12-12 85 1 91-050-012 CABLE, BATTERY,	27	7	1	12-005-1616	FITTING, STRT, MNPT-MJIC, 16-16	77	1	33-995-019	LABEL, PLATE, MODEL/SERIAL, APS
29 1 12.011.0606 FIITING, STRT, FNPT-MJIC, 06-06 79 2 10.950.201 HOSE CLAMP, I-BOLT, STAINLESS, 2-1/8' OD 30 3 12.027.0606.B FIITING, STRT, FJIC-HOSE, 06-06.B 80 3 10.960-006 HOSE CLAMP, I-BOLT, STAINLESS, 2-1/8' OD 31 5 12.027.0616.B FIITING, STRT, FJIC-HOSE, 16-16.B 81 1 99.013-020 ROUTING CLAMP, 1-5/16' ID, ZINC STEEL 32 1 12.030-2424.B FIITING, 90, MNPT-MJIC, 08-04 83 1 11.001-011 ENCLOSURE, BATTERY, 31M, (ALSO A-9407) 34 1 12.033-0804 FIITING, 90, MNPT-MJIC, 16-16 84 1 11.001-016 BATTERY, 12V, 31M, (1000 CCA (A-9338) 35 1 12.044-1212 FIITING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2''WD, 8FT LG, NYLON 36 1 12.044-1212 FIITING, 90, MSAE-MJIC, 16-16 86 1 11-005-011 CABLE, BATTERY, BLX, 2/0, 3/8 RNG, 72' LG 37 1 12.102-0606 RUN TEE, MJIC-MJIC-FNPT, 06-06-06 87 1 11-005-011 CABLE, BATT	28	3	2	12-007-2424.B	FITTING, STRT, MNPT-HOSE, 24-24.B	78	3	33-995-021	DECAL, VINYL, WARNING, PINCH POINT
30 3 12-027-0606.B FITTING, STRT, FJIC-HOSE, 06-06.B 80 3 10-960-006 HOSE CLAMP, WORM DR, 7/16 - 25/32, 5 IN WD 31 5 12-027-1616.B FITTING, STRT, FJIC-HOSE, 16-16.B 81 1 99-013-020 ROUTING CLAMP, 1-5/16' ID, ZINC STEEL 32 1 12-030-2424.B FITTING, 90, MNPT-FNPT, 24-24.B 82 1 99-013-021 ROUTING CLAMP, 11/16'ID, ZINC STEEL 33 1 12-033-0804 FITTING, 90, MNPT-MJIC, 08-04 83 1 11-001-011 ENCLOSURE, BATTERY, 31M, (ALSO A-9407) 34 1 12-033-1616 FITTING, 90, MNPT-MJIC, 16-16 84 1 11-001-016 BATTERY, 12V, 31M, 1000 CCA (A-9338) 35 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2' WD, 8FT LG, NYLON 36 1 12-044-1616 FITTING, 90, MSAE-MJIC, 16-16 86 1 11-005-011 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72° LG 37 1 12-044-1616 FITTING, 90, MSAE-MJIC, 16-16 86 1 11-005-013 CABLE, BATTERY, BLK	29	,	1	12-011-0606	FITTING, STRT, FNPT-MJIC, 06-06	79	2	10-950-201	HOSE CLAMP, T-BOLT, STAINLESS, 2-1/8" OD
31 5 12-027-1616.B FITTING, STRT, FJIC-HOSE, 16-16.B 81 1 99-013-020 ROUTING CLAMP, 1-5/16* ID, ZINC STEEL 32 1 12-030-2424.B FITTING, 90, MNPT-FNPT, 24-24.B 82 1 99-013-021 ROUTING CLAMP, 11/16*ID, ZINC STEEL 33 1 12-033-0804 FITTING, 90, MNPT-MJIC, 08-04 83 1 11-001-011 ENCLOSURE, BATTERY, 31M, (ALSO A-9407) 34 1 12-033-1616 FITTING, 90, MNPT-MJIC, 16-16 84 1 11-001-016 BATTERY, 12V, 31M, (ALSO A-9407) 35 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2* WD, 8FT LG, NYLON 36 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 11-005-011 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72* LG 37 1 12-102-0606 RUN TEE, MJIC-MJIC-FNPT, 06-06-06 87 1 11-005-012 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72* LG 38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, RED, 4GA, 3/8	30	5	3	12-027-0606.B	FITTING, STRT, FJIC-HOSE, 06-06.B	80	3	10-960-006	HOSE CLAMP, WORM DR. 7/16 - 25/32, .5 IN WD
32 1 12-030-2424.8 FIITING, 90, MNPT-FNPT, 24-24.8 82 1 99-013-021 ROUTING CLAMP, 11/16'ID, ZINC STEEL 33 1 12-033-0804 FIITING, 90, MNPT-MJIC, 08-04 83 1 11-001-011 ENCLOSURE, BATTERY, 31M, (ALSO A-9407) 34 1 12-033-1616 FIITING, 90, MNPT-MJIC, 16-16 84 1 11-001-016 BATTERY, 12V, 31M, 1000 CCA (A-9338) 35 1 12-044-1212 FIITING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2'' WD, 8FT LG, NYLON 36 1 12-044-1616 FIITING, 90, MSAE-MJIC, 12-12 85 1 11-05-011 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72'' LG 37 1 12-02-0606 RUN TEE, MJIC-MJIC-FNPT, 06-06-06 87 1 11-05-011 CABLE, BATTERY, BLK, 4GA, 3/8 RNG, 108' LG 38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-05-013 CABLE, BATTERY, RED, 2/0, 3/8 RNG, 108'' LG 39 2 12-250-1600 PLUG, MNPT, HOLLOW HEX, 16 90 1 13-500-007 KIT-HOSE, S300, BASE, HYD, CR	31	1	5	12-027-1616.B	FITTING, STRT, FJIC-HOSE, 16-16.B	81	1	99-013-020	ROUTING CLAMP, 1-5/16" ID, ZINC STEEL
33 1 12-033-0804 FITTING, 90, MNPT-MJIC, 08-04 83 1 11-001-011 ENCLOSURE, BATTERY, 31M, (ALSO A-9407) 34 1 12-033-1616 FITTING, 90, MNPT-MJIC, 16-16 84 1 11-001-016 BATTERY, 12V, 31M, 1000 CCA (A-9338) 35 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2* WD, 8FT LG, NYLON 36 1 12-044-1616 FITTING, 90, MSAE-MJIC, 16-16 86 1 11-005-011 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72* LG 37 1 12-102-0606 RUN TEE, MJIC-MJIC-FNPT, 06-06-06 87 1 11-005-012 CABLE, BATTERY, RED, 2/0, 3/8 RNG, 72* LG 38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, BLK, 4GA, 3/8 RNG, 108* LG 39 2 12-250-1600 PLUG, MNPT, 16 89 1 11-005-014 CABLE, BATTERY, RED, 2/0, 3/8 RNG, 108* LG 40 1 12-250-2000 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 42 1 12-250-2400 PLUG, MNPT, 24 <	32	2	1	12-030-2424.B	FITTING, 90, MNPT-FNPT, 24-24.B	82	1	99-013-021	ROUTING CLAMP, 11/16"ID, ZINC STEEL
34 1 12-033-1616 FITTING, 90, MNPT-MJIC, 16-16 84 1 11-001-016 BATTERY, 12V, 31M, 1000 CCA (A-9338) 35 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2" WD, 8FT LG, NYLON 36 1 12-044-1616 FITTING, 90, MSAE-MJIC, 16-16 86 1 11-005-011 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72" LG 37 1 12-102-0606 RUN TEE, MJIC-MJIC-FNPT, 06-06-06 87 1 11-005-012 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72" LG 38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, BLK, 4GA, 3/8 RNG, 108" LG 39 2 12-250-1600 PLUG, MNPT, 16 89 1 11-005-014 CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108" LG 40 1 12-250-1605 PLUG, MNPT, HOLLOW HEX, 16 90 1 13-016-2000.8LU HOSE, PUSH-LOK, -16, 175 PSI, BLU 41 1 12-250-2000 PLUG, MNPT, 20 91 44 IN 13-016-2000.8LU HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW	33	3	1	12-033-0804	FITTING, 90, MNPT-MJIC, 08-04	83	1	11-001-011	ENCLOSURE, BATTERY, 31M, (ALSO A-9407)
35 1 12-044-1212 FITTING, 90, MSAE-MJIC, 12-12 85 1 99-050-005 STRAP, CINCH, SQZ BCKL, 2" WD, 8FT LG, NYLON 36 1 12-044-1616 FITTING, 90, MSAE-MJIC, 16-16 86 1 11-005-011 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72" LG 37 1 12-102-0606 RUN TEE, MJIC-MJIC-FNPT, 06-06-06 87 1 11-005-012 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72" LG 38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, BLK, 4GA, 3/8 RNG, 108" LG 39 2 12-250-1205 PLUG, MNPT, 16 89 1 11-005-014 CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108" LG 40 1 12-250-1605 PLUG, MNPT, 16 89 1 11-005-014 CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108" LG 41 1 12-250-1605 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, PUSH-LOK, -16, 175 PSI, BLU 42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW	34	4	1	12-033-1616	FITTING, 90, MNPT-MJIC, 16-16	84	1	11-001-016	BATTERY, 12V, 31M, 1000 CCA (A-9338)
36 1 12-044-1616 FITTING, 90, MSAE-MJIC, 16-16 86 1 11-005-011 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72° LG 37 1 12-102-0606 RUN TEE, MJIC-MJIC-FNPT, 06-06-06 87 1 11-005-012 CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72° LG 38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, BLK, 4GA, 3/8 RNG, 108° LG 39 2 12-250-1600 PLUG, MNPT, 16 89 1 11-005-014 CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108° LG 40 1 12-250-1605 PLUG, MNPT, HOLLOW HEX, 16 90 1 13-500-007 KIT-HOSE, S300, BASE, HYD, CRMP 41 1 12-250-2000 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, FUEL, PUSH-LOK, -16, 175 PSI, BLU 42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY 44 6 10-416-050 BOLT, HEX, 1/4"-20 X 3/4"	35	5	1	12-044-1212	FITTING, 90, MSAE-MJIC, 12-12	85	1	99-050-005	STRAP, CINCH, SQZ BCKL, 2" WD, 8FT LG, NYLON
37 1 12-102-0606 RUN TEE, MJIC-FMPT, 06-06-06 87 1 11-005-012 CABLE, BATTERY, RED, 2/0, 3/8 RNG, 72° LG 38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, RED, 2/0, 3/8 RNG, 108° LG 39 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108° LG 40 1 12-250-1605 PLUG, MNPT, HOLLOW HEX, 16 90 1 13-500-007 KIT-HOSE, S300, BASE, HYD, CRMP 41 1 12-250-2400 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, FUEL, PUSH-LOK, -16, 175 PSI, BLU 42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 44 6 10-416-050 BOLT, HEX, 1/4*-20 X 3/4* HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 45 2 90-008-075 BOLT, HEX, 3/8*-16 X 1* HEX <td>36</td> <td>5</td> <td>1</td> <td>12-044-1616</td> <td>FITTING, 90, MSAE-MJIC, 16-16</td> <td>86</td> <td>1</td> <td>11-005-011</td> <td>CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72" LG</td>	36	5	1	12-044-1616	FITTING, 90, MSAE-MJIC, 16-16	86	1	11-005-011	CABLE, BATTERY, BLK, 2/0, 3/8 RNG, 72" LG
38 2 12-250-1205 PLUG, MNPT, HOLLOW HEX, 12 88 1 11-005-013 CABLE, BATTERY, BLK, 4GA, 3/8 RNG, 108° LG 39 2 12-250-1600 PLUG, MNPT, 16 89 1 11-005-014 CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108° LG 40 1 12-250-1605 PLUG, MNPT, HOLLOW HEX, 16 90 1 13-500-007 KIT-HOSE, S300, BASE, HYD, CRMP 41 1 12-250-2000 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, PUSH-LOK, -16, 175 PSI, BLU 42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY 44 6 10-416-050 BOLT, HEX, 1/4°-20 X 3/4° 46 6 90-012-100 BOLT, HEX, 3/8°-16 X 1° 10	37	7	1	12-102-0606	RUN TEE, MJIC-MJIC-FNPT, 06-06-06	87	1	11-005-012	CABLE, BATTERY, RED, 2/0, 3/8 RNG, 72" LG
39 2 12-250-1600 PLUG, MNPT, 16 89 1 11-005-014 CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108° LG 40 1 12-250-1605 PLUG, MNPT, HOLLOW HEX, 16 90 1 13-500-007 KIT-HOSE, S300, BASE, HYD, CRMP 41 1 12-250-2000 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, PUSH-LOK, -16, 175 PSI, BLU 42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY 44 6 10-416-050 BOLT, HEX, M10X 50MM, CLASS 10.9 45 2 90-008-075 BOLT, HEX, 3/8°-16 X 1° 46 6 90-012-100 BOLT, HEX, 3/8°-16 X 1°	38	3	2	12-250-1205	PLUG, MNPT, HOLLOW HEX, 12	88	1	11-005-013	CABLE, BATTERY, BLK, 4GA, 3/8 RNG, 108" LG
40 1 12-250-1605 PLUG, MNPT, HOLLOW HEX, 16 90 1 13-500-007 KIT-HOSE, S300, BASE, HYD, CRMP 41 1 12-250-2000 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, PUSH-LOK, -16, 175 PSI, BLU 42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 44 6 10-416-050 BOLT, HEX, M10X 50MM, CLASS 10.9 HOSE, PUSH-LOK, -6, 300 PSI, YLW 45 2 90-008-075 BOLT, HEX, 1/4*-20 X 3/4* HEX. 46 6 90-012-100 BOLT, HEX, 3/8*-16 X 1* HEX.	39	,	2	12-250-1600	PLUG, MNPT, 16	89	1	11-005-014	CABLE, BATTERY, RED, 4GA, 3/8 RNG, 108" LG
41 1 12-250-2000 PLUG, MNPT, 20 91 44 IN 13-016-2000.BLU HOSE, PUSH-LOK, -16, 175 PSI, BLU 42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY 44 6 10-416-050 BOLT, HEX, M10X1.5MM X 50MM, CLASS 10.9 45 2 90-008-075 BOLT, HEX, 1/4*-20 X 3/4* 46 6 90-012-100 BOLT, HEX, 3/8*-16 X 1*	40	5	1	12-250-1605	PLUG, MNPT, HOLLOW HEX, 16	90	1	13-500-007	KIT-HOSE, S300, BASE. HYD. CRMP
42 1 12-250-2400 PLUG, MNPT, 24 92 95 IN 13-006-2000.YLW HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 44 6 10-416-050 BOLT, HEX, M10X1.5MM X 50MM, CLASS 10.9 HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 45 2 90-008-075 BOLT, HEX, 1/4"-20 X 3/4" HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW 46 6 90-012-100 BOLT, HEX, 3/8"-16 X 1" HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YLW	41	1	1	12-250-2000	PLUG, MNPT, 20	91	44 IN	13-016-2000.BLU	HOSE, PUSH-LOK,-16, 175 PSI, BLU
43 2 10-410-035 BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY 44 6 10-416-050 BOLT, HEX, M10X1.5MM X 50MM, CLASS 10.9 45 2 90-008-075 BOLT, HEX, 1/4"-20 X 3/4" 46 6 90-012-100 BOLT, HEX, 3/8"-16 X 1"	42	2	1	12-250-2400	PLUG, MNPT. 24	92	95 IN	13-006-2000 YI W	HOSE, FUEL, PUSH-LOK, -6, 300 PSI, YI W
44 6 10-416-050 BOLT, HEX HEAD, M16 X 2MM X 50MM, CLASS 10.9 45 2 90-008-075 BOLT, HEX, 1/4"-20 X 3/4" 46 6 90-012-100 BOLT, HEX, 3/8"-16 X 1"	43	3	2	10-410-035	BOLT, HEX, M10X1.5MM X 35MM, 10.9 ALLOY	_			
45 2 90-008-075 BOLT, HEX, 1/4"-20 X 3/4" 46 6 90-012-100 BOLT, HEX, 3/8"-16 X 1"	44	4	6	10-416-050	BOLT, HEX HEAD, M16 X 2MM X 50MM. CLASS 10.9				
46 6 90-012-100 BOLT, HEX, 3/8"-16 X 1"	45	5	2	90-008-075	BOLT, HEX, 1/4"-20 X 3/4"				
	46	5	6	90-012-100	BOLT, HEX, 3/8"-16 X 1"				

90-012-125

90-016-100

90-016-125

90-017-125

47

48

49

50

В

_

12

4

6

4

BOLT, HEX, 3/8"-16 X 1-1/4"

BOLT, HEX, 1/2"-13 X 1"

BOLT, HEX, 1/2"-13 X 1-1/4"

BOLT, HEX, 1/2"-20 X 1-1/4"



						APS AND THE APS LOGO ARE E REGISTERED TRADEMARKS OR TRA	either .dfmarks		UNLESS OTHER ALL DIMENSION	WISE SPECIFIED IS ARE IN INCHES	TITLE:
А						OF SHAPE TECHNOLOGIES INC.	. IN THE	DI BF	VI'S IN [mm] ARE REAK SHARP EDC	E REFERENCE ONLY GES & DEBURR .015	
						UNITED STATES AND/OK UTTER CO		TOLER	ances (ex	(CEPT AS NOTED)	THIRD ANG
			REVISIONS			THIS DOCUMENT CONTAINS CONFIDENTIAL		SURFACE FINISH	63/	DIM TOLERANCES: (in)	DWG BY
ZONE	E REV.		DESCRIPTION	DATE	APPROVED	DISCLOSED TO OTHERS FOR ANY PURPOS FOR MANUFACTURING PURPOSES WITHO	SE NOR USED	MACHINE FILLETS	R.02	$.X = \pm .003$ $.XX = \pm .015$	
	0		INITIAL RELEASE	5/1/2020	K. SMITH	PERMISSION FROM ADVANCED PRESSUR	RE SYSTEMS.	ANGLE	±1°	$.XXX = \pm .005$ $.XXXX = \pm .0005$	
	8	8	7	6		5		4		3	



Ε

D

С

А



3





4

						APS AND THE APS LOG REGISTERED TRADEMARKS OF SHAPE TECHNOLOG	o are either or trademarks ies inc. in the	L Al IN DIM	UNLESS OTHER LL DIMENSION: NTERPRET PER / 'S IN [mm] ARE	WISE SPECIFIED S ARE IN INCHES ANSI Y14.5-2009 : REFERENCE ONLY SES & DEBUBL 015	TITLE:
			REVISIONS			UNITED STATES AND/OR O THIS DOCUMENT CONTAINS CONF WHICH MAY BE CONTROLLED	IHER COUNTRIES	TOLERA SURFACE FINISH	NCES (EX	CEPT AS NOTED) DIM TOLERANCES: (in) .X = ± .063	THIRD ANC
ZONE	REV.		DESCRIPTION	DATE APP	ROVED	DISCLOSED TO OTHERS FOR ANY FOR MANUFACTURING PURPOS	PURPOSE NOR USED	FILLETS	R.02	.XX = ± .015	APRVD BY
	0		INITIAL RELEASE	5/1/2020 K.	SMITH	PERMISSION FROM ADVANCED	PRESSURE SYSTEMS.	ANGLE	±1°	$.XXX = \pm .005$ $.XXXX = \pm .0005$	
	8	}	7	6		5	1	4		3	

5

APS S-300 - TIER 4 C7.1 (BASE UNIT) PART NUMBER: 32-500-000 5,000 - 40,000 PSI FLUID END OPTIONS ASSEMBLED BY ADVANCED PRESSURE SYSTEMS, TOMBALL, TX. PRIME MOVER: CAT TIER 4 C7.1 DIESEL ENGINE ESTIMATED WEIGHT: 8,000 LBS. (DRY) NOISE EMMISSION: 105 dBA @ 3 FT. @ 2100 ENGINE RPM OIL CAPACITY: 40 GALLONS FUEL CAPACITY: 25 GALLONS / USE DIESEL FUEL ONLY DEF CAPACITY: 8.5 GALLONS MAX FUEL CONSUMPTION: 13 GAL./HOUR











						GO ARE EITHER		UNLESS OTHE ALL DIMENSIO	ERWISE SPECIFIED	TITLE:
д						GIES INC. IN THE		DIM'S IN [mm] AI BREAK SHARP EE	RE REFERENCE ONLY DGES & DEBURR .015	
							TOLE	rances (e	XCEPT AS NOTED)	THIRD ANG
		REVISIONS				FIDENTIAL INFORMATION	SURFACE FINISH	63/	DIM TOLERANCES: (in)	DWG BY
ZO	NE REV.	DESCRIPTION	DATE	APPROVED	DISCLOSED TO OTHERS FOR AN FOR MANUFACTURING PURPOS	Y PURPOSE NOR USED SES WITHOUT WRITTEN	MACHINE FILLETS	R.02	$.X = \pm .003$ $.XX = \pm .015$	
	0	INITIAL RELEASE	5/1/2020	K. SMITH	PERMISSION FROM ADVANCE	D PRESSURE SYSTEMS.	ANGLE	±1°	$.XXX = \pm .005$ $.XXXX = \pm .0005$	
	8	7	6		5	Ť	4		3	

R



Е

D

-0

С

А





	8	7	6	5	Ļ	4			3		2		1	
					•		REF. NO	HOSE SIZE	FITTING 1	LOCATION FROM	FITTING 2	LOCATION TO	EST. OAL	COLOR
		\sim		r					I	WATER	HOSE PLAN			
				<u>r</u>	USH-LOK HOSE PLAN		[1]	-16	12-027-1616.B	CHARGE PUMP OUTLET	12-027-1616.B	HEAT EXCHANGER INLET	30 IN.	BLUE
							[2]	-16	12-027-1616.B	HEAT EXCHANGER OUTLET	12-027-1616.B	WATER FILTER INLET	15 IN	BLUE
		000							•	DIESEL	HOSE PLAN	·		F
F							[3]	-6	10-960-006	DIESEL COOLER	12-027-0606.B	DIESEL TANK	40 IN.	YELLOW
							[4]	-6	10-960-006	DIESEL RETURN	12-027-0606.B	DIESEL TANK	35 IN.	YELLOW
							[5]	-6	10-960-006	DIESEL SUCTION	12-027-0606.B	DIESEL TANK	20 IN.	YELLOW
	90													
_														_
				A market and the second										
E														F
				1 me										
	The second			00 00 00 00 00						\sim				
	BALF				- Company				6					
				00000										
											A - A - A - A - A - A - A - A - A - A -			
					8									
														C
					0 0									
	3-6				0									
					G			\geq			and a	0		
				0 0					1 Aller		Ka T	10		
•											- AL			•
					(3			H	ALA					
								-						
	(1)	$\overline{2}$												
	r -			- - -		7 /								
				an										
	0				40				- PA					
_	•				2									
							D. H. P.	Ð						
											9			
								122						
	▏Ĺ▁╜║──							7						
В							/				~			В
													0 0	
							(2)	11(1(D)						
	L <u>L</u>			U			(12-02)	/-1010.B)—	_					
1	(3)	$\sqrt{5}$								<u> </u>				
					F APS LOGO ARF FITHER	UNLESS O	THERWISE SPECI	IFIED	TITLE:			-5300 RASE		
				REGISTERED TRA	DEMARKS OR TRADEMARKS	ALL DIMEN INTERPRET	PER ANSI Y14.5-	-2009						
А					CHNOLOGIES INC. IN THE	DIM'S IN [mm BREAK SHARI	I ARE REFERENC	JRR .015		ADVANCE 701 S. PERSIMMON DR	D PRESSURE SYSTEMS . TOMBALL, TX 77375		C	A
					THE COUNTRIES	TOLERANCES	(EXCEPT A	AS NOTED)	THIRD	ANGLE PROJECTION	$\oplus = 1$			DOUDE
		REVISIONS		THIS DOCUMENT COM	NTAINS CONFIDENTIAL INFORMATION	SURFACE 63/	DIM TO	olerances			¥		CHNOLOGIES G	ROUP
	RE//		ΠΔΤΕ		CONTROLLED AND IS NOT TO BE HERS FOR ANY PURPOSE NOR USED	MACHINE R.02	X. XX.	= ± .06 = ± .01	5	K. SMIT	1	DWG. NO. 37-5	00-00	REV.
	0	INITIAL RELEASE	5/1/2020	K. SMITH	AING PURPOSES WITHOUT WRITTEN A ADVANCED PRESSURE SYSTEMS.	ANGLE ±1°	.XXX .XXX	$x = \pm .00$ $x = \pm .00$	5 APRVD B	B. PARK	ER	MATL.		
L	8	7	6	5	↑	4		± .00	3		2		1	



			8	7
	ITEM NO.	QTY.	PART NO.	DESCRIPTION
	1	1	61102112	MANF-SUCT,SPLT BLK,HP,GA-GB
	2	1	61102062	MANF-DISCH, SERIES 250, HP
	3	12	90-026-500	BOLT, HEX, 1"-8 X 5"
	4	8	90-028-550	BOLT, HEX, 1-1/4"-7 X 5-1/2"
E	5	3	25-500-316	ASSY-LP PKG, HP, 1.00"
1	6	3	61113085	NUT-INTER ROD, SERIES 250 , NEW STYLE, AQD B05064-09
	7	3	61103088	CLT-PLGR, 1.0, HP, GA & GB
	8	3	25-500-108	ROD-PONY, \$300, 0.75"-1.38"
	9	3	61119654	SPACER - SPLIT BLOCK TYPE - ALL H/P
	10	3	25-500-106	RTNR-PKG, S300, 0.75"-1.13"
_	11	3	25-500-216	ASSY-HP PKG, HP, 1.00"
	12	3	25-500-102	BARL-S300, HP, 0.75"-1.38"
ŀ	13	3	61115064	PLGR-PMP, 1.0X10.00, CERAMIC
	14	3	61119662	SPACER, SPRING GA, GB, W200-HP, DIAM 1"
	15	3	61120529	SPR-SUCT,SST
Е	16	3	61122827	VLV-SUCT,GA,GB AND GE SERIES
	17	9	61117350	SEAL-CPRSN,2.125X1.750
	18	3	61122760	GDE-VLV,DISCH,GA & C SERIES,HP
	19	3	10183168	O RNG-152,3.25X3.44X.09, BN-N,D-70
	20	3	61119152	SEAT-VLV,HP BARREL,GA,GB,GE&W 200
	21	3	61115907	RNG-RTNG,INT,1.437
_	22	12	90-826-000	FLAT WASHER, 1"
	23	3	61121942	VLV-DISCH,GA-HP
	24	3	61120339	SPR-CPRSN, .48 X 1.5, SST, AQD S24139-06
	25	3	61117835	O RNG-145,2.56X2.75X.09, BN-N,D-70,AQD \$29145-00
	26	3	30-002-150	O-RING, 2-150 BUNA-N 70 DURO
D				

->

С

В

	6		5 🛓	4	3 2	1	-
<complex-block></complex-block>							
<image/>							
<complex-block></complex-block>							F
<image/>					\sim		
					V V		
						\sim	E
		\langle					
				A A A CONTRACT			
	F						D
					He A		
					þ		
							7
APPROVED The APP LOGO ARE EITHER BODINGS TO HEAPS LOGO ARE EITHER UNITED RADEWARKS ON READBARKS OF SHAFE REATING COMPRESS ON READBARKS OF SHAFE READBARKS ON READBARKS ON SHAFE READBARKS ON READBARKS ON READBARKS ON SHAFE READBARKS ON READBARKS ON READBARKS ON SHAFE READBARKS ON READBARKS ON READBARKS ON READBARKS ON SHAFE READBARKS ON READBARKS ON READBARKS ON SHAFE READBARKS ON READBARKS ON READBARKS ON READBARKS ON READBARKS ON SHAFE READBARKS ON READBARKS ON READBARKS ON READBARKS ON R							
APS AND THE APS LOGO ARE ETITERY CONSISTENCED TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO ARE ETITERY UNDERVICE TRADEMARS ON TRADEMARS OF SHAPE TECHNOLOGIES AND THE APS LOGO AND THE APPROVED THE APPROV							С
APS AND THE APS LOGO ARE EITHER PEOSISTREED TRADE-MARKS OF TRADE-MARKS DIATES AND/OR OTHER STOR ANY THEOREM NOT THE MARKET REAL STORES STORES ANY THEOREM NOT THE TABLE AND/OR OTHER COUNDERTS AND THE COUNTRIES INSTANDARY OF THE COUNTRIES INSTANT THE COUNTRIES INSTANT THE COUNTRIES IN THE COUNTRIES INSTANT THE COUNTRIES IN THE COUNTRIES IN THE COUNTRIES INSTANT THE COUNTRIES INTO THE COUNTRIES		-					
APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OF TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES DATE Image: States and/or s							
APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OR TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER CONTROLET INLESCODEENCE STOCES AULADYNE SERIES SD CONNECTOR Material Information SUBSPACE SUBSPACE SUBSPACE INC. MATERIAL INFORMATION DE INFORMATION DOT SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER CONTROLET SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSPACE SUBSP				O_{0}			
APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OR TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES INLERS OTHERWSE SPECIFIER ALL DIMENSION ARE IN INCIDES UNITED STATES AND/OR OTHER COUNTRIES ITTLE: FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD MACHINE REGISTERED TRADEMARKS OR TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES INTLESS OTHERWSE SPECIFIER ALL DIMENSION ARE IN ISCIDES UNITED STATES AND/OR OTHER COUNTRIES ITTLE: FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD MACHINE R. 02 ALL DIMENSION ARE IN ISCIDES UNITED STATES AND/OR OTHER COUNTRIES INTLE: FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD MICHINE R. 02 NOT SI ISON INTOLERANCES (KCEPT AS NOTED) UNITED STATES AND/OR OTHER COUNTRIES INTERPETER RANDING DIR TOLERANCES (IN WICHING HAVE ECONTROLIED AND IS IN OTTO BE VIEW AND AND ALL IS 7793 INTOLERANCES (KCEPT AS NOTED) INTOLERANCES (KCEPT AS NO							
APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OR TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES IMMESS OTHERWISE SPECIFIED ALL DMISSIONS ARE IN INC. DMS IN UNABLE 12 INFORMATION DMS INFORMATION IN TO MARKED PRESSURE SYSTEMS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES IMMESS OTHERWISE SPECIFIED ALL DMISSIONS ARE IN INC. DMS IN UNABLE 12 INFORMATION DMS INFORMATION IN TO MARKED PRESSURE SYSTEMS TO LERANCES (IXCEPT I AS NOTED) ITTLE: FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD Integrate Tex. NSI 14.5.2009 DMS INFORMATION INFORMATION WHICH MAY BE CONTROLLED AND IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE SUFFICIENCE ONLY WHICH MAY BE CONTROLLED AND IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE SWITHOUT WRITTIN PROVED TO MANUFACTURINE PURPOSE SWITHOUT WRITTIN TO MARKED TO CONTAINS CONFIDENTIAL INFORMATION INTOLERANCES (IN) XXX = ± .005 XXX = ± .005 THIRD ANGLE PROJECTION WIG BY K. SMITH DWG, NO. 25-520-016 00 REF. 00 00 0450044-16 00							В
APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OR TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES IMINESS OTHERWSE SPECIFIED ALL DIMENSIONS ARE IN INCHES INTERNET PER ANSI VIA.5.2009 DIMS NI Imm) ARE REFERENCE ONLY DIMS NI Imm) ARE INFORMATION NI IMM AND				PRESSURE PORTS, 6 PLACES AQUADYNE SERIES 50 CONN	ECTOR		
APS AND THE APS LOGO ARE EITHER INLESS OHERWISE SPECIFIED TITLE: FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD APS AND THE APS LOGO ARE EITHER ALL DIMENSIONS ARE IN INCHES INTERPET PER ANSI 14.5.2009 DIM SIGNE ARE IN INCHES OF SHAPE TECHNOLOGIES INC. IN THE INTERPET PER ANSI 14.5.2009 DIM SIGNE PERSIME SYSTEMS ADVANCED PRESSURE SYSTEMS UNITED STATES AND/OR OTHER COUNTRIES UNITED STATES AND/OR OTHER COUNTRIES INTERPET PER ANSI 14.5.2009 THIRD ANGLE PROJECTION INTERPET PERSIMMON DR. TOMBALL, 1X 77375 Intel APPROVED THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATION WHICH MAY BE CONTROLED AND IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED PERSISTEM FOR ANY PURPOSE NOR USED PERSISTEM STATE + .005 THIRD ANGLE PROJECTION INTERPET PERSISTER CONTAINS CONFIDENTIAL INFORMATION WHICH MAY BE CONTROLED AND IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED PERSISTON FROM ADVANCED PRESSURE SYSTEMS. DIM TOLERANCES: (IN X = ± .005 XX = ± .005 DARKER REF. DWG. D45044.16 SHT 1 OF 6 6 5 4 3 2 1 1 1 1 1 1 1 1 1							
APS AND THE APS LOGO ARE EITHER APS AND THE APS LOGO ARE EITHER INVESSION FRADEMARKS OR TRADEMARKS OF TRADEMARKS OF TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES INVESSION FRADEMARKS OF TRADEMARKS OF TRADEMARKS OF TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES INVESSION FRADEMARKS OF TRADEMARKS OF TRADEMARKS OF TRADEMARKS OF TRADEMARKS OF TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES INVESSION FRADEMARKS OF TRADEMARKS OF TRADEMAR							
OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES DIM TO MAR REFERENCE ONLY BREAK SHARP EDGES & DEBURR.015 ADVANCED PRESSURE SYSTEMS 701 S. PERSIMMON DR. TOMBALL, TX 77375 ADVANCED PRESSURE SYSTEMS 701 S. PERSIMMON DR. TOMBALL, TX 77375 THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATION WHICH MAY BE CONTROLLED AND IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM ADVANCED PRESSURE SYSTEMS. SURFACE 63/ DIM TOLERANCES: (in) XX = ± .063 XXX = ± .005 THIRD ANGLE PROJECTION Image: Control of the control o			APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OR TRADEMARKS	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES INTERPORT OF ANSI VIA 5 2000	TITLE: FL END ASSY-SERIES 3	00, HP, 20KSI, 1.00", AQD	
Init Document contraints controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be controlled and is not to be written and be written			OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES	DIMS IN [mm] ARE REFERENCE ONLY BREAK SHARP EDGES & DEBURR .015 TOLERANCES (EXCEPT AS NOTED)	ADVANCED PRESSURE SYSTEM 701 S. PERSIMMON DR. TOMBALL, TX 7737		A
DATE APPROVED DISCLOSED IO OTHERS FOR ANY PURPOSE NOR USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM ADVANCED PRESSURE SYSTEMS. R.02 FILLETS XX = ± .015 .XXX = ± .005 .XXX = ± .005 APRVD BY B. PARKER REF. DWG. D45044-16 SHT 1 OF 6 6 5 4 3 2 1			THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATIO WHICH MAY BE CONTROLLED AND IS NOT TO BE	N SURFACE 63/ FINISH DIM TOLERANCES: (in) $X = \pm .063$	DWG BY K. SMITH	DWG. NO.	
3/18/2020 K. SMIIH ANGLE ±1° XXXX = ± .0005 D. F/KKEK KEF. DWG. D45044-16 SHT 1 OF 6 6 5 4 3 2 1	DATE	APPROVED	FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM ADVANCED PRESSURE SYSTEMS	FILLETS $\kappa.02$ $.XX = \pm .015$ ANCLE ± 10 $.XXX = \pm .005$	APRVD BY B PARKER		
	3/18/2020	K. SMITH	5	4 .XXXX = ± .0005	2	1 D45044-16 SHT 1 OF 6]

							APS AND THE APS LOG	O ARE EITHER OR TRADEMARKS	<u>l</u> Al	UNLESS OTHERWISE SI LL DIMENSIONS ARE	IN INCHES	TITLE:
А								ES INC. IN THE	DIM' BRE	'S IN [mm] ARE REFER	RENCE ONLY DEBURR .015	
							UNITED STATES AND/OR O	THER COUNTRIES	TOLERA	NCES (EXCEP	PT AS NOTED)	THIRD ANG
ſ				REVISIONS			THIS DOCUMENT CONTAINS CONFI WHICH MAY BE CONTROLLED	DENTIAL INFORMATION AND IS NOT TO BE	SURFACE FINISH	63 DIA	$\forall \text{ TOLERANCES: (in)} $	DWG BY
ľ	ZONE	REV.		DESCRIPTION	DATE	APPROVED	DISCLOSED TO OTHERS FOR ANY FOR MANUFACTURING PURPOSE	PURPOSE NOR USED ES WITHOUT WRITTEN	MACHINE FILLETS	R.02 .x	$XX = \pm .015$	APRVD BY
		0		INITIAL RELEASE	3/18/2020	K. SMITH	PERMISSION FROM ADVANCED	PRESSURE SYSTEMS.	ANGLE	±1° .x	$XXX = \pm .0005$ $XXXX = \pm .0005$	
		8	3	7	6		5	Ť	4		3	



			REVISIONS			THIS DOCUMENT CONTAINS CON WHICH MAY BE CONTROLLE	IFIDENTIAL INFORMATION	FINISH	63
ZONE	REV.		DESCRIPTION	DATE	APPROVED	DISCLOSED TO OTHERS FOR AN FOR MANUFACTURING PURPC	VY PURPOSE NOR USED	MACHINE FILLETS	R.0
	0		INITIAL RELEASE	3/18/2020	k. smith	PERMISSION FROM ADVANCE	D PRESSURE SYSTEMS.	ANGLE	±l
		8	7	6		E		4	

NOTES: 1. LUBRICATE THREADS WITH SILVER GRADE ANTI-SEIZE AND TORQUE TO 500 FT. LBS. (SEE SHEET 6 FOR TO 2. LUBRICATE THREADS WITH SILVER GRADE ANTI-SEIZE AND TORQUE TO 300 FT. LBS. (SEE SHEET 6 FOR TO 3. LUBRICATE BORE OF SUCTION MANIFOLD WITH SILVER GRADE ANTI-SEIZE PRIOR TO INSTALLATION 4. LUBRICATE O-RINGS WITH FML-2 FOOD GRADE MACHINERY GREASE	DRQUE PATTERN) DRQUE PATTERN)				F
E	<u> </u>				E
D (61102062) 12X(90-826-000) 3X(61122760) 12X(90-826-000)					D
C 2 12X (90-026-500 C (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)			- <u>61117835</u>)3x <u>4</u> J3x <u>3</u>	(61102112)	C
		<u>(61117350</u>)3X			В
		APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OR TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE UNITED STATES AND/OR OTHER COUNTRIES	UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES INTERPRET PER ANSI Y14.5-2009 DIM'S IN [mm] ARE REFERENCE ONLY BREAK SHARP EDGES & DEBURR .015 TOLERANCES (EXCEPT AS NOTED)	TITLE: FL END ASSY-SERIES 300, HP, 20KSI, 1.00'', AQD Advanced pressure systems 701 S. PERSIMMON DR. TOMBALL, TX 77375 THIRD ANGLE PROJECTION	
REVISIONS ZONE REV. 0 INITIAL RELEASE	DATE APPROVED 3/18/2020 K. SMITH	THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATION WHICH MAY BE CONTROLLED AND IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE NOTRO USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM ADVANCED PRESSURE SYSTEMS.	$\begin{tabular}{ c c c c c c c c c c c c c c c c c c c$	DWG BY K. SMITH DWG. NO. 25-520-016 APRVD BY B. PARKER REF. DWG. D45044-16 SHT 3 OF	REV. 00 DF 6



	8 7	6	5	4	3	2	1
					/	\sim	
	NOTES:					J	
	 LUBRICATE THREADS WITH SILVER GRADE ANTI-SEIZE PRIOR TO INSTALLATION LUBRICATE ALL O-RINGS WITH FML-2 FOOD GRADE MACHINERY GREASE 			3X(61115907)			
				3X(<u>25-500-316</u>)		Ĵ	
							<pre>/</pre>
-							
			28 (41110/42)				
			33(61119662)				
			3X(<u>61120529</u>)		the state		
		3	3X(61122827)				
		\checkmark				<u>30-002-150)3x 2 ></u>	
	3X(61117356						
					\(<u>25-500-</u>	<u>106</u>)3X[1]>	
	38(61119152)				<u>(25-500-216)</u> 3X		
	3X(<u>61117350</u>)						
l							
l				-(25-500-102)3X			
			<u>(10183168)</u> 3X <u>2</u>	\rangle			
			APS AND THE APS LOGO ARE FITHER		TITLE: FL EN	D ASSY-SERIES 300 F	
			REGISTERED TRADEMARKS OR TRADEMARKS OF SHAPE TECHNOLOGIES INC. IN THE	INTERPRET PER ANSI Y 14,5-2009 DIM'S IN [mm] ARE REFERENCE ONLY		ADVANCED PRESSURE SYSTEMS	
			UNITED STATES AND/OR OTHER COUNTRIES	BREAK SHARP EDGES & DEBURR .015 TOLERANCES (EXCEPT AS NOTED)			APS APS
	REVISIONS		THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATIO! WHICH MAY BE CONTROLLED AND IS NOT TO BE	N SURFACE 63 DIM TOLERANCES: (FINISH X = + 0.63	DWG BY		SHAPE TECHNOLOGIES GROUP*
ZONE	REV. DESCRIPTION	DATE APPROVED	DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM ADVANCED PRESSIPE SYSTEMS	MACHINE FILLETSR.02.XX= \pm .015ANGLE.XXX= \pm .005	APRVD BY	B. PARKER	25-520-016



NOTES: 1. LUBRICATE THREADS WITH SILVER GRADE ANTI-SEIZE AND TORQUE TO 60 FT. LBS.	
3X(25-500-108)	
3X (61103088)	
3X (61115064)	
	F
APS AND THE APS LOGO ARE EITHER ALL DIMENSIONS ARE IN INCHES REGISTERED TRADEMARKS OR TRADEMARKS INTERPRET PER ANSI Y14.5-2009	FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD
OF SHAPE TECHNOLOGIES INC. IN THE DIMS IN [mm] ARE REFERENCE ONLY UNITED STATES AND/OR OTHER COUNTRIES TO FOR AN ACTION OF A CHICAGE AND A CHI	ADVANCED PRESSURE SYSTEMS 701 S. PERSIMMON DR. TOMBALL, TX 77375
REVISIONS THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATION SURFACE 63 DIM TOLERAN	DWG BY K SA UTU
NE REV. DESCRIPTION DATE APPROVED MACHINE ROUSE NOR USE OF THE STREAM MACHINE ROUSE NOR USE OF THE STREAM	N. SMITH DWG. NO. REV. 00 .015 APRVD BY B. PAPKED 25-520-016 00
0 INITIAL RELEASE 3/18/2020 K. SMITH Examples of the state of the stat	.0005 REF. DWG. D45044-16 SHT 5 OF 6 3 2 1

						APS AND THE APS LOGO ARE EITHER REGISTERED TRADEMARKS OR TRADEMARKS		UNLESS OTHER ALL DIMENSION	RWISE SPECIFIED NS ARE IN INCHES ANSI Y14.5-2009	TITLE:
A						OF SHAPE TECHNOLOGIES INC. IN THE		DIM'S IN [mm] AR BREAK SHARP ED	RE REFERENCE ONLY GES & DEBURR .015	
						UNITED STATES AND/OK OTHER COUNTRIES	TOLE	rances (e)	XCEPT AS NOTED)	THIRD AND
			REVISIONS			THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATIC WHICH MAY BE CONTROLLED AND IS NOT TO BE	N SURFACE	63/	DIM TOLERANCES: (in) X = + 0.63	DWG BY
ZONE	REV.		DESCRIPTION	DATE	APPROVED	DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN	MACHINE FILLETS	R.02	$.XX = \pm .015$	
	0		INITIAL RELEASE	3/18/2020	K. SMITH	PERMISSION FROM ADVANCED PRESSURE SYSTEMS.	ANGLE	±1°	$.XXX = \pm .005$ $.XXXX = \pm .0005$	
	2	3	7	6		5	1		3	

F

E

D

->

С

В



FL END ASSY-SERIES 300, HP, 20KSI, 1.00", AQD ADVANCED PRESSURE SYSTEMS 701 S. PERSIMMON DR. TOMBALL, TX 77375 APS $\blacksquare \blacksquare$ THIRD ANGLE PROJECTION SHAPE TECHNOLOGIES GROUP* K. SMITH DWG. NO. REV. 25-520-016 00 B. PARKER REF. DWG. D45044-16 SHT 6 OF 6 2

IC

D

			8	7	6			5		4		3
Γ	ITEM NO.	QTY.	PART NO.	DESCRIPTION			•					
Γ	1	1	61105026	FTG-BLNK, SERIES 50, Q/CHNG								
Г	2	5	61105248	FTG-SERIES 50, .56 AE MP, Q/CHNG								
G	3	6	30-001-208	O-RING, 2-208 BUNA-N 90 DURO								
	4	2	35-008-010	RUPT DISC ASSY, 9/16MP RH (13/16"-16) 20K COMP				4X(90-110-125)-	_ /		(35-001-025)	
	5	1	35-006-240	RUPT DISC, 24K BURST, 1/4 A/S				(1105249)	\land			
	6	1	35-006-270	RUPT DISC, 27K BURST, 1/4 A/S				(01103240)				-
	7	1	65-120-015	ASSY, 20K J/S TY PRESS REGULATING VLV (PRV)				(30-001-208)	V V	1111		25
_	8	1	65-120-047	TORPEDO ADPTR; 1-16 RHM J/S (PORT) X 9/16 MP		2X	(65-120-007)—	$\sim \circ$	\setminus / /			
L	9	2	65-120-007	PLUG, J/S TY 1-16 RHM W/ SEAL ASSY								
	10	1	35-001-025	PRESS GAUGE, 4" 0-40K/2758 BAR RANGE, 20K/1379				Ę				
	11	1	21-002-003	COLLAR, 9/16" MP, SS, 20K		(65-	120-015)			-0	21 003 003	
	12	1	21-003-003	GLND NUT, 9/16" MP, SS, 20K							1-003-003	
F	13	1	25-500-020	KIT-CLNG, S3300, AQD F/E			C	S NAUMA) $\setminus \setminus$	2	21-002-003	
	14	1	12-033-0808.B	FITTING, 90, MNPT-MJIC, 08-08.B			(($^{\prime}$ $^{\prime}$ $^{\prime}$			
Ļ	15	1	12-027-0808.B	FITTING, STRT, FJIC-HOSE, 08-08.B								
	16	1	12-030-3232.AL	FITTING, 90, MNPT-FNPT, 32-32.AL								
	17	1	99-013-234	FITTING, CAM LOCK, 2" MNPT X 1-1/2" CAMLCK		(65-1	20-04/)					
	18	1	99-013-235	FITTING, CAM LOCK, 1-1/2" CAMLCK X 1" HB						<u>-</u>		
	19	24	90-110-125	BOLT, SHCS, 5/16"-18 X 1-1/4"				Ħ				
Ļ	20	3	12-091-0104	FITTING, 90, MNPT-PTC, 01-04		4X(90-1	10-125)	. Y				
-	21	1	12-250-3200.SS	PLUG, MNPT, 32.SS						//		
_	22	1	99-013-030	HOSE CLAMP, WORM DR, 13/16 - 1-1/2, .5 IN WD		<u> </u>			/			
	23	96 IN.	13-008-2000.BLU	HOSE, PUSH-LOK, -8, 250 PSI, BLU		(611	05248					
-	24	72 IN.	13-016-2000.BLU	HOSE, PUSH-LOK,-16, 175 PSI, BLU		(30-0	01-208				8	
ŀ	25	9 FI.	60-072-040	TUBING; 1/4 PUSH-LOK POLYETHYLENE (BLACK)								
				(12-030-3232.AL)			Ć					
				\sim					0			/
D										1 0	\langle	
											5	
					j u							
				(99-013-234)								()
											\sim	° /
_					2	/ 1 /		-				-
					AX (90-110-125)-							
				(99-013-235)							- 01 Ma	
						<u>5026</u>)—						
						<u>)-001-208</u>)—/	_					
С				(LACO	ľ							
					1	(30-001-208)						\setminus -12
						(1105040)		(20,001,000)				
					J	(61105248)		(30-001-208)	•			-(30-110-123)
				QE .				(61105248)				61105248
_						(90-110-125)						-001-208
											(30	001 200
						(35-006-270)		(90-110-125)	A			
								-				
_						(25,009,010)		(35-006-240)	∎∐			
в									M			
							\bigcirc	35-008-010				
									\bigcup			
									\smile			

						C	ADVANCED PRESSURE SYST 701 S. PERSIMMON DR. TON UNLESS OTHER	ems MBALL, TX 77375 RWISE SPECIFIED:	TITLE:			
			REVISIONS		SHAPE TE	CHNOLOGIES GROUP ^A	ALL DIMENSIONS ARE IN INCHE DIMS IN MM ARE F	S, INTERPRET PER ANSI Y14.5-2009 OR REFERENCE ONLY	THIRD AND			
^ Z	ONE	REV.	DESCRIPTION	DESCRIPTION INITIAL RELEASE						BREAK SHARP EDG TOLERANCES (E	es and deburr .015 XCEPT AS NOTED)	DWG BY
		0	INITIAL RELEASE				APS AND THE APS LOGO ARE EITHER REGISTERED		RE EITHER REGISTERED		DIM TOLERANCES: (in) $X = \pm .063$	APRVD BY
		1 REPLACED PRV FITTING, DWG FORMAT				K. SMITH	INC. IN THE UN	NITED STATES AN	D/OR OTHER COUNTRIES	ANGLE ±1°	.XX = ± .015 .XXX = ± .005 .XXXX = ± .0005	MATERIAL
		Ê	3 7	6			5			4	3	





								~	701 S. PERSIMMON DR. TO	MBALL, TX 77375	111LE.
							IAP	5		RWISE SPECIFIED:	
		REVISIONS			SHADE TEC	HNOLOGIES GROUPA	DIMS IN MM ARE F	OR REFERENCE ONLY	THIRD AND		
Ą	ZONE REV.	DESCRIPTION					SHAFE FE	INVEDGIES GROUP	BREAK SHARP EDC TOLERANCES (E	GES AND DEBURR .015 EXCEPT AS NOTED)	DWG BY
	0	INITIAL RELEASE		9/30/2020	K. SMITH		HE APS LOGO AI			DIM TOLERANCES: (in) $X = \pm .030$	APRVD BY
	1	REPLACED PRV FITTING, DWG FORMA	Т	2/6/2023	K. SMITH	INC. IN THE UN	NITED STATES AND	D/OR OTHER COUNTRIES	ANGLE ±1°	$.XX = \pm .010$ $.XXX = \pm .005$ $.XXXX = \pm .0005$	MATERIAL
	8	7	6			5			4	3	





U.S. EPA Tier 4 Final and EU Stage V 151 bkW/202 bhp @ 2200 rpm

Image shown may not reflect actual engine configuration.

Specifications

Cat [®] C7.1 ACERT Industrial Power Unit	Metric	Imperial (English)			
Configuration	I-6, 4-Stroke				
Bore	105 mm	4.13 in			
Stroke	135 mm	5.31 in			
Displacement	7.01 L	402.8 in ³			
Aspiration	Series Turbocharge	ed-Aftercooled (TTA)			
Compression Ratio	16.5:1				
Combustion System	Direct Injection				
Rotation (from flywheel end)	Counterclockwise, viewed on flywheel				
Total Coolant Capacity	24.25 L	6.4 U.S. gal			
Total Lubricating Capacity	17.9 L	4.72 U.S. gal			
Total DEF Capacity	32 L*	8.45 U.S. gal*			
Cooling System	Liq	luid			
Estimated total weight including radiator support brackets Dry Wet	1087 kg 1124 kg	2396 lbs 2478 lbs			
Firing Order	1, 5, 3, 6, 2, 4				
Lifting Points Location	Baseframe				
Mobile Used G-load Limitations	6 g				

*Usable volume needs to take into account gradient capability and DEF expansion.

For additional information on all your power requirements, visit www.cat.com/industrial



Technical Data

Overall Dimensions

Height, including radiator support brackets . .1461 mm Length, front of radiator to rear of

air cleane	r		•	 •	•	•	•	•	•	•	 	•	•	•	•	•	•	•	1769	mm
Width											 								916	mm

Moments of Inertia (GD²)

Engine rotational components	0.18255	kgm ²
Crank pulley	0.01555	kgm ²
Flywheel (D0004) SAE 3	1.2	kgm ²
Flywheel (D0094) SAE 2	0.89	kgm ²
Flywheel (D0093) SAE 1	2.05	kgm ²

Center of Gravity

Forward from rear of block (wet) 445.3 mm Above crankshaft centerline (wet) 253.2 mm Offset to RHS of crankshaft centerline (wet) . . 8.8 mm

Center of Gravity (Engine)

Forward from rear of block (wet)	393 mm
Above crankshaft centerline (wet)	182 mm
Offset to RHS of crankshaft centerline (wet).	. 30 mm

General Installation

Performance

All ratings certified to within ± 3% **Note:** All data based on operation to ISO/TR14396 standard reference conditions.

Test Conditions

Air Temperature	25°C
Barometric Pressure.	100 kPa
Relative Humidity	10.7%
Air Inlet Restriction at Maximum	
Power (Nominal)	5 kPa
Exhaust Backpressure at Maximum	
Power (Nominal)	. 35 kPa
Fuel Temperature (Inlet Pump)	80°C

Noise Data

Average Sound Power Level for Bare Engine Without Inlet and Exhaust at 1 m	@ 2200 rpm	@ 1400 rpm
At Rated Speed With Suction Fan	113 dB(A)	104 dB(A)
Rated Speed With Blower Fan	117 dB(A)	107 dB(A)

Note: If the engine is to operate in ambient conditions other than those of the test conditions, suitable adjustments must be made for these changes.

Designation	Unito	Engine speed rpm									
Designation	Units	1200	1400	1600	1800	2000	2200				
Gross Engine Power ⁽³⁾	kWm	116.9	144.1	151	151	151	150.9				
Brake Mean Effective Pressure	kPa	1668	1763	1616	1436	1293	1175				
Cooling Fan Airlflow at Zero Duct – Suction	(m³/s)	3	3.5	4.1	4.6	5.2	5.7				
Radiator Core Resistance	kPa	0.15	0.2	0.25	0.31	0.38	0.45				
Fan Power Absorption – Suction	kWm	2	3.2	4.8	6.8	9.3	12.4				
Net Power at Flywheel ⁽¹⁾	kWm	115	141	146	144	142	139				
Torque (gross)	kWm	930	983	901	801	721	655				
Engine Coolant Flow Against 35 kPa Restriction	L/min	197	230	262	294	326	360				
Inlet Air Flow Volume (Wet)	m³/min	7.3	8.5	9	9.6	10.3	11.5				
Exhaust Gas Flow (Wet)	m³/min	6.8	7.9	8.3	8.8	9.5	10.5				
Exhaust Gas Mass Flow (Wet)	kg/min	8.8	10.2	10.7	11.4	12.2	13.5				
Exhaust Gas Temperature (Exhaust Manifold/Turbo Outlet)	°C	448	439	425	437	448	441				
Specific Fuel Consumption (SFC) Gross	g/kWhr	210	202	203	210	217	227				
Fuel Consumption ⁽²⁾	L/hour	29.3	34.9	36.5	37.8	39.1	40.9				

1. Gross power less auxiliaries. 2. Figures given for 100% net engine power.

3. Refer to Performance Curve T 4888.

Cautions:

 All engines are to operate between sea level and 1676 m and in ambient temperatures between -40°C and +48°C if a canopy is fitted with a 200 Pa air flow restriction without de-rating or specification change (excluding customer-fit cold start aid).

• Maximum ambient temperature increases to +55°C if the canopy air flow restriction does not exceed 120 Pa.



Energy Balance

Designation	Unito	Engine speed rpm									
Designation	Units	1200	1400	1600	1800	2000	2200				
Energy in (Heat of Combustion)	kWt	335	398	417	433	451	475				
Energy to Power (Gross)	kWm	116.9	144.1	151	151	151	150.9				
Energy to Cooling Fan – Suction	kWm	1.5	2.3	3.5	4.9	6.8	9.1				
Energy to Power Net	kWm	114.9	140.9	146.2	144.2	141.7	138.5				
Energy to (Coolant and Lubricating Oil) Radiator	kWt	86	96	98	105	108	117				
Energy to Exhaust	kWt	117	133	137	148	162	178				
Energy to Charge Cooler	kWt	13	16	16	16	16	19				
Energy to Radiation	kWt	15	18	18	19	20	20				

Cooling System

Cooling Pack

Overall Weight (Wet)	101.7 kg
Overall Face Area	. 0.6646 m ²
Width	. 875.8 mm
Height	1088.5 mm

Radiator

Maximum Load on Rad Assembly
from Stone Guard Mounts 2.8 kg
Face Area
Number of Rows 57
Matrix Density 10 fins/inch
Width of Matrix
Height of Matrix 800 mm
Pressure Cap Setting 1 bar

Charge Cooler

Face Area	0.203 m²
Number of Rows	2
Matrix Density	13 fins/inch
Width of Matrix	. 257.8 mm
Height of Matrix	789 mm

Fan

Туре	Suction
Diameter	724 mm
Drive Ratio	1:1
Number of Blades	7
Material Co	omposite

Coolant

Total System Capacity 2	24.25 liters
Bare Engine Capacity 1	2.25 liters
Maximum Top Tank Temperature	108°C
Thermostat Operation Range	. 82-94°C

Recommended Coolant

The following coolant should be used:

- Acceptable A commercial heavy-duty antifreeze that meets "ASTM D6210" specifications.
- 1. The C7.1 industrial engines must be operated with a 1:1 mixture of water and glycol. This concentration allows the NOx reduction system to operate correctly at high ambient temperatures.
- 2. Do not use a commercial coolant/antifreeze that only meets the ASTM D3306 specification. This type of coolant/antifreeze is made for light automotive applications.

Duct allowance – Maximum Additional Restriction to Cooling Airflow and Resultant Minimum Airflow						
Description	Unito	En	gine Sp	eed – r	pm	
Description	Units	1800	2200	1800	2200	
Ambient Clearance	°C	55	55	55	55	
Duct Allowance	kPa	120	120	200	200	
Cooling Fan Airflow	m³/min	4.62	5.8	4.27	5.42	
Radiator Core Resistance	kPa	553	791	609	871	



Electrical System

Engine Stop Method ECM controlled

Alternator Model	Unit	Remy 13SI	Remy 13SI
Alternator Voltage	Volts	12	24
Alternator Output	Amps	120	80

Starter model	Unit	lskra AZF	Remy iMT	Denso P5
Starter Motor Voltage	Volts	12 24		12
Starter Motor Power	kW	4 8.5		5
	SAE 1 D0093		156	
Number of Teeth on Flywheel	SAE 2 D0094	134		
	SAE 3 D0094	126	126(1)	126
Number of Teeth on Starter Pinion		10	12	13
Minimum Cranking Speed	rpm	100		
Starter Solenoid – Maximum Pull-in Current @ 0°C	Amps	68 2		41
Starter Solenoid – Maximum Hold-in Current @ 0°C	Amps	20	2	11

⁽¹⁾ 24V SAE 3 options only compatible with C0067 LHS starter.

Fuel Injection System

Fuel Pump Type/Model. Denso HP4 Injection System. Electronic Injector Type Common rail Injector Pressure 200 MPa
Fuel Feed
Fuel Lift Pump Type Gerotor
Maximum Fuel Supply Restriction at
Primary Filter
Maximum Fuel Return Restriction
at Low Idle 20 kPa
Maximum Fuel Return Flow 2.5 m ³ /min
Maximum Fuel Flow Through Inlet
Connection 3.7 I/min
Maximum Lift Pump Delivery Flow Rate 3.7 I/min
Maximum Pump Delivery Pressure 8500 kPa
Maximum Suction Head At Fuel
Pump Inlet 50 KPa
Maximum Static Pressure Head 20 kPa
Maximum Fuel Temperature at Lift
Pump Inlet 80°C
Maximum Fuel Filter Service Interval 500 hrs

Fuel Specification

BS2869 Class 2 (off highway, gas oil); DIN EN590 DERV (Class A to F and 0 to 4)

Density	0.840-0.865 (kg/liters @ 15°C)
Viscosity	2-3.2 (mm²/s @ 40°C)
Sulfur Content	0.0007-0.0015 (% mass)
Cetane No.	

Induction System

Maximum Air Intake Restriction

Clean Filter	5 kPa
Dirty Filter	8 kPa
Induction Indicator Setting	8 kPa
Air Filter Type 1	25 pm



Cold Start Recommendations

Air Temp. Oil Viscosity Limit	With (Plu 12V AZ Bare E	Glow gs F & P5 ngine	Without Plugs 12 Bare E	t Glow 2V AZF ngine	With Plugs 2 Bare E	Glow 4V IMT Ingine	Withou Plugs 2 Bare E	t Glow 4V IMT ingine	With Plu 24V A Bare E	Glow Igs ZF hp Ingine	Withou Plu 24V A Bare E	t Glow gs ZF hp ingine
-5°C	15W40	950	15W40	950	15W40	525	15W40	525	15W40	525	15W40	525
-10°C	15W40	950	15W40	950	15W40	525	15W40	525	15W40	525	15W40	525
-15°C	15W40	1650	15W40	(1)	15W40	680	15W40	(1)	15W40	680	15W40	(1)
-20°C	10W40	1650	10W40	(1)	10W40	680	10W40	(1)	10W40	680	10W40	(1)
-25°C	5W30	1900	5W30	(1)	5W30	750	5W30	(1)	5W30	680	5W30	(1)
Maximum Battery CCA.		2400		2400		1400		1400		1200		1200

Minimum Battery Cold Cranking Amps

⁽¹⁾ Must use glow plugs.

Lubrication System

Total System Capacity (to Include Filter,
Rail, and Cooler) 17.9 liters
Maximum Sump Capacity 16 liters
Minimum Sump Capacity 13 liters
Maximum Oil Temperature
Continuous Operation
Maximum Oil Temperature
Intermittent Operation
Lubricating Oil Pressure
At Rated Speed 400-520 kPa
Minimum
Oil Relief Valves Opens at 520 kPa
Sump Drain Plug Tapping Size or
Hose Connection Size 3/4 UNF STOR port
Oil Pump Speed/Drive Method Gerotor (gear-driven
off crankshaft)
Lubricating Oil Flow at Rated Speed 60 I/min
Lubricating Oil Pressure at
Rated Speed 400-520 kPa
Oil Consumption at Full
Load Rated Speed 0.08% of fuel

Exhaust System

Aftertreatment System Type DOC, DPF, SCR/
AMOX+DEF System
Type of Regeneration
(High/Low Temperature) Low
Aftertreatment Height 455 mm
Aftertreatment Length 733 mm
Aftertreatment Width 769 mm
Aftertreatment Weight 107 Kg
Aftertreatment Skin Temperature
Maximum Temp. for Electronic
Components on Aftertreatment 120°C
Maximum Temp. for External Electronic
Components for Aftertreatment
(Soot Sensor Box) 85°C
Typical Maximum Temperature
Exhaust Out 475°C
Maximum System Backpressure Limit
for hp 175-275/130-205 kW 49.1 kPa
Aftertreatment Exhaust Outlet Connection 76.2 mm
Aftertreatment Exhaust Outlet Connection
Load Limit
Attenuation of the DPF 25 dB(A)
Ash Service NA
Maximum Backpressure for
Customer-installed Pipe Work 5.3 kPa

Normal Operating Angles

Front and Rear	25°
Side	25°



Recommended SAE Viscosity

A multigrade oil which conforms to API-CJ4 (ACEA-E9) must be used.



PTO Capabilities

Flange Type (N•m)	Standard Various Refer	Heavy Duty SAE "B" 13-tooth
		Spille
I orque Capability Intermittent	142	210
Torque Capability Continuous	99	147
Maximum Bending Moment at Flange	0	15

Note: Refer to "Applications and Installation Manual" for "PTO approval requirements."

Mountings

Maximum Static Bending Moment at Rear Face of Block	1130 N•m				
Maximum Permissible Overhung Load on the Flywheel	See Polar Diagram Chapter 6 of the ESM				
	Dynamic Vertical BM	Dynamic Lateral BM			
Maximum Bending Moment at Rear of Flywheel Housing – SAE 3	±3000 N•m	±1700 N•m			
Maximum Bending Moment at Rear of Flywheel Housing – SAE 2	±5600 N•m	±2800 N•m			
Maximum Bending Moment at Rear of Flywheel Housing – SAE 1	±8200 N•m	±5750 N•m			

Note: Refer to "Applications and Installation Manual" for "Bending Moment approval requirements."



Features

Emissions

Meets U.S. EPA Tier 4 Final and EU Stage V emission standards.

Compliance

The engine meets the European Machinery Directive, 2006/42/EC, with each engine supplied with a Declaration of Incorporation.

Reliable, Quiet, and Durable Power

World-class manufacturing capability and processes coupled with proven core engine designs assure reliability, quiet operation, and many hours of productive life.

High Performance

Series turbocharging with smart wastegate available on all ratings for fast response, high power, and increased torque.

Fuel Efficiency

Fluid consumption optimized to match operating cycles of a wide range of equipment and applications.

Fuel & Oil

Tier 4 Final/Stage V engines require ultra-low sulfur diesel fuel (ULSD with 15 ppm of sulfur or less) and new oil formulations to support the new technology. Cat[®] engines are designed to accommodate B20 biofuel. Your Cat dealer can provide more information regarding fuel and oil.

Broad Application Range

Industry leading range of factory configurable ratings and options for agricultural, materials-handling, construction, mining, aircraft ground support, and other industrial applications.

Package Size

Exceptional power density enables standardization across numerous applications. Multiple installation options minimize total package size. Ideal for equipment with narrow engine compartments.

Low-Cost Maintenance

Worldwide service delivers ease of maintenance and simplifies the servicing routine. Hydraulic tappets, multi-vee belts, service free DPF and 500-hour oil change intervals enable low-cost maintenance. Many service items have a choice of location on either side of the engine to enable choice of service access. The S•O•S[™] program is available from your Cat dealer to determine oil change intervals and provide optimal performance.

Quality

Every Cat engine is manufactured to stringent standards in order to assure customer satisfaction.

World-class Product Support Offered Through Global Cat Dealer Network

- Scheduled maintenance, including S•O•S sample
- Customer Support Agreements (CSA)
- Cat Extended Service Coverage (ESC)
- Superior dealer service network
- Extended dealer service network through the Cat Industrial Service Distributor (ISD) program



Standard Engine Equipment

Air Inlet

Standard air cleaners

Control System

Full electronic control system, all connectors and wiring looms waterproof and designed to withstand harsh off-highway environments, flexible and configurable software features and well supported SAE J1939 CAN bus enables highly integrated machines

Cooling System

Top tank temperature 108°C (226°F) as standard to minimize cooling pack size, 50:50 water glycol mix, detailed guidance on cooling system design and validation available to ensure machine reliability

Exhaust System

Diesel Oxidation Catalyst, Diesel Particulate Filter, and Selective Catalytic Reduction system supplied installed on engine. Zero downtime due to regeneration.

Flywheels and Flywheel Housing

Fitted with SAE 3, SAE 2, or SAE 1 flywheel housing configuration as standard – for use with a variety of flywheels.

Fuel System

Electronic high pressure common rail, ACERT™ Technology, innovative filter design to ensure maximum protection of the engine.

Lube System

Wide choice of sumps for different applications

Power Take Off

SAE A or SAE B flanges on left-hand side, engine power can also be taken from the front of the engine on some applications, compressors are also available

Dimensions





(1) Length 1769 mm (69.6 in)



(3) Height (including radiator support brackets) 1461 mm (57.5 in)

Note: Final dimensions dependent on selected options



151 bkW/202 bhp

Performance Data

Series Turbocharged-Aftercooled – 2200 rpm



Rating	Rated Speed rpm	Max Gross Power bkW	Max Gross Power bhp	Peak Torque Speed rpm	Peak Torque N•m	Peak Torque Ib-ft	Max Net Power Speed rpm	Max Net Power at Flywheel kWm	Max Net Power at Flywheel hp
С	1800-2200	151	202	1400	983	725	1600	146	196

Rating Definitions and Conditions

IND-C (Intermittent) is the horsepower and speed capability of the engine where maximum power and/or speed are cyclic (time at full load not to exceed 50%).

Additional ratings are available for specific customer requirements. Consult your Cat dealer.

Aftertreatment Features

Regeneration: Passive regeneration completely transparent to the operator.

Rating Conditions are based on SAE J1995, inlet air standard conditions of 99 kPa (29.31 in Hg) dry barometer and 25°C (77°F) temperature. Performance measured using a standard fuel with fuel gravity of 35° API having a lower heating value of 42 780 kJ/kg (18,390 btu/lb) when used at 29°C (84.2°F) with a density of 838.9 g/L.

Service: Service-free DPF for the emissions life of the engine

Available in 12V or 24V systems

Standard Emissions Control Equipment

DOC: Diesel Oxidation Catalyst **DPF:** Diesel Particulate Filter **SCR:** Selective Catalytic Reduction A range of SCR system components, including pump, tanks, and lines

LEHH0590-00






















151 kW @ 2200 rpm – Rear View with SAE 3 flywheel housing shown







©2018 Caterpillar All rights reserved.

Materials and specifications are subject to change without notice. The International System of Units (SI) is used in this publication.



Product Manual

Engine Display & Control Panel

J1939 Final T4 Engines



Part Number: C4F-F10185 Revision: 1.0

TABLE OF CONTENTS

PRIOR TO STARTING ENGINE	2
THROTTLE SETTINGS	
CAN BUS SETTINGS	
PANEL OPERATION	3
ENGINE START	
ENGINE STOP	
THROTTLE CONTROL	
MODULE CONNECTORS	4
PRIMARY 14 PIN MODULE CONNECTOR	
SECONDARY 23 PIN MODULE CONNECTOR	
PANEL CONNECTORS	6
23-PIN ENGINE CONNECTOR	
31-PIN ACCESSORY CONNECTOR	
ENGINE ALARMS, CODES AND MESSAGES	7
ENGINE ECU ALARMS/DE-RATE/SHUT DOWNS	
PANEL ALARM ANNUNCIATION AND CODE READER	
PANEL INDICATION LAMPS ACTIVE AND STORED ENGINE ECU CODES	
	Q
CONTROL PANEL SPECIFIC SAFETY ALARMS	
CONTROL DANIEL ANALOG AND DIGITAL INDUTS	10
DIGITAL INPUTS	
ANALOG INPUT OPTIONS	
DIGITAL INPUT OPTIONS	
CONTROL PANEL RELAY OUTPUTS	
RELAY OUTPUTS	
RRELAY OUTPUT OPTIONS	
EMISSIONS MONITORING	
MENU SYSTEM	
MENU ACCESS, EXIT AND NAVIGATION	
MENUS TO VIEW INFORMATION	
MENUS TO CONFIGURE MODULE SETTINGS	

PRIOR TO STARTING ENGINE

<u>Prior to starting the engine</u>, select the proper throttle control mode required for application. These settings are accessed in the Throttle Configuration menu.

Throttle Configuration	Throttle Type - Throttle Type Selection (Default = Vernier)
	TSC Mode Selection
	TSC Min Speed Selection (Default = 850 rpm)
	TSC Max Speed Selection (Default = 2400 rpm)
	TSC Ramp Rate Selection (Default = 100 rpm/sec)
	Throttle Curve Selection
	Multistate Speed 1 Selection
	Multistate Speed 2 Selection
	Multistate Speed 3 Selection
	Multistate Speed 4 Selection

MANUAL THROTTLE OPTIONS

1) Vernier Throttle (Default)

Vernier throttle is standard up and down throttle between the minimum and maximum selections. The ramp rate is the rate of acceleration in rpm's per second. The control panel uses J1939 throttle, also called "torque speed control" or TSC1.

2) Multistate Throttle

Multistate throttle provides for one, two, three or four specific operating speeds. Pressing the up and down buttons adjusts engine speed between the selected multistate speed selections.

Communication between the panel and the engine ECU occurs over the two wire CAN bus (CAN High wire and CAN Low wire). It is necessary that the panel and engine ECU settings be the same for the following parameters. The communication settings are available in the **CAN Configuration** *menu* shown below.

CAN Configuration Menu	Source Address (Default = 44) Available 3, 17, 228, 4, 43, 44
	TSC1 Address (Default = 3) Available 3, 17, 228, 4, 43, 44
	Engine Address (Default = 0)
	Oil/Fuel Transmit

PANEL OPERATION

- 1) Engine Start Turn key to run position
- 2) Engine Stop Turn key to off position
- 3) Engine Throttle Push up and down buttons

Manual Throttle Control

With the key in the RUN position, and the toggle switch placed in manual, the panel operates the throttle by pressing the up and down buttons. An arrow will indicate increasing or decreasing engine speed.

Hydro Throttle Control

Opening and closing the hydro Throttle Switch can change engine speed between the programmed Minimum Speed and the Last Operating Speed for each run. The last Operating Speed is the speed at which the engine was last when the Hydro Throttle switch was opened, <u>or</u> the Throttle switch was changed to "Automatic".



MODULE CONNECTORS



Primary Connector (14 Pin)

Pin	Function	Pin	Function
1	Relay #2 -ECU Signal	8	J1939 Low
2	Relay #1 NO	9	Relay #3 Common
3	Relay #3 NO	10	Not Used
4	Relay #2 & #4 Common	11	Battery Positive
5	Relay #4 NO	12	Battery Negative
6	Relay #1 Common	13	Fuel Level
7	J1939 High	14	DI #1 Hydro-Throttle

CAUTION:

Maximum current draw for signal circuits is 5 amps

Secondary Connector (23 Pin)

Pin	Function	Pin	Function	Pin	Function
1	Relay #5	9	Relay 5/6 Common	16	Relay #6
2	Not Used	10	Not Used	17	DI #2 Override
3	Not Used	11	Not Used	18	DI #3 E-Stop
4	Not Used	12	Not Used	19	DI #4 Low Water
5	Not Used	13	DI #9	20	DI #5
6	Not Used	14	DI #8	21	DI #6
7	Not Used	15	Relay #7	22	DI #7
8	Relay 7/8 Common			23	Relay #8

Note: Modbus is available as an option in the C Series 200 Level product. Consult with a factory sales engineer for ordering.

PANEL CONNECTORS

Engine Harness Connector – Deutsch 21 pin (HDP24-24-21PE)



	21 Pin Engine Harness Connector		
Pin	Function		
В	Battery Positive		
Ε	Battery Negative		
G	Key On Power		
D	Crank Signal		
V	J1939 High		
U	J1939 Low		
J	Alternator Excite		
Ρ	Fuel Level		
L	Analog Throttle Emulator		
М	Analog Throttle Emulator		
С	Analog Throttle Emulator		
R	Digital Throttle Emulator		
S	Digital Throttle Emulator		

CAUTION:

Maximum current draw for relay output circuits is 5 amps

ENGINE ALARMS, CODES AND MESSAGES

ENGINE ECU ALARMS/DE-RATE/SHUT DOWNS

It is important to understand panel operation with respect to engine safety protections, alarms, and fault codes. The panel operates with J1939 engines. These engines have an ECU (engine control unit) which is essentially a computer that runs the engine. When engine parameters are out of normal operating ranges, the <u>ECU takes specific actions which can include the following</u>:

- 1) Broadcast a trouble code
- 2) Broadcast a red or yellow lamp
- 3) De-rate the engine
- 4) Shut down the engine
- 5) Turn on alarm horn

It is the <u>engine ECU that de-rates or shuts down</u> the engine when it is not operating within normal parameters. This includes more common shut downs like high engine temperature and low oil pressure but can encompass a large range of parameters depending on the ECU.

PANEL ALARM ANNUNCIATION AND CODE READER

This panel is configured to operate with standard J1939 engines where engine de-rate and shutdowns are managed by the engine ECU. The panel communicates with the engine ECU and serves as a trouble code reader. When the engine ECU broadcasts a trouble code (called an SPN.FMI code) the panel does the following:

- 1) Illuminates the appropriate LED indicator lamp
 - a. Yellow Lamp = Alarm
 - b. Red Lamp = Engine Shut Down
- 2) Displays the trouble code (standard SPN.FMI code)
- 3) Displays a code description on the LCD screen
- 4) Displays the occurrence count of the code



INDICATOR LAMPS

The panel red (alarm) and amber (pre alarm) lamp indicators.



ACTIVE AND STORED ENGINE ECU CODES

The panel also provides the ability to check the engine ECU for all <u>ACTIVE</u> and <u>STORED</u> engine ECU codes. These codes can be viewed via the <u>Active Codes</u> and <u>Stored Codes</u> menus. In addition, the control panel has its own <u>Alarm Event Log</u> menu that shows the last 16 engine ECU alarms as well as any control panel specific alarms.

CONTROL PANEL SPECIFIC ALARMS AND SHUT DOWNS

The panel has its own engine safety alarms and shut downs that can be enabled. These alarms and shut downs are managed by the control panel <u>independent from the engine ECU</u>. The available options are listed below and can be accessed via the Engine Safety Configuration menu.

Each alarm must be enabled in the Engine Safety Configuration menu to activate.

Heading	Default	Range	Units
Sender Check Bypass	0:10	0:05 – 1:00	Min:Sec
Fuel Level Check	Off	Off / Always / Run	
Low Fuel Pre Alarm	20	0 - 100	%
Low Fuel Alarm	1	0 - 100	%
Fuel Alarm Delay	0:05	0:01 – 1:40	Sec
Oil Pressure Check	Run	Off / Always / Run	
Low Oil Press Pre Alarm	15	0 - 100	PSI
Low Oil Press Alarm	10	0 - 100	PSI
Oil Press Alarm Delay	5	0:01 – 1:40	Sec
Temperature Check	Run	Off / Always / Run	
Low Temp Pre Alarm	0	0 - 300	Deg F
Low Temp Alarm	0	0 - 300	Deg F
High Temp Pre Alarm	220	150 - 300	Deg F
High Temp Alarm	230	150 - 300	Deg F
Temp Alarm Delay	0:05	0:01 – 1:40	Min:Sec
Battery Volts Check	Off	Off / Always / Run	
Low Battery Pre Alarm	12.0	0.0 - 40.0	Volts
Hi Battery Pre Alarm	15.0	0.0 – 40.0	Volts
Over Speed Check	Off	Off / Always / Run	
Over Speed Alarm	3000	650 - 5000	RPM
Over Speed Alarm Delay	0:05	0:01 - 1:40	Min:Sec

- 1) <u>Off / Always / Run</u> Describes when the parameter will be monitored for alarm conditions. Run refers to when the engine is running. Off disables the alarm conditions. Always enables the alarm constantly regardless of engine state.
- 2) <u>Alarm Delay</u> The time period, after Sender Check Bypass, that the parameter must be on the alarm condition before the alarm becomes latched.

CONTROL PANEL ANALOG AND DIGITAL INPUTS

The panel is shipped from the factory with the **bold** print inputs pre-wired and enabled in the panel. <u>Inputs not in bold print need to be wired and enabled to be used.</u>

Analog inputs				
Input	Heading	Default	Connector	Pin
Analog 1	Function	Fuel Level	Terminal Strip	3

Analog Inputs

Digital Inputs

Input	Heading	Default	Connector	Pin
	Normally	Open		
Digital 1	Function	Hydro Throttle	Terminal	1
Digital 1	Message	None	Strip	T
	Check	Always		
	Normally	Open		
Digital 2	Function	Pre Alarm		
Digital 2	Message	Override Active		
	Check	Always		
	Normally	Open		
Digital 2	Function	Alarm	Terminal	2
Digital 5	Message	E-Stop	Strip	
	Check	Always		
	Normally	Open		
Digital 4	Function	Alarm	Terminal	л
Digital 4	Message	Low Water	Strip	4
	Check	Run		
	Normally	Open		
Digital 5	Function	Available	21 Din	20
Digital 5	Message	None	SIPIII	20
	Check	Off		
	Normally	Open		21
Digital 6	Function	Available	21 Din	
	Message	None		
	Check	Off		

	Normally	Open		
Digital 7	Function	Available	21 Din	22
	Message	None	51 PIN	22
	Check	Off		
	Normally	Open		
Digital 8	Function	Available		14
	Message	None	51 PIN	
	Check	Off		
	Normally	Open		
Digital 9	Function	Available	21 Din	13
	Message	None	JT FIII	
	Check	Off		

<u>Hydro Throttle (Digital)</u> – A hydro throttle switch can be attached to the customer connection terminal strip position 1. With the Throttle toggle in the automatic position, closing this input to ground will allow the engine to run at the last operating speed. Opening the circuit will return the engine to idle. Additionally, the engine speed can be adjusted at the panel with the hare and turtle buttons while this circuit is closed. A single orange wire is provided with a single pin weather pack terminal attached

<u>Emergency Stop (Digital)</u> – An E-Stop switch can be attached to the customer connection terminal strip position 2. A shut down will occur when active. Wire as a normally open, close to ground circuit. *Note: Shut Down Override will disable this function.* For normally closed requirements, circuit board mounted jumper, JP11, must be moved to position B-C. A single grey wire is provided with a single pin weather pack terminal attached.

<u>Fuel Level Sender (Analog)</u> - A Fuel Level Sender can be attached to customer connection terminal strip position 3. Use a 240 to 33 ohm scale for a 0 to 100% display. Attaching a fuel sender will automatically change the LCD display from reading Fuel Rate to Fuel Level. A Pre Alarm is programmed at 20%. A shut down will occur below 5% if dipswitch 7 is in the ON position.

Low Water Level (Digital) – A level switch can be attached to the customer connection terminal strip position 4. Wire as a normally open, close to ground circuit. A shut down will occur when active.

ANALOG #1 INPUT FUNCTIONS

- Fuel Level S-W Fuel amount, in percentage, can be measured and displayed on the C3 module using a standard Stewart Warner scale sender of 240 ohms – 33 ohms. 240 = Empty and 33 = Full. Sender ground must be common with battery negative.
- Fuel Level VDO Fuel amount, in percentage, can be measured and displayed on the C3 module using a VDO scale sender of 10 ohms 180 ohms. 10 = Empty and 180 = Full. Sender ground must be common with battery negative.
- <u>Oil Pressure PSI</u> Oil pressure, in PSI, can be measured and displayed on the C3 module using a standard Stewart Warner scale sender of 240 ohms 33 ohms. 240 = 0 PSI and 33 = 100 PSI. Sender ground must be common with battery negative.
- <u>Oil Pressure bar</u> Oil pressure, in bar, can be measured and displayed on the C3 module using a standard Stewart Warner scale sender of 240 ohms 33 ohms. 240 = 0 bar and 33 = 7 bar. Sender ground must be common with battery negative.
- 5) <u>Oil Pressure VDO PSI</u> Oil pressure, in PSI, can be measured and displayed on the C3 module using a standard Stewart Warner scale sender of 10 ohms 180 ohms. 10 = 0 PSI and 180 = 150 PSI. Sender ground must be common with battery negative.
- <u>Oil Pressure bar</u> Oil pressure, in bar, can be measured and displayed on the C3 module using a standard Stewart Warner scale sender of 10 ohms 180 ohms. 240 = 0 bar and 33 = 10 bar. Sender ground must be common with battery negative.
- 7) <u>Rheostat</u> Speed control can be accomplished by connecting a 5 K potentiometer in series with the flex analog input. Engine speed will vary with the change in resistance value.
- 8) <u>0 5 VDC</u> Reserved for OEM applications.
- 9) <u>Ratiometric</u> Reserved for OEM applications.
- 10) <u>4-20mA</u> Reserved for OEM applications.
- 11) <u>Switch</u> This setting allows for a switch to be connected rather than an analog sender. Set Analog 1 Message to assign a label to the switch device.
- 12) <u>None</u> Set to None when no functionality is required.

DIGITAL FUNCTIONS

The digital inputs can be configured for different uses depending on the application. These include the following:

- 1) <u>Alarm</u> Engine shutdown once active with display message as assigned. A red lamp will also be illuminated.
- 2) <u>Pre Alarm</u> Warning message will be displayed along with a yellow lamp when active.
- 3) <u>Soft Alarm</u> Recoverable Alarm. Engine will shut down as soon as this input is tripped, but will recover to running if the condition is cleared quickly enough.
- 4) <u>Aux Throttle Up</u> Mimics the front panel key press for speed control.
- 5) <u>Aux Throttle Down</u> Mimics the front panel key press for speed control.
- 6) <u>Return to Idle</u> Engine will resume its pre-designated idle speed
- 7) <u>Return to Operating Speed</u> Engine will return to its pre-designated operating speed

DIGITAL FUNCTION MONITORING

<u>Off / Always / Run</u> – Describes when the parameter will be monitored for alarm conditions. Run refers to when the engine is running. Off disables the alarm conditions. Always enables the alarm constantly regardless of engine state.

DIGITAL FUNCTION DELAYS

<u>Alarm Delay</u> – The time period, after Sender Check Bypass, that the parameter must be on the alarm condition before the alarm becomes latched.

CONTROL PANEL RELAY OUTPUTS

The panel is shipped from the factory with the **highlighted** outputs enabled and prewired in the panel.

Relay	Heading	Default	Connector	Pin
	Function	None		
Relay 1	Polarity	Positive		-
	Initial State	Off		
	Function	Fuel/Run		
Relay 2	Polarity	Positive	21-Pin	G
	Initial State	On		
	Function	None		
Relay 3	Polarity	Positive	-	-
	Initial State	Off		
	Function	None		
Relay 4	Polarity	Positive	-	-
	Initial State	Off		
	Function	None		
Relay 5	Polarity	Positive		
	Initial State	Off		
	Function	None		
Relay 6	Polarity	Positive		
	Initial State	Off		
	Function	None		
Relay 7	Polarity	Positive		
	Initial State	Off		
	Function	None		
Relay 8	Polarity	Positive		
	Initial State	Off		

The relays are rated at 5 amps.

RELAY FUNCTIONS

Available relays can be assigned for different uses.

- a. None Assign to "none" when not used.
- b. <u>Pre Alarm</u> Relay will be active when there is a pre alarm condition. Typically used to drive an alarm horn or lamp. Can be used to send a signal to a monitoring station.
- c. <u>Alarm</u> Relay will be active when there is an alarm condition. Typically used to drive an alarm horn or lamp. Also can be used to send a signal to a monitoring station.
- d. <u>Pre Alarm & Alarm</u> Energizes an external audible alarm when a pre alarm or alarm condition is present. Pressing the ENTER button will silence.
- e. <u>Alarm Horn</u> Energizes an external audible alarm when an alarm condition is present. Pressing the ENTER button will silence.
- f. <u>Engine Run</u> Relay will be active when engine RPM is greater than 600. Typically used to drive an auxiliary circuit such as louvers or send a signal to a monitoring station.
- g. Low Oil Press Alarm Relay closes if a low oil pressure shutdown is detected.
- h. <u>High Coolant Temp Alarm</u> Relay closes if a high engine temp shutdown is detected.
- i. Over Speed Alarm Relay closes if an over speed shutdown is detected.
- j. Over Crank Alarm Relay closes if an over crank alarm is detected.
- k. Low Fuel Level Alarm Relay closes if a low fuel level shutdown is detected.
- I. <u>Fuel / Run</u> Relay will be active during an engine start request and while the engine is running. Used to drive the engine's ECU circuit. Also active when requesting active and stored J1939 codes.
- m. <u>Custom 1</u> Reserved for OEM applications.
- n. <u>Throttle B0</u> Reserved for OEM applications.
- o. <u>Throttle B1</u> Reserved for OEM applications.

RELAY POLARITY

- a. Positive Relay acts as a normally open contact.
- b. Invert Relay acts as a normally closed contact.

RELAY INITIAL STATE

- a. On Relay is activated upon power up.
- b. Off Relay is not activated upon power up.

EMISSIONS MONITORING

Emissions Information

The panel provides lamp indications, display messages and other emission related information. This information is broadcast from the engine ECU and is captured and displayed by the panel. The panel includes an <u>Emissions Parameters</u> viewing menu that allows the operator to view the following emissions related information.

Heading	Default	Range
DPF Soot Load	View Only	0 – 200%
DPF Ash Load	View Only	0 – 200%
Time Since Regeneration	View Only	# of Hours Since Last Regeneration
Regeneration Process	Current Status	Active or Not Active





Regeneration

The regeneration process is controlled by the engine ECU. The engine ECU monitors emissions parameters such as soot level and ash level. When the engine ECU determines that a regeneration is necessary, it initiates the regeneration process which requires the engine to operate at a designated speed for a designated period of time as determined by the engine ECU. The engine ECU communicates the need for a regeneration via the regeneration lamp on the panel.



When the engine ECU initiates a regeneration, the yellow DPF (Diesel Particulate Filter) lamp will illuminate with the display message shown above. The operator can press the ENTER button (for Yes) to allow the regeneration to initiate or the MENU button (for No) to delay the regeneration process to a later time. Answering "No" only delays the regeneration process. The regeneration lamp stays illuminated and regen request prompts continue as long as the engine ECU determines a regeneration is required

Over time, the engine ECU increases the level of severity through both lamp indications and display messages.

Levels of severity:

- 1) Lowest Level
- 2) Moderate Level
- 3) High Level
- 4) Warning Level
- 5) Service Regen Level

<u>At the lowest level</u>, the DFP lamp illuminates. As the levels increase, the DFP lamp begins to blink. As the levels continue to increase the yellow alarm lamp illuminates.



<u>At the most severe level</u>, the DPF lamp blinks and the red engine alarm lamp illuminates.



Standard Regeneration

If the operator selects ENTER for yes, the panel will show the "RPM May Increase" message and ask the operator to respond by pressing the MENU button for "no" or the ENTER button for "yes".



This interlock question is asked to make sure the operator is aware that the engine ECU may increase engine speed per the regeneration requirements.





The regeneration active lamp illuminates during the regeneration process. The DFP lamp stays illuminated until the engine ECU determines that a regeneration is no longer required.

Service Regen Level

The most severe level is the <u>service regen level</u>. At this level, the DFP lamp is blinking and the red alarm lamp illuminates. When the service level is reached, the engine ECU has determined that the situation is severe and a service regeneration is necessary. At the service regen level, the engine ECU may de-rate the engine or prevent it from starting and the message shown below appears on the display.



Regen Inhibit

The panel provides two methods for "inhibiting" a regeneration process. The first method is to answer "No" to the Regen Request message when it appears on the display. The second method is to select "Inhibit Regen" in the <u>Emissions Configuration Menu</u> (under Regen Options). The two available settings are "Auto" and "Inhibit Regen".

The "Auto" setting allows the engine ECU to initiate the regeneration process as it requires. The "Inhibit Regen" setting delays the regeneration process. The "Inhibit Regen" setting only delays the regeneration process until higher levels of severity are reached. At higher levels of severity, the engine ECU no longer accepts the "Inhibit Regen" message from the panel.

When the "Inhibit Regen" setting is selected, the inhibit lamp illuminates.



MENU SYSTEM

To Enter Menu System

Hold MENU button and press ENTER button.

Menu Navigation

Press MENU button to scroll menu options. Press the UP arrow button to enter the menu. Press the DOWN arrow button to reverse.

Exit Menu System

Hold MENU button and press ENTER button.

To Change a Setting

Press the ENTER button to bring up brackets, []. Press UP arrow button and DOWN arrow button to change setting. Press ENTER button to make selection, brackets disappear.

Recycle key to the OFF position after changing a setting.

MAIN MENUS

Emissions Parameters	Regen Options		
	DEF Level		
	DPF Soot Load		
	DPF Ash Load		
	Active Regen Status		
	Regen Inhibit Status		
	DPF Out Gas Temperature		
	DPF Differential Pressure		
Active Engine Fault Codes	View/Scroll Active Fault Codes		
Stored Engine Fault Codes	View/Scroll Stored Fault Codes		Viewing Menus
Operation Event Log	View Last 32 Events (Start, Stop, Alarms)		
Alarms Event Log	View Last 32 ECU and Controller Alarms)		
Engine Parameters Menu	View ECU Engine Information		
	(% Load, Torque, Oil Temp, etc.)		
Engine Identification Menu	Engine Model # View		
	Engine Serial # View		
Module Information Menu	Control Unit Part# View	/	1
	Control Unit Software Version View		

Controller Setup Menus	Input Configuration	(1))
(PASSWORD PROTECTED)	Output Configuration	(2)	
	Throttle Configuration	(3)	Configuration
	Engine Safety Configuration	(4)	> Menus
	Module Configuration	(5)	
	CAN Configuration	(6)	
	Emissions Configuration	(7)	J

CONFIGURATION MENUS

(1) Input Configuration	Analog 1 Function (Fuel Level Settings)	
	Digital Input 1 Setup (Pre-Set to Hydro-Throttle)	
	Digital Input 2 Setup (Pre-Set to Override Active)	
	Digital Input 3 Setup (Pre Set to E-Stop)	
	Digital Input 4 Setup (Pre Set to Low Water)	
	Digital Input 5 Setup (NO/NC, Action, Message, When Active, Delay)	
	Digital Input 6 Setup (NO/NC, Action, Message, When Active, Delay)	
	Digital Input 7 Setup (NO/NC, Action, Message, When Active, Delay)	
	Digital Input 8 Setup (NO/NC, Action, Message, When Active, Delay)	
	Digital Input 9 Setup (NO/NC, Action, Message, When Active, Delay)	

(2)	Output Configuration	Relay Output 1 Setup (Function, Polarity, Initial State)
		Relay Output 2 Setup Pre-Set to Fuel/Run
		Relay Output 3 Setup (Function, Polarity, Initial State)
		Relay Output 4 Setup (Function, Polarity, Initial State)
		Relay Output 5 Setup (Function, Polarity, Initial State)
		Relay Output 6 Setup (Function, Polarity, Initial State)
		Relay Output 6 Setup (Function, Polarity, Initial State)
		Relay Output 7 Setup (Function, Polarity, Initial State)
		Relay Output 8 Setup (Function, Polarity, Initial State)

(3)	Throttle Configuration	Throttle Type - Throttle Type Selection (Default = TSC Vernier)
		TSC Mode Selection (Default = Primary)
		TSC Min Speed Selection (Default = 650 RPM)
		TSC Max Speed Selection (Default = 2400 RPM)
		TSC Bump Speed (Default = 20 rpm)
		TSC Ramp Rate Selection (Default = 100 rpm/sec)
		Throttle Curve Selection (Default = Linear)
		Multistate Speed 1 Selection
		Multistate Speed 2 Selection
		Multistate Speed 3 Selection
		Multistate Speed 4 Selection

(4) Engine Safety Configuration	Sender Check Bypass Time (Default = 0:10)
	Fuel Level Check Selection (Default = Off)
	Low Fuel Level Pre Alarm % Selection (Default = 20%)
	Low Fuel Level Alarm % Selection (Default = 1%)
	Fuel Level Alarm Delay Time (Default = 0:05)
	Oil Pressure Check (Default = Run)
	Low Oil Pressure Pre Alarm % (Default = 6 PSI)
	Low Oil Pressure Alarm % (Default = 5 PSI)
	Oil Pressure Alarm Time Delay (Default = 0:10)
	Engine Temperature Check (Default = Run)
	Engine Low Temperature Pre Alarm (Default = 0 Degrees F)
	Engine Low Temperature Alarm (Default = 0 Degrees F)
	Engine High Temperature Pre Alarm (Default = 244 Degrees F)
	Engine High Temperature Alarm (Default = 245 Degrees F)
	Engine Temperature Alarm Time Delay (Default = 0:10)
	Battery Volt Check (Default = Off)
	Low Battery Volt Pre Alarm (Default = 12.0 Volts)
	High Battery Volt Pre Alarm (Default = 15.0 Volts)
	Battery Volt Trim Setting 100mV (Default = 5)
	Over speed Alarm (Default = Off)
	Over speed Alarm RPM Setting (Default = 3000 RPM)
	Over speed Alarm Time Delay Selection

(5)	Module Configuration	English/Metric Selection
		Hour Meter Source (Default Engine ECU)
		Hour Meter Setting (if not ECU)
		Battery Volt Source (Default = J1939)
		Pre Alarms Displayed (Default = 4)
		Clear Operation Log Yes/No
		Clear Alarm Log Yes/No

(6)	CAN Configuration	Source Address (Default = 44)
		TSC1 Address (Default = 3)
		Engine Address (Default = 0)
		Oil/Fuel Transmit

(7)	Emissions Configuration	DEF Level Check (Default = Off)
		Low DEF Pre Alarm (Default = 16%)
		TSC Regen Speed
		Allow Service Regen (Default = No)
		Regen Interlock (Default = Off)
		TSC Transmit (Default = On)